
User manual (internal Cobra document)

## Module description.


1. A PCB assembly that contains the BT IC, flash memory IC, antenna, voltage regulator, and connectors to interconnect to a motherboard.

## Use limitations

- 2. The assembly is designed for inclusion in Cobra radar detector products to supply the BT and laser detection functions.
- 3. The Bluetooth module assembly can only be used in Cobra devices designed for this particular form factor. Other form factors are not allowed without FCC and IC reauthorization.
- 4. Although this device is a very low output power device. The RF exposure limits we self impose are for use in mobile or fixed location products => 20 cm.
- 5. The BT protocols and data interface is per the manufacturer's data sheet for the BT integrated circuit.
- 6. The radiated or conducted output power cannot be changed without re authorization.



Module photo 1



Module photo 2