



# 16'x16' GEOSPORT™ SHADE

## Instructions apply to Part Number 9391-261

### When You Are Ready To Set Up Your Shelter

- Select a level area clear of rocks, branches and other hard or sharp objects.
- Do not assemble your shelter under trees.
- For easier set up, two or more people are recommended.

### ASSEMBLY PARTS

Center Hub Part (1)  
No. 9392-2251



Canopy Poles (5)  
Part No. 9392-6161

Canopy Hub(5)  
Part No. 9392-2261



Leg Hub (5)  
Part No. 9392-2271



Leg Poles (5)  
Part No. 9392-6171



Leg Connector Poles (10)  
Part No. 9392-6181



## 1 Pole & Hub Assembly

- Begin with the Center Hub and Canopy Poles.
- Insert the end marked TOP into the center hub and connect one pole at a time to the hub. (illus.1), (illus. 4)

## 2


- Add a canopy hub to the five open ends of the center hub assembly. (illus. 2), (illus. 4)
- Insert the clip end of Leg Connector Poles into the Canopy Hub.

## 3

- Where the two open ends of the Leg Connector Poles meet, insert them into the two angled openings of the Leg Hub. Repeat for 4 more sets. (illus. 3), (illus. 4)



## 4

- Insert clip end of Leg Pole into open end of Leg Hub. Disconnect the shock-corded Leg Pole so that the lower spiked pole is laying on the ground. (illus. 4)



# 5 Attach Shelter to Frame

- Drape the canopy over the frame (illus. 5)
- Position each corner over a Leg Hub
- Fully extend each pole by completing the interlocking of the shock corded pole sections.
- Insert the brass hook into the hole near the base of the pole (illus. 6, 8)
- From the inside of the shelter secure the pole frame to the shelter with the hook and loop closures.
- Adjust poles to pull the shelter taut and stake down through the fabric loops at the end of each pole
- Adjust hook straps to increase tautness (illus. 7)
- Attach guy lines to fabric guy loops at each corner and stake out (illus. 7)



## Things You Should Know

- Never store shelter, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your shelter. Use separate storage bag.
- STAKES SHOULD BE REMOVED BY PULLING ON THE STAKE ITSELF. NEVER PULL ON THE SHELTER FABRIC OR SHELTER STAKE LOOP TO REMOVE STAKE.
- SHELTER POLES SHOULD NOT BE LEFT TELESKOPED TOGETHER DURING STORAGE.
- Do not leave your shelter set-up for weeks at a time, be aware that exposure to the ultraviolet rays of the sun can seriously damage material and/or cause it to become discolored.

**WARNING: Keep all flame and heat sources away from this tent fabric.** This shelter meets the flammability requirements of CPAI-84. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the shelter fabric may render the flame-resistant properties ineffective.



THE COLEMAN CO., INC.

3600 N. Hydraulic • Wichita, Kansas 67219  
1-800-835-3278 • www.coleman.com

MADE IN CHINA

PRINTED IN CHINA Rev. 8/06