


**To connect Remote Control-Fitted Earphone Microphone**

You can listen to the sound output from your Toshiba Pocket PC by connecting the optional remote control-fitted earphone microphone.

Insert the optional remote control-fitted earphone plug into the stereo headphone jack as shown in the figure below.



*Use the specified remote control-fitted earphone. If you use a different type of earphone, it may malfunction.*

*The connectable pin size of the headphone/earphone is a 3.5 mm mini plug type.*

### **Connecting to a Computer**

Before connecting your Toshiba Pocket PC to a computer, check the following.

- ActiveSync has been installed on your computer. (See Chapter 3.)
- Make sure that the Pocket PC and the computer are both turned off.
- The position of connecting port on the computer may differ according to the computer type.

#### **To Connect Using The Supplied USB Cradle:**

1. Connect the USB cradle to your computer as shown in the illustration below.

