

www.tuv.com

1.6 User Manual

EC - Declaration of Conformity

We, ModeLabs Technologies Ltd of
31/F China Online Centre,
333 Lockhart Road,
Wan Chai, Hong Kong

declare under our sole responsibility that our product

BLUETREK SENSE

to which this declaration refers is in conformity with the appropriate standards

EN300 328-02
EN301 489-17
EN301 489-01
EN50371
EN60950

Following the provisions of Radio and Telecommunications Terminal Equipment directive
1999/5/EC.

September 2007



Guillaume Ponticelli, Director of Development

FCC/ Industry Canada Notice

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

In compliance with Industry Canada regulations, technical specifications have been provided in a declaration of conformity. This does not imply that Industry Canada approved the equipment.

Caution: Changes or modifications to this Bluetooth® headset not expressly approved by the party responsible for compliance could void the user's authority to operate it.

Bluetooth® is a trademark owned by Bluetooth SIG, Inc. and is used by the manufacturer under license.

English

Before using your headset for the first time


- You must charge it continuously for about 4 hours, until the red indicator light turns off. Please refer to the "Charging the BLUETREK® SENSE" section of this manual.
- Pair the headset with a mobile phone. Please refer to the "Pairing the BLUETREK® SENSE" section of this manual.

Introduction

The BLUETREK® SENSE headset is a wireless headset based on the Bluetooth® technology. It complies with Bluetooth® 1.2 protocol, supporting Headset and Hands-free profile.

A built-in voice alert is an advanced feature that is now available on your headset. A recorded voice reminds you of the actions in your headset. For details, please refer to "Voice alert" section of this manual.

- ① Sensitive Key (TALK button)
- ② Main button
- ③ Indicator light



The Sensitive key will automatically lock when your headset is connected to a phone and left idle for more than 20 seconds. To unlock the headset, double click on the Sensitive key. Your headset will also be unlocked automatically when there is an incoming call.

Charging the BLUETREK® SENSE

Please connect the charger to the headset and to the main. During the charge, the indicator light is red. The indicator light will turn off when the charge is complete. During subsequent charges, the charging should take approximately 3 hours.

When you hear a low-tone beep (or the voice alert if activated) in your headset at regular intervals, and the indicator light flashes in red, your headset needs to be recharged.

Important:

- If your headset is fully charged, the red indicator light will not turn on when plugging into the charger.
(To check whether your headset is fully charged, press the talk button for approx. 2 seconds, once released, the red indicator light will turn on for approx. 3 seconds.)
- To maximize battery lifetime, it is recommended to recharge your headset to full capacity only when the battery is low, since a battery has a lifetime of about 500 charging cycles.
- If you leave your headset battery empty for an extended period of time, it could excessively discharge the battery. In this case, charge your headset for 3 hours or more until the battery recovers and recharges completely. When you first charge the headset after prolonged storage, it may take few minutes for the red indicator light to turn on.
- Do not charge your headset for more than 10 hours.
- The use of any other charger will automatically suspend the warranty. It is strictly forbidden and can be very dangerous.


BLUETREK SENSE I 2

Pairing the BLUETREK® SENSE


Before using the BLUETREK® SENSE headset, you must pair it with your Bluetooth® mobile phone. Pairing is the process of linking 2 Bluetooth® devices, so that they can communicate.

To initiate pairing:


- 1 Place the BLUETREK® SENSE and your mobile phone within 0.3 meter (1 foot) from each other.
- 2 Switch on your phone and select its Bluetooth® discover mode (refer to the Bluetooth® mobile phone user manual).



- 3 When the BLUETREK® SENSE is switched off, press and hold the Main button for about 7 seconds until the indicator light flashes red and blue alternately. And a sound can be heard in the speaker.



- 4 Once the mobile phone detects the headset, a "BLUETREK SENSE" message will be displayed. Follow the phone instructions to accept the pairing. The PIN code (or passkey) is 0000, then press "yes" or "ok"



- 5 For some phones, you may need to select "Connect".




If pairing was successful, the indicator light will switch to blue and flashes slowly.

If you haven't started the discovery mode within 5 minutes, the headset will go to the standby mode. You must then switch off your headset and start the pairing again.


BLUETREK SENSE I 4

Wearing the BLUETREK® SENSE

Two different sizes of metal ear hooks are included in the pack to suit your ear size. To attach the ear hook, simply insert the ear hook ring to the back of the headset as shown in the diagrams.



For left ear wearing, the ear hook should be inserted as shown in the diagrams.



Switching the BLUETREK® SENSE ON and OFF

Switching BLUETREK® SENSE ON

When your headset is off, press and hold the Main button for about 3 seconds until the blue indicator light is on. A beep (2 tones) can be heard in the speaker. Release the Main button.

Switching BLUETREK® SENSE OFF

When your headset is on, press and hold the Main button for about 7 seconds until the red indicator light is on. A beep (2 tones) can be heard in the speaker then release the TALK button.

English

Making a call

Mobile phone with voice recognition

- . Make sure the voice recognition function on your mobile is activated and your voice tags have been recorded with the phone. To enter these, please refer to your phone's manual.
- . When there is no incoming or active call, press once on the TALK button
- . Wait for the audio signal sent by the mobile phone (generally a short tone).
- . Speak the name of person you wish to call.

BLUETREK SENSE I 6

English

Mobile without voice recognition

- . Make sure both the headset and the mobile phone are ON and in stand-by mode.
- . Dial the number on the phone keypad, after approximately 2 seconds the audio connection will be established.

This function may not be available on some phones, please refer to the trouble shooting frequent asked questions in our website: www.bluetrek.com. to find out more.

Answering a call

When the headset rings, press once on the TALK button to take the call.

Ending a call

Press once on the TALK button to end an active call.

Adjusting the volume

Adjust the volume from your mobile phone during an active call.

Muting the microphone

Mute the microphone from your mobile phone during an active call.

Transferring a call from BLUETREK® SENSE to the mobile phone

During an active call, double click on the TALK button.

This function only works in the Hands-Free Profile.

In the Headset profile, you can simply turn off your headset.

Transferring a call from the mobile phone to the BLUETREK® SENSE

During an active call on the mobile phone, double click on the TALK button to transfer the call.

This function may not be available depending on your phone.

Call waiting

When you hear a call waiting alert while you are on a call, press approx. 2 seconds on the TALK button to accept the second call and place the current call on hold.

To switch between an active call and a hold call, press approx. 2 seconds on the TALK button.


To end the active call and take the hold call, press once on the TALK button.

This function may not be available, depending on your phone. However, you can always answer the second call from your phone keypad.


BLUETREK SENSE I 8

Fitting bud

4 different sizes of bud are included in the pack to suit your ear size. You can adjust the bud position that you feel the most comfortable.



To replace the bud, remove the speaker cover by pulling gently out from the speaker.



Voice alert

A built-in voice alert is an advanced feature that is now available on your headset. A recorded voice reminds you of the actions in your headset, such as: redial the last number, reject a call, end a call, when your headset needs to be charged, if your headset is connected/disconnected from the handset and lock/unlock the Sensitive key.

The voice alert is activated when you purchase your headset, but you may choose to activate /inactivate this function as follows:

To inactivate the voice alert:

- 1) Ensure your headset is OFF.
- 2) Press and hold the Main button for about 12 seconds until the indicator light flashes twice in blue.
- 3) Press once again on the Main button and the indicator light will flash twice in red. This indicates that the voice alert is inactivated.
- 4) Restart your headset.

To activate the voice alert:

- 1) Ensure your headset is OFF.
- 2) Press and hold the Main button for about 12 seconds until the indicator light flashes twice in red.
- 3) Press once again on the Main button and the indicator light will flash twice in blue. This indicates that the voice alert is activated.
- 4) Restart your headset.

BLUETREK SENSE I 10

Additional features with some phones

Rejecting a call

Press the TALK button for about 2 seconds to reject a call.

Redial the last number

When there is no incoming or active call, press the TALK button for about 3 seconds until you hear a beep (or the voice alert if activated).

Troubleshooting guide

The first thing you should do when encountering a problem that you cannot solve with this manual, is to switch off your headset and your mobile phone, and switch them on again.

To find out more, please refer to the trouble shooting frequent asked questions in our website: www.bluetrek.com.

Guidelines for safe use

Read those guidelines before using your headset.

- The volume level of the Bluetooth® headset may vary, depending on your mobile phone. Before using your headset for the first time, adjust the headset volume to the lowest, then increase the volume gradually until you reach to an acceptable level. High levels of volume may result in hearing loss, avoid using the headset at high volume continuously. If you experience ringing in your ears or muffled speech, consult your doctor immediately and stop using the headset.
- Do not drop or try to alter the shape of your headset.
- Do not expose your headset to liquid or moisture.
- Do not expose your headset to extreme temperatures. Temperature range : 0-40°C.
- Do not expose your headset to fire or open flames.
- Do not try to disassemble your headset. Service and Maintenance can only be performed by authorized BLUETREK® dealers.
- Keep your headset away from dust and dirt.
- Do not let children play with your headset, since it contains small parts that could become detached and create a choking hazard.
- Check the regulation in your area if you plan to use your headset while driving.
- Turn off your headset before boarding an airplane.

CAUTION : The built-in battery is non-replaceable. Do not attempt to replace it. Danger of explosion if battery is incorrectly replaced. Dispose of batteries according to local regulations. Do not dispose as household waste.

BLUETREK SENSE I 12



Note on environmental protection:

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies:

Electrical and electronic devices may not be disposed of with domestic waste.



Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilising old devices, you are making an important contribution to protecting our environment.