





















1.6 User Manual

 <p>model name: COOKOO watch</p>	<p>cookoo Quick Start Guide</p> <p>Step 1: Download the COOKOO™ CONNECTED App For iOS users: Search for the "COOKOO" app on the App Store Compatible with the new iPhone 5, iPhone 4S, iPad (4th generation) and iPad (3rd generation) with iOS 6 or iOS 5. Please visit cookoowatch.com for latest compatibility list.</p> <p>Step 2: Connect the COOKOO watch with your mobile phone or tablet</p> <ol style="list-style-type: none"> 1. Turn on the watch's CONNECTED Display by pressing the CONNECT button for 6 seconds. 2. Open the COOKOO CONNECTED App on your mobile or tablet, the App will search for your watch and connect with it (you can select your watch from the devices list if it doesn't automatically connect). <p>Step 3: Customize your COOKOO watch's settings Select your watch from the devices list in the COOKOO App and tap the settings button to customize your watch's alerts*.</p> <p>cookoo Your phone is connected  Your watch's beep is activated  Your watch's vibration is activated  You have an alarm* or reminder  You have received a chat or text*  It is time to charge your phone  You have received an email*  You have a call or missing call</p> <p>* Some notifications may not be available in iOS devices today, but are anticipated in future iOS releases or through a server / push. More CONNECTED functions will be enabled in the near future with new app releases. Visit cookoowatch.com for more information.</p>
<p>Battery for CONNECTED System</p>  <p>model CR2032</p>	<p>Illustration of buttons</p>  <p>acknowledge the alert or change the notification setting > beep only > vibration only > beep & vibration > alerts off</p> <p>adjust the time</p> <p>configurable via the COOKOO CONNECTED App</p>
<p>Battery for analog movement</p>  <p>model SR626SW</p>	<p>You can also customize the COMMAND button under the setting menu:</p>  <p>Check in on Facebook Drop a pin Take a picture Find your phone</p> <p>Replacing the Battery for the CONNECTED System 1. Open the battery cover and remove the old battery.</p>  <p>model CR2032 Battery cover (Open to insert/replace the battery)</p>
 <p>cookoowatch.com</p>  <p>store.cookoowatch.com</p>	<p>2. Remove the old battery and apply a hard reset by touching the two metal battery contacts together for 3 seconds using a metal paperclip (see image).</p>  <p>touch the two metal parts for 3s to reset battery for analog movement* black O-ring</p> <p>3. Insert the new battery and replace the battery cover (make sure the black O-ring is correctly positioned to ensure water resistance).</p> <p>*For the Analog movement: Open the battery cover and replace a new battery (model SR626SW, battery life lasts up to 3 years*) underneath the CONNECTED System battery. **Battery life may vary depending on brand and condition of battery</p> <p>For more information about the watch and app, check out the help section in the app or visit our website cookoowatch.com. For more support, please email us at support@cookoowatch.com</p> <p>Limited 1 year free warranty Visit cookoowatch.com for product registration. You will need to keep your original receipt as proof of purchase. To keep your watch in good condition and to avoid voiding the warranty:</p>
<p>app download</p>  <p>support</p>  <p>facebook</p>  <p>twitter</p> 	<p>Bluetooth range is up to 33 feet (10 metres). Obstructions, such as walls or other electronic devices, can cause interference or shorten the effective range. For optimal performance, place your watch and phone on the same side of your body.</p> <ul style="list-style-type: none"> • Do not open or disassemble the watch. • Do not expose the watch to excessive pressure, impact, dust, open flames, or extreme temperatures. • Operating temperature: -20 to +55C (-4 to +131F) • Always ensure the battery cover O-ring is correctly in place and the watch is tightly sealed before exposing the watch to any moisture or liquid. • Avoid submerging the watch for an extended period of time. • 5 ATM of water resistance means that your COOKOO watch is wearable around household sinks, while playing sports and while swimming in shallow water. Do not wear it while bathing, snorkeling or scuba diving. • Keep the front glass away from sharp or hard objects to prevent scratching. • Do not attempt to repair or modify the watch yourself. Service and maintenance can only be performed by authorized technicians. • Exposure to high or low temperatures may shorten battery life. • Keep the watch, accessories, and any small parts out of the reach of children. <p>Thank you for supporting COOKOO™</p>


FCC/ Industry Canada Notice

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. In compliance with Industry Canada regulations, technical specifications have been provided in a declaration of conformity. This does not imply that Industry Canada approved the equipment. Caution: Changes or modifications to this Bluetooth® device not expressly approved by the party responsible for compliance could void the user's authority to operate it.

Certification and Safety approvals

This product is CE marked according to the provisions of the R&TTE Directive (99/5/EC). We declare that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. For further information, please refer to website.



Bluetooth® is a trademark owned by Bluetooth SIG, Inc. and is used by the manufacturer under license.

EN Note on environmental protection:

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices.

702-000231-04

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NCC

本產品符合低功率電波輻射性電機管理辦法第十二條、第十四條等條文規定。

1. 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
2. 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

Company name : Bluetrek Technologies Ltd -8/F. Tai Yip Building, 141 Thomson Rd, Wan Chai, HongKong

FR Remarques concernant la protection de l'environnement:

Conformément à la directive européenne 2002/96/CE et 2006/66/CE, et afin d'atteindre un certain nombre d'objectifs en matière de protection de l'environnement, les règles suivantes doivent être appliquées:
Les appareils électriques et électroniques ainsi que les batteries ne doivent pas être éliminés avec les déchets ménagers. Le pictogramme "picto" présent sur le produit, son manuel d'utilisation ou son emballage indique que le produit est soumis à cette réglementation. Le consommateur doit retourner le produit/la batterie usager aux points de collecte prévus à cet effet. Il peut aussi le remettre à un revendeur. En permettant enfin le recyclage des produits ainsi que les batteries, le consommateur contribuera à la protection de notre environnement. C'est un acte écologique.

ES Nota sobre la protección medioambiental:

Después de la puesta en marcha de la directiva Europea 2002/96/EU y 2006/66/EU en el sistema legislativo nacional, se aplicara lo siguiente: Los aparatos eléctricos y electrónicos, así como las baterías, no se deben evacuar en la basura doméstica. El usuario está legalmente obligado a llevar los aparatos eléctricos y electrónicos, así como pilas y pilas recargables, al final de su vida útil a los puntos de recogida comunales o a devolverlos al lugar donde los adquirió. Los detalles quedaran definidos por la ley de cada país. El símbolo en el producto, en las instrucciones de uso o en el embalaje hace referencia a ello. Gracias al reciclaje, al reciclaje del material o a otras formas de reciclaje de aparatos/pilas usados, contribuye Usted de forma importante a la protección de nuestro medio ambiente.

DE Hinweis zum Umweltschutz:

Ab dem Zeitpunkt der Umsetzung der europäischen Richtlinien 2002/96/EG und 2006/66/EG in nationales Recht gilt folgendes: Elektrische und elektronische Geräte sowie Batterien dürfen nicht mit dem Hausmüll entsorgt werden. Der Verbraucher ist gesetzlich verpflichtet, elektrische und elektronische Geräte sowie Batterien am Ende ihrer Lebensdauer an den dafür eingerichteten, öffentlichen Sammelstellen oder an die Verkaufsstelle zurückzugeben. Einzelheiten dazu regelt das jeweilige Landesrecht. Das Symbol auf dem Produkt, der Gebrauchsanleitung oder der Verpackung weist auf diese Bestimmungen hin. Mit der Wiederverwertung, der stofflichen Verwertung oder anderen Formen der Verwertung von Altgeräten/Batterien leisten Sie einen wichtigen Beitrag zum Schutz unserer Umwelt.

IT Informazioni per protezione ambientale:

Dopo l'implementazione della Direttiva Europea 2002/96/EU e 2006/66/EU nel sistema legale nazionale, ci sono le seguenti applicazioni: Le apparecchiature elettriche ed elettroniche e le batterie non devono essere smaltite con i rifiuti domestici. I consumatori sono obbligati dalla legge a restituire i dispositivi elettrici ed elettronici e le batterie alla fine della loro vita utile ai punti di raccolta pubblici previsti per questo scopo o nei punti vendita. Dettagli di quanto riportato sono definiti dalle leggi nazionali di ogni stato. Questo simbolo sul prodotto, sul manuale d'istruzioni o sull'imballo indicano che questo prodotto è soggetto a queste regole. Riciclando, ri-utilizzando i materiali o utilizzando sotto altre forme i vecchi prodotti/le batterie, darete un importante contributo alla protezione dell'ambiente.

DU Notitie aangaande de bescherming van het milieu:

Ten gevolge van de invoering van de Europese Richtlijn 2002/96/EU en 2006/66/EU in het nationaal juridisch systeem, is het volgende van toepassing:
Elektrische en elektronische apparatuur, zoals batterijen mag niet met het huisvuil weggegooid worden. Consumenten zijn wettelijk verplicht om elektrische en elektronische apparaten zoals batterijen op het einde van gebruik in te dienen bij opbarensa verzamelpunten special opgezet voor dit doeleinde of bij een verkooppunt. Verdere specificaties aangaande dit onderwerp zijn omschreven door de nationale wet van het betreffende land. Dit symbool op het product, de gebruiksaanwijzing of de verpakking duidt erop dat het product onderworpen is aan deze richtlijnen. Door te recyclen, hergebruiken van materialen of andere vormen van hergebruiken van oude toestellen/batterijen, levert u een grote bijdrage aan de bescherming van het milieu.

Fin Ympäristönsuojelua koskeva ohje:

Sisältä lähinnä, kun Euroopan unionin direktiivi 2002/96/EU ja 2006/66/EU otetaan käyttöön kansallisessa lainsäädännössä, pätevät seuraavat määräykset:
Sähkö- ja elektronikkalaitteita ja paristoja ei saa hävittää talousjätteen mukana. Kuluttajilla on lain mukaan velvollisuus toimittaa sähkö- ja elektronikkalaitteet niiden käyttöänsä päätyttyä niille varattuihin julkisiin keräyspisteisiin tai palauttaa ne myyntipaikkaan. Tähän liittyvät yksityiskohtaiset säädetään kulloisenkin osavaltion laissa. Näistä määräyksistä mainitaan myös tuotteen symbolissa, käyttöohjeessa tai pakkauskassassa. Uudelleenkäyttöä, materiaalien paristojen uudelleenkäyttöä tai muilla vanhojen laitteiden uudelleenkäyttöä on tärkeä vaikutus yhteisen ympäristömme suojelussa.