

Document :

User Manual for BH/HM Fob

Project :

BH / HM Fob

Project Code :

Version:

0.1

Date:

Jun. 07 '07

Engineering change order-No.:

Design Freeze No.:

Number of pages:

6

Filename:

User Manual for BH_HM_Fob

Contents list

Page

1.	System configuration	3
1.1	Scope of SMART KEY SYSTEM	3
1.2	Short description of the SYSTEM	3
1.2.1	General Definition of SMART KEY	3
1.2.2	Wireless Communication	3
1.2.3	Concept Description	3
1.3	System Overview / Block Diagram	4
2	Smart Key Fob for homologation	6

Proprietary data, company confidential. All rights reserved.
Confidential à titre de secret d'entreprise. Tous droits réservés.
Comunicado como secreto empresarial. Reservados todos los derechos.
Confidido como secreto industrial. Nos reservamos todos los derechos.

Weitergabe sowie Vervielfältigung dieser Unterlage, Verbreitung und Mitteilung ihres Inhalts nicht gestattet, sofern nicht ausdrücklich zugestanden. Zu widerhandlungen verpflichten zu Schadensersatz. Alle Rechte vorbehalten, insbesondere für den Fall der Patenterteilung oder Gm-Eintragung

Editor : KK Ko	Document name	Project code
Version: 0.1 Jun. 07. 2007 File: User Manual for BH_HM_Fob	ECO / DF No. Identification No. : Document No.	Page 2 / 6

1. System configuration

1.1 Scope of SMART KEY SYSTEM

The System offers the following features:

- passive access for two doors, driver side and passenger side as well as trunk/tailgate
- passive start after interior detection of the SMART KEY FOB (without interior trunk and hat shelf detection)
- LF-RF communication (based on Siemens' SMART KEY system)
- passive access trunk/tailgate via the trunk lid switch at the trunk
- max. 2 SMART KEY FOBS can be handled by the system
- communication to the engine management system via a single line interface
- communication to the ESCL via a single line interface

1.2 Short description of the SYSTEM

1.2.1 General Definition of SMART KEY

The SMART KEY system is a system that allows the user to access and operate a vehicle in a very convenient way. To access the vehicle no traditional key or remote control unit is needed.

The user carries a SMART KEY FOB which itself does not require any conscious actions by the user (e.g. operate a button).

After being triggered the vehicle sends out a request in a limited range. If the SMART KEY FOB receives this request, it automatically sends a response to the vehicle. Then the system decides whether to perform a particular action (unlocking, locking...) or remain inactive.

1.2.2 Wireless Communication

Electromagnetic waves are used to exchange information between the vehicle and the SMART KEY FOB. Both, vehicle and SMART KEY FOB are equipped with a transmitter, a receiver and several antennas.

1.2.3 Concept Description

With this concept it is possible to have a set of interior antennas that covers the vehicle's interior and a set of exterior antennas that covers the vehicle's exterior.

For an unambiguous separation between the vehicle's interior and exterior it is sufficient that at least one area is covered exactly by the corresponding operating ranges of the antennas.

The functions of the SMART KEY system have to be provided in a clearly defined and limited range. For the up-link from the vehicle to the SMART KEY FOB, a magnetic field with a frequency of 125 kHz and ASK modulation is used. Inductive antennas in and at the vehicle radiate the electromagnetic energy.

Editor : KK Ko	Document name	Project code
Version: 0.1 Jun. 07. 2007 File: User Manual for BH_HM_Fob	ECO / DF No. Identification No. : Document No.	Page 3 / 6

Proprietary
Confidential
à
data, company
tire de secret
Comunicado como
segredo empresarial.
Confiditado como
secreto industrial.

All rights reserved.
Tous droits réservés.
Reservados todos os direitos.
Nos reservamos todos los derechos.

Weitergabe sowie Vervielfältigung dieser Unterlage, Verwertung und Mitteilung ihres Inhalts nicht gestattet, soweit nicht ausdrücklich zugestanden. Zweiherhandlungen verpflichten zu Schadensersatz. Alle Rechte vorbehalten, insbesondere für den Fall der Patentteilung oder GM-Eintragung

Technical aspects of 125 kHz – magnetic field:

- virtually no reflections,
 - cubical decrease of field strength → allows good range control,
 - released frequency band (ISM),
 - high penetration,
 - low quiescent current demand due to 125 kHz input stage (SMART KEY FOB),
 - less sensitive for detuning compared to higher frequency.

For the down-link from the SMART KEY FOB to the vehicle, the standard radio frequency (RF) is used (similar to the classic remote control functions) with FSK modulation.

1.3 System Overview / Block Diagram




Figure 1: Principle of Communication

Editor : KK Ko	Document name	Project code
Version: 0.1 Jun. 07. 2007 File: User Manual for BH_HM_Fob	ECO / DF No. Identification No. : Document No.	Page 4 / 6

Proprietary data, company confidential. All rights reserved. Comunicado como secreto empresarial. Reservados todos os direitos. Considerado como secreto industrial. Nos reservamos todos los derechos.

Weitergabe sowie Veröffentlichung dieser Unterlage, Verwertung und Mitteilung ihres Inhalts nicht gestattet, soweit nicht ausdrücklich zugestanden. Zweiherhandlungen verpflichtlichen zu Schadensersatz. Alle Rechte vorbehalten, insbesondere für den Fall der Patentteilung oder GM-Eintragung




Figure 2: System Block Diagram

Editor : KK Ko	Document name	Project code
Version: 0.1 Jun. 07. 2007 File: User Manual for BH_HM_Fob	ECO / DF No. Identification No. : Document No.	Page 5 / 6

2 Homologation

FCC Compliance Statement.

This device complies with part 15 of the FCC Rules.
 Operation is subject to the following two conditions :
 (1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including
 interference that may cause undesired operation.

Do Not



Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

Editor : KK Ko	Document name	Project code
Version: 0.1 Jun. 07. 2007 File: User Manual for BH_HM_Fob	ECO / DF No. Identification No. : Document No.	Page 6 / 6