

## **MODEL : CC-2G1**

### **1. INTRODUCTION**

Thank you for choosing a Community Controls products. Please read this manual carefully before using the product.

### **2. PROGRAMMING**

Find the 'learn' button on your existing garage door opener (the motor unit) located on the ceiling of your garage. Press and hold this 'learn' button for 2 seconds and then release. The LED light located beside the 'learn' button will go on. Then press the button on your new transmitter remote for 1 second and then release to activate it. The LED light on your existing garage door opener will flash, then go off. Your remote transmitter is now programmed into your existing garage door opener and will operate your garage door.

### **3. OPERATION**

Press the button from a distance of about 10 feet. If the receiver activates, the garage door opener will start to operate.

### **4. BATTERY ACCESS**

Slide the front cover down to reach battery compartment. Attend to proper polarity when installing or replacing the battery.

The A23 battery has a shelf life of about 1 year.

### **FCC**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **WARNING**

DO NOT let children use the garage door transmitter without adult supervision. Children can injure themselves or others with the garage door opener.

**WARRANTY**

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

**Controlled Entry Distributors, Inc.**

2500 South 3850 West, Suite A, Salt Lake City, Utah 84120, USA

Tel: (801) 972-4331 [www.communitycontrols.com](http://www.communitycontrols.com)