



easy-squeeze

Space Talkies


Grip-it, light-up, walkie-talkie fun

Get Started

1. Insert one new 9-volt battery into each Space Talkie.

2. Slide the power switch on the side to I (ON).

3. Squeeze and hold the buttons on either side of your Space Talkie to talk to your friend. When the rocket mouthpiece shines green, your friend can hear you.



4. To hear your friend talk, let go of the buttons.

5. You can attach your Space Talkie to your pocket or belt using the clip on the back.

6. Now go and make someone giggle. Have fun!

Note: To save battery power, slide the switch to O (OFF) when you've finished playing.

For even more fun, visit cranium.com!

WOeng01

SpaceTalkies_WOeng_Instructions.1 1

6/29/07 3:26:42 PM

TROUBLESHOOTING

Are you having trouble with your Easy-Squeeze Space Talkies?

- If one of your Space Talkies won't turn on or light up, try installing a new 9-volt battery.
- If one of your Space Talkies sounds garbled or has static, move away from microwaves, cell phones, cordless phones, etc., and make sure you're within 30 feet of the other Talkie.

If you've tried these steps and you're still having trouble...

- In the U.S., go to cranium.com/support or call 1-877-CRANIUM
- Outside the U.S., go to cranium.com/worldwidesupport

We value your input and we'll do our best to help!

CHANGING THE BATTERY

Need to change the battery? Ask an adult to get a new 9-volt battery and follow these instructions.

1. Turn the Space Talkie over and unscrew the battery cover.

2. Insert the battery as indicated.

3. Replace the battery cover and tighten the screw.

WARNING: CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

WARNING: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules and EMC regulations. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Model no. 304021000, Canada 310. Carrier frequency: 27.145 MHz, field strength: 60.2 dBfV/m at 3 m. This radiocommunication device complies with all the requirements of Industry Canada Standard RSS-310. Ce dispositif de radiocommunication renvoie toutes les exigences de la norme CNR-310 d'Industrie Canada. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

© 2007 CRANIUM, INC. ALL RIGHTS RESERVED. THE FOLLOWING ARE TRADEMARKS OR REGISTERED TRADEMARKS OF CRANIUM, INC. IN THE U.S. AND/OR OTHER JURISDICTIONS: CRANIUM, CREATIVE CAT, DATA HEAD, EVERYONE SHINES, STAR PERFORMER, WORD WORM, THE CRANIUM LOGO, AND THE BRAIN LOGO. WE PACK EVERY CRANIUM TOY WITH A VARIETY OF OUTRAGEOUS ACTIVITIES. IT'S UP TO YOU TO USE CAUTION, PLAY IT SMART, AND HAVE FUN.

BATTERY SAFETY

- Do not put the battery in backwards. Positive (+) and negative (-) ends must be inserted in the correct directions following the polarity (+/-) diagram in the battery compartment.

- Only batteries of the same or equivalent type as recommended are to be used.

- Rechargeable batteries must be removed before recharging.

- Rechargeable batteries must be recharged by an adult only.

- Batteries must be installed and removed by an adult only.

- Remove exhausted batteries and dispose of them properly.

- Do not try to recharge non-rechargeable batteries.

- The supply terminal is not to be short-circuited.



WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.

For even more fun, visit cranium.com!

SpaceTalkies_WOeng_Instructions.2 2

6/29/07 3:26:49 PM