

The background image shows two women from behind, their arms raised in celebration. They are standing on a balcony or terrace overlooking a vast, scenic landscape of rolling green hills and a valley. The lighting is warm, suggesting a sunset or sunrise. The woman on the left has dark hair and is wearing a black top with a blue bag slung over her shoulder. The woman on the right has long, blonde hair and is also wearing a black top. The overall mood is one of joy and achievement.

CRAVE

Curve

USER GUIDE

TABLE OF CONTENTS

Package Contents

03

Connectivity

06

Specifications

09

Overview

04

Audio Control

07

Troubleshooting

10

Powering

05

Phone Calls

08


Safety

12


PACKAGE CONTENTS



User Guide



Micro USB Charging Cable



Crave Curve Speaker

OVERVIEW



Press and hold to turn the speaker on or off.



Press this button to **Play/Pause** audio.



Press and hold the **+** or **-** button to increase or decrease volume.



Tap (without holding) the **+** or **-** button to switch between audio tracks.

POWERING


Charge the Crave Curve speaker with the provided USB cable and your USB charger (not included) before first time use.



Power the speaker on/off by holding the power button.

CONNECTIVITY

Connection via Bluetooth

- Hold  for several seconds to Power On.
 - Listen for Power On tone, followed by Bluetooth pairing signal.
 - Enable Bluetooth function on your device.
 - Speaker will remain in pairing mode until located on the device list.
 - Select "CRAVE Curve" speaker from the device list.
- Once paired, you will hear Bluetooth connected tone.


Connection via the 3.5mm stereo cable (non Bluetooth option)

- Connect your device to the 3.5mm port using a stereo audio cable.
- Play audio from any device utilizing the 3.5mm output port.

AUDIO CONTROL


For best sound quality:

- 01** Place the speaker base on a hard surface.
- 02** Face the speaker in direction of user.
- 03** Keep the device within speaker range.



PHONE CALLS

Using built-in speakerphone and microphone



Accept/end a phone call by pressing the Play/Pause button or from your phone directly.

SPECIFICATIONS



USB Charge Voltage:
DC 5V, 1.5A



Battery size:
2000 mAh



Frequency:
90Hz - 20kHz



Speaker Power:
10W x2



Bluetooth Range:
66 ft.(20m)



Size:
7.87x2.36x2.36 in

TROUBLESHOOTING

Sound Quality

- 1 | Check if your phone/tablet/device is in close proximity to the speaker.
- 2 | Remove any visible obstructions between the speaker and your device.
- 3 | Reduce volume on the device.

Speaker is disconnecting from phone/tablet

- 1 | Move your device closer to the speaker.
- 2 | Power cycle the speaker off/on and reconnect.
- 3 | Remove any visible obstruction between the speaker and your device.
- 4 | Check for signal interference from other devices in proximity to the speaker.

TROUBLESHOOTING

Unable to pair the speaker with your phone/tablet

- 1 | Check if Bluetooth function is enabled on your device.
- 2 | Check the speaker for low battery (plug into power source).
- 3 | Check if the speaker is possibly paired to another device.
- 4 | One Bluetooth enabled device should be available for pairing at any given time, multiple enabled devices can cause the speaker to pair to another device without you knowing.

Volume too low/volume too high

- 1 | Turn volume up or down on the speaker or your device.
- 2 | Check if the 3.5mm cable is well connected (non Bluetooth option).

SAFETY

Read safety precautions carefully to ensure your personal safety and to prevent property damage

Fire Safety

- 1 | Do not attempt to repair or take the speaker apart.
- 2 | Do not leave the speaker in direct sunlight and/or extreme temperatures.
- 3 | Do not charge the speaker in wet or damp areas.
- 4 | Do not leave the speaker near an open fire or hot surfaces.

Drop/Fall

- 1 | Do not leave unattended on any surface, vibration of the speaker may cause movement.

SAFETY

Electrical Safety

- 1 | Do not expose or use the speaker in rain, moisture, humidity or near water.
- 2 | Do not disassemble, break open, crush, bend, puncture, shred, microwave, paint or insert foreign objects into the speaker.
- 3 | Clean using a dry cloth only.

Disposal

- 1 | Never dispose of the speaker through burning.
- 2 | Dispose of the speaker in accordance with local battery disposal regulations.

FCC INFORMATION

FCC Radiation Exposure Statement

FCC ID: 2AN7XC20W01

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

FCC INFORMATION

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

(continued on the following page)

FCC INFORMATION

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CRAVE



@crave.direct



cravedirect.com



@cravedirect

Questions or comments? Please contact us at support@cravedirect.com

Designed by Crave in USA.
Made in China.