





Installation diagram: WarmUp with Bluetooth® Hub and relay with GND pin

