



◆ TROUBLESHOOTING

Something not sound right?No sound at all?
Microphone not working?
• Try to move to the microphone closer to the location of the bluetooth device connected.When the headset located close to connect bluetooth device range (barrier-free or interference farthest 8 meters) inside,On the headset electricity/wireless connection status indicator should show stable green light.
• Adjust the volume and microphone settings to an audible level in both your application and operating system/Bluetooth device.
• Try using the headphones with another computer.

Headphones not working with acomputer?
•If the headphones don't work and you're using a computer, you may need to specify the headphones as the default audio output/input device for your operating system.
•Decide whether computers for bluetooth device or external USB bluetooth equipment;
Such as: computer external USB bluetooth adapter.

Windows®XP
1.Go to Start/Control Panel/Sounds and Audio devices/Audio tab.
2.In the Sound Playback/Default Device window, choose the Bluetooth AV Audio Wireless Headphones.
3.Select the Voice tab.
4.In the Voice tab,choose the Bluetooth AV Audio Wireless Headphones.
5.Click ok.
6.Restart your media application.

Windows®Vista and Windows®7
1.Go to Start/Control Panel/Sounds/Playback Devices tab.
2.Choose Playback Devices.
3.Choose the Bluetooth AV Audio Wireless Headphones.
4.Click Set Default,and then click OK.
5.Select the Recording Tab.
6.Choose the Bluetooth AV Audio Wireless Headphones.
7.Click Set Default,and then click OK.
8.Restart yout media application.



◆ TROUBLESHOOTING

Mac® OS
1.Open System Preferences.
2.Click on the Sound icon.
3.Click on the Output tab.
4.Choose the luckee phone Wireless Headphones.
5.Select the Lnpot tab.
6.Choose the luckee phone Wireless Headphones.
7.Close window.
8.Restart your media application.

Headphones not charging?
•Use the provided USB charging cable,connect the cable to the charging port on the headphones,Connect the other end ot the cable to a USB port on your computer(or to an optional USB charger).
•If you are using a USB hub, connect the charging cable directly to a USB port on your computer.
•If on the headset electricity/wireless connection instruction set is not purple lights (stable or flashing blue light), That is no headphones from the computer USB port receiving power. Please try to use a computer on the other USB port, and then open the computer or wake up, the headset to charge.
•exit and restart the media application.
•try on another computer is to use the earphone.

Music controls not working?
•Music controls for applications other than iTunes,QQ Music and Windows Media Player® are not supported.

Bluetooth not connecting?
•Try moving the headphones closer to your Bluetooth device.The Battery/wireless status light on the headphones turns solid blue when the headphones are in range (up to 8m)with the Bluetooth device.



◆ TROUBLESHOOTING

•Try powering off the headphone,and then power it back on by pressing the Multi-function button.
•Make sure the headphones are selected as the active output audio device on your Bluetooth device.
•Re-establish pairing between the headphones and your Bluetooth device.For more informatiN,refer to First Bluetooth pairing and Additional Bluetooth pairings in this guide.
•Try using the headphones with a different Bluetooth device.

◆ SAFETY INFORMATION

Read and follow these instructions,heed all warnings.and keep this document for future re ference.
•Do not use your product near water,including dripping or splashing sources(e.g.,indoor fountains),or near objects filled with liquids, such as flower vases or fish tanks.

•Do not use your product near water(e.g.,radiators,heat registers, stoves,open flames,such as lighted candles,or other heat-producing devices,such as audio amplifiers or Tvs.)

•Refer all servicing and repair to qualified service personnel.

•Please use the appropriate music volume so as not to damage your hearing and sound system.your hearing and sound system.

•Your product is suitable for use in semi-tropical and moderate climates only.



◆ SAFETY INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)this device may not cause harmful interference, and
(2)this device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.



LUCKEE 乐天下®
BLUETOOTH HEADPHONES




BH2100H
USER MANUAL
Please read carefully before use




LIST OF THE ACCESSORIES


Open the package, please checked the model and the mark on the packing box,checked the type of physical from the packing list of accessories, such as wrong product model,or inconformity items different with the accessories list,please contact the businessman where you purchase as soon as possible.



1



3




2

- 1.Luckee phone 1pcs
- 2.User's Manual 1pcs
- 3.USB Cable 1pcs



PRODUCT FEATURES



- 1.Adjustable headband
- 2.Multi-function button
(power on/off, pairing, play/ pause, answer/reject calls)
- 3.Volume up/next song
- 4.Volume down/prev
- 5.Sculpted ear pads
- 6.Noise-canceling microphone
- 7.Battery/wireless status light
- 8.Charging port
- 9.USB charging cable

SPECIFICATIONS

- Wear mode-----Over ear
- Speaker diameter -----30 mm
- Drag resistance -----32 Ω
- Power supply mode-----lithium battery
- Connector-----micro USB
- Receiving distance-----8 m
- Conversation time -----about eight hours
- Charging time-----2 ~ 3 hours
- Working current-----maximum 35 ma
- Charging voltage-----USB 5 v
- Applicable scope-----mobile phones,

Bluetooth function of the computer



CONNECT TO A BLUETOOTH® DEVICE

- First Bluetooth pairing**
- 1.Power on the Bluetooth device (e.g.MP3,mobile phone, smartphone or tablet)to be paired with the headphones.Turn on Bluetooth for that device.(Refer to your Bluetooth device documentation to complete these tasks.
 - 2.Long press for nine seconds the headphone Multi-function button. The headphone status light blinks rapidly.The headphones enter pairing mode.
 - 3.In the Bluetooth device menu,select luckee phone from the Bluetooth device requests a security code,PIN,enter 0000.
 - 4.When the headphone status light turns solid Blue,a Bluetooth connection is made.



CHARGING

To charge the headphones,plug hte included USB charging cable into your headphones and computer(or an optional USB charger). When the headphone battery is very low,a full charge about take up to three hours.But you don't have to stop using\the headphones because they charge while you talk or listen to music.



USE THE HEADPHONES

- Listen to music or make an internet call.**
- listen to music.**
- 1.Select an audio track or video clip.
 - 2.Tap the Multi-function button to play the audio track or video clip. Tap the Multi-function button to pause the track or clip.
 - 3.Long press the volume "+" / "-" button control the Volume up/down, short press control the next song/previous.When the maximun volume is reached,the headphones emit a tone.
- Answer an incoming call.**
- Connect the headphones to a smartphone.Tap (press for less than one second)the Multi-function button to answer an incoming call.
- Reject an incoming call.**
- Press for two seconds the Multi-function button.
- End a call.**
- Tap(Press for less than one second)the Multi-function button to end the call.
- Start and shutdown.**
- 1. Long press multi-function key 5 seconds, complete the startup or shutdown.
 - 2. When the phone is switched on your headset automatically connect the last shutdown using equipment.

Bluetooth and USB wireless Nano receiver indications

Solid blue	Bluetooth:Aconnection is made;your headphones are ready to use.
Flashing blue	Bluetooth:Arapid blink indicates pairing is achieved; a slower blink indicates the headphones are connectable,but not connected.
No light	Your headphones are powered off.

Light	Battery level	Charging complete
Red and beeping	< 10%	< 30 minutes of talk time left
Flashing purple		Headphones charging
Steady purple	100%	Charging complete