











EN	Component	Description
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pause music when pressed.
	2 Volume up button	Increases the volume when pressed.
	3 Volume down button	Decreases the volume when pressed.
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
	6 Audio-in jack	Connects the speaker to a device.
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before

Blinking white and amber: The speaker is pairing Blinking amber: The battery is low. Solid amber: The speaker is This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain

first use.

Solid white: The speaker is paired

or connected directly to an audio

the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the ${\it Product}$ Notices included with your product.

Power light

	*Cable not included.		
AR	Component	Description	
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.	
	2 Volume up button	Increases the volume when pressed.	
	3 Volume down button	Decreases the volume when pressed.	
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.	
	6 Audio-in jack	Connects the speaker to a device.	
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.	
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device. Blinking white and amber: The	

wer. Be before paired audio speaker is pairing. Blinking amber: The battery is low. Solid amber: The speaker is charging.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product.

*Cable not included.

Comp	onent	Description
① Ca	ll button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
_	lume up tton	Increases the volume when pressed.
_	lume down tton	Decreases the volume when pressed.
4 Po	wer button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6 Au	dio-in jack	Connects the speaker to a device.
6 Mid	cro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
7 Po	wer light	Solid white: The speaker is paired or connected directly to an audio device. Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is low. Solid amber: The speaker is charging.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

Component	Description
1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2 Volume up button	Increases the volume when pressed.
3 Volume down button	Decreases the volume when pressed.
Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6 Audio-in jack	Connects the speaker to a device.
6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
	Blinking white and amber: The speaker is pairing.
	Blinking amber: The battery is low.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental

Solid amber: The speaker is

Damage Protection Care Pack. For regulatory and safety notices, refer to the ${\it Product}$ ${\it Notices} \ {\it included} \ with your \ product.$

*Cable not included.

CS	Component	Description
	Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
	2 Volume up button	Increases the volume when pressed.
	3 Volume down button	Decreases the volume when pressed.
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
	6 Audio-in jack	Connects the speaker to a device.
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is low.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

charging.

Solid amber: The speaker is

For regulatory and safety notices, refer to the *Product Notices* included with your product.

*Cable not included.

DA	Component	Description
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or paus music when pressed.
	2 Volume up button	Increases the volume when pressed.
	3 Volume down button	Decreases the volume when pressed.
	4 Power button	Turns the speaker on or off when pressed. The speaker automatical connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
	6 Audio-in jack	Connects the speaker to a device.
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is low
		Solid amber: The speaker is charging.
	This product is rate	ed IP-64, which means that it is

protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the Product Notices included with your product. *Cable not included.

nponent	Description	
Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.	
Volume up button	Increases the volume when pressed.	
Volume down button	Decreases the volume when pressed.	
Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.	
Audio-in jack	Connects the speaker to a device.	
Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.	
Power light	Solid white: The speaker is paired or connected directly to an audio device.	
	Blinking white and amber: The speaker is pairing.	
	Blinking amber: The battery is low. Solid amber: The speaker is charqing.	
	Volume up button Volume down button Power button Audio-in jack Micro USB port	

protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a quarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product*

Notices	Notices included with your product.	
*Cable	not included	
Compo	onent	Description
1 Call	button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2 Volument	ume up ton	Increases the volume when pressed.
3 Vol	ume down ton	Decreases the volume when pressed.
4 Pov	ver button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6 Aug	dio-in jack	Connects the speaker to a device.
6 Mic	ro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
7 Pov	ver light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is low. Solid amber: The speaker is charging.
		d IP-64, which means that it is ust and splashing water. To maintain

the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product.

*Cable not included.

EL Component	Description
1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2 Volume up button	Increases the volume when pressed.

3 Volume down Decreases the volume when button pressed. 4 Power button Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.

6 Audio-in jack Connects the speaker to a device. **6** Micro USB port Connects the speaker to power. Be

sure to charge the speaker before Power light Solid white: The speaker is paired or connected directly to an audio device. Blinking white and amber: The speaker is pairing. Blinking amber: The battery is low.

charging.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

Solid amber: The speaker is

Answers or ends a call when

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

FR Component Description

Call button

		pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2	Volume up button	Increases the volume when pressed.
3	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6	Audio-in jack	Connects the speaker to a device.
6	Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
0	Power light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is low.
		Solid amber: The speaker is charging.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the $\ensuremath{\textit{Product}}$ Notices included with your product. *Cable not included.

pressed. If connected to a device

Component Description Answers or ends a call when

		through Bluetooth®, plays or pauses music when pressed.
2	Volume up button	Increases the volume when pressed.
8	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6	Audio-in jack	Connects the speaker to a device.
6	Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
7	Power light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is low.
		Solid amber: The speaker is charging.
TL		LID CA IIII III III

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

Component Description Call button Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed. 2 Volume up Increases the volume when button pressed.

Volume down Decreases the volume when button pressed. Power button Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect

to a device through Bluetooth, see

device documentation. Audio-in jack Connects the speaker to a device.

6 Micro USB port Connects the speaker to power. Be sure to charge the speaker before

Power light Solid white: The speaker is paired or connected directly to an audio Blinking white and amber: The speaker is pairing. Blinking amber: The battery is low.

charging. This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental

Solid amber: The speaker is

Answers or ends a call when

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

KK Component Description

1 Call button

Damage Protection Care Pack.

_	Call Button	pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2	Volume up button	Increases the volume when pressed.
8	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6	Audio-in jack	Connects the speaker to a device.
6	Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
0	Power light	Solid white: The speaker is paired or connected directly to an audio device. Blinking white and amber: The speaker is pairing.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

Blinking amber: The battery is low.

pressed. If connected to a device

through Bluetooth®, plays or pauses

Solid amber: The speaker is

For regulatory and safety notices, refer to the ${\it Product}$ Notices included with your product. *Cable not included.

Component Description Answers or ends a call when Call buttor

		music when pressed.
2	Volume up button	Increases the volume when pressed.
₿	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6	Audio-in jack	Connects the speaker to a device.
_	Missa LICD park	Connects the speaker to power De

6 Micro USB port Connects the speaker to power. Be sure to charge the speaker before first use.

Power light Solid white: The speaker is paired or connected directly to an audio Blinking white and amber: The speaker is pairing. Blinking amber: The battery is low.

charging. This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage

Solid amber: The speaker is

under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack. For regulatory and safety notices, refer to the *Product*

Notices included with your product. *Cable not included.

LT Component	Description
1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pause music when pressed.
2 Volume up button	Increases the volume when pressed.
3 Volume dow button	n Decreases the volume when pressed.
4 Power butto	on Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect

device documentation. Audio-in jack Connects the speaker to a device.

to a device through Bluetooth, see

6 Micro USB port Connects the speaker to power. Be sure to charge the speaker before first use. Power light Solid white: The speaker is paired

or connected directly to an audio device. Blinking white and amber: The speaker is pairing. Blinking amber: The battery is low.

Solid amber: The speaker is charging. This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage

Damage Protection Care Pack. For regulatory and safety notices, refer to the *Product* Notices included with your product.

requires the purchase of an optional HP Accidental

*Cable not included.

HU Component Description

Call button

		pressed. If connected to a device through Bluetooth®, plays or pau music when pressed.
2	Volume up button	Increases the volume when pressed.
€	Volume down button	Decreases the volume when pressed.

4 Power button Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect device documentation.

Answers or ends a call when

6 Audio-in jack Connects the speaker to a device. 6 Micro USB port Connects the speaker to power. Be sure to charge the speaker before

first use. **7** Power light Solid white: The speaker is paired or connected directly to an audio device.

speaker is pairing.

Blinking amber: The battery is low. Solid amber: The speaker is charging. This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain

Blinking white and amber: The

the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack. For regulatory and safety notices, refer to the *Product*

Notices included with your product. *Cable not included.

NL Component Description Answers or ends a call when pressed. If connected to a device

		through Bluetooth®, plays or paus music when pressed.
2	Volume up button	Increases the volume when pressed.
3	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatical connects to the last device paired through Bluetooth. If it cannot find that device, it automatically

enters pairing mode. To connect to a device through Bluetooth, see device documentation. 6 Audio-in jack Connects the speaker to a device.

6 Micro USB port Connects the speaker to power. Be sure to charge the speaker before first use. Power light Solid white: The speaker is paired

or connected directly to an audio Blinking white and amber: The speaker is pairing.

Blinking amber: The battery is low. Solid amber: The speaker is charging. This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage

requires the purchase of an optional HP Accidental Damage Protection Care Pack. For regulatory and safety notices, refer to the *Product*

under IP-64 test conditions or any accidental damage

Notices included with your product.

*Cable not included.



10	Component	Description		
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.		
	2 Volume up button	Increases the volume when pressed.		
	3 Volume down button	Decreases the volume when pressed.		
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.		
	6 Audio-in jack	Connects the speaker to a device.		
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.		
	7 Power light	Solid white: The speaker is paired or connected directly to an audio		

charging. This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack

Blinking white and amber: The speaker is pairing.

Solid amber: The speaker is

Blinking amber: The battery is low.

For regulatory and safety notices, refer to the *Product* Notices included with your product.

*Cable not included.

Component Description 1 Call button Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed. 2 Volume up Increases the volume when button pressed. S Volume down Decreases the volume when button pressed. Turns the speaker on or off when Power button pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation. Audio-in iack Connects the speaker to a device. 6 Micro USB port Connects the speaker to power. Be sure to charge the speaker before Power light Solid white: The speaker is paired or connected directly to an audio

device. Blinking white and amber: The speaker is pairing. Blinking amber: The battery is low. Solid amber: The speaker is charging. This product is rated IP-64, which means that it is

protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

Answers or ends a call when

PT Component Description

1 Call button

	pressed. If connected to a device through Bluetooth®, plays or paus music when pressed.
2 Volume up button	Increases the volume when pressed.
3 Volume down button	Decreases the volume when pressed.
4 Power button	Turns the speaker on or off when pressed. The speaker automaticall connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6 Audio-in jack	Connects the speaker to a device.
Micro LICD port	Connects the speaker to power Bo

6 Micro USB port Connects the speaker to power. Be sure to charge the speaker before first use.

Power light Solid white: The speaker is paired or connected directly to an audio device.

Blinking white and amber: The speaker is pairing Blinking amber: The battery is low.

Solid amber: The speaker is charging.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door, IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product.

*Cable not included.

Component	Description
1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2 Volume up button	Increases the volume when pressed.
3 Volume down button	Decreases the volume when pressed.
4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6 Audio-in jack	Connects the speaker to a device.
6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
	Blinking white and amber: The speaker is pairing.
	Blinking amber: The battery is low.
	Solid amber: The speaker is charging.

guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the ${\it Product}$ Notices included with your product.

*Cable not included

	Cable not included.			
RO	Component	Description		
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.		
	2 Volume up button	Increases the volume when pressed.		
	3 Volume down button	Decreases the volume when pressed.		
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.		
	6 Audio-in jack	Connects the speaker to a device.		
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.		
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device.		
		Blinking white and amber: The speaker is pairing.		
		Blinking amber: The battery is low. Solid amber: The speaker is charging.		

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

Component Description

Call button

	can batton	pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2	Volume up button	Increases the volume when pressed.
8	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6	Audio-in jack	Connects the speaker to a device.
6	Micro USB port	Connects the speaker to power. Be sure to charge the speaker before

Answers or ends a call when

Solid white: The speaker is paired or connected directly to an audio device. Blinking white and amber: The speaker is pairing. Blinking amber: The battery is low.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

Solid amber: The speaker is

For regulatory and safety notices, refer to the ${\it Product}$ ${\it Notices} \ {\it included} \ with \ your \ product.$

*Cable not included.

SK	Component	Description		
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pause music when pressed.		
	2 Volume up button	Increases the volume when pressed.		
	3 Volume down button	Decreases the volume when pressed.		
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.		
	6 Audio-in jack	Connects the speaker to a device.		
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.		
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device.		
		Blinking white and amber: The speaker is pairing.		
		Blinking amber: The battery is low.		
		Solid amber: The speaker is charging.		

Solid amber: The speaker is charging.
This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.
For regulatory and safety notices, refer to the <i>Product Notices</i> included with your product.

*Cable not included.

Component	Description	SV	Component	Description
1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.		1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2 Volume up button	Increases the volume when pressed.		2 Volume up button	Increases the volume when pressed.
3 Volume down button	Decreases the volume when pressed.		3 Volume dov	n Decreases the volume when pressed.
4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.		4 Power butto	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6 Audio-in jack	Connects the speaker to a device.		6 Audio-in jac	k Connects the speaker to a device.
6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.		6 Micro USB p	ort Connects the speaker to power. Be sure to charge the speaker before first use.
7 Power light	Solid white: The speaker is paired or connected directly to an audio device.		7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
	Blinking white and amber: The speaker is pairing.			Blinking white and amber: The speaker is pairing.
	Blinking amber: The battery is low.			Blinking amber: The battery is low.
	Solid amber: The speaker is charging.			Solid amber: The speaker is charging.
This product is rate	ed IP-64, which means that it is		This product is	rated IP-64, which means that it is

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door, IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product.

*Cable not included.

SL Component

Component	Description
1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pause music when pressed.
2 Volume up button	Increases the volume when pressed.
3 Volume down button	Decreases the volume when pressed.
Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
5 Audio-in jack	Connects the speaker to a device.
6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
	Blinking white and amber: The speaker is pairing.
	Blinking amber: The battery is low. $ \\$
	Solid amber: The speaker is charging.

protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

SR	Component	Description
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
	2 Volume up button	Increases the volume when pressed.
	3 Volume down button	Decreases the volume when pressed.
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
	6 Audio-in jack	Connects the speaker to a device.
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is low.
		Solid amber: The speaker is charging.
	This product is rate	d IP-64, which means that it is

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the $\ensuremath{\textit{Product}}$ Notices included with your product. *Cable not included.

Component	Description
1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2 Volume up button	Increases the volume when pressed.
3 Volume down button	Decreases the volume when pressed.
4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6 Audio-in jack	Connects the speaker to a device.
6 Micro USB por	t Connects the speaker to power. Be sure to charge the speaker before first use.
7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
	Blinking white and amber: The speaker is pairing.
	Blinking amber: The battery is low.
	Solid amber: The speaker is charging.
protected agains the IP-64 rating,	ted IP-64, which means that it is t dust and splashing water. To maintair close the I/O door. IP ratings are not a ure performance. Coverage for damage

under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the $\ensuremath{\textit{Product}}$ Notices included with your product.

*Cable not included.

TH	Component	Description	
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.	
	2 Volume up button	Increases the volume when pressed.	
	3 Volume down button	Decreases the volume when pressed.	
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.	
	6 Audio-in jack	Connects the speaker to a device.	
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.	
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device.	

charging. This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

speaker is pairing.

Blinking white and amber: The

Solid amber: The speaker is

Answers or ends a call when

Blinking amber: The battery is low.

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

Component Description

Call button

		pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2	Volume up button	Increases the volume when pressed.
€	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6	Audio-in jack	Connects the speaker to a device.
6	Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
0	Power light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is low.
		Solid amber: The speaker is

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage $\,$ under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the $\ensuremath{\textit{Product}}$ Notices included with your product.

*Cable not included.

UK	Component	Description
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pau music when pressed.
	2 Volume up button	Increases the volume when pressed.
	3 Volume down button	Decreases the volume when pressed.
	4 Power button	Turns the speaker on or off when pressed. The speaker automatica connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, se device documentation.
	6 Audio-in jack	Connects the speaker to a device.
	6 Micro USB port	Connects the speaker to power. E sure to charge the speaker before first use.
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.
		Blinking amber: The battery is lov Solid amber: The speaker is charging.
		d IP-64, which means that it is Just and splashing water. To main

the IP-64 rating, close the I/O door, IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product.

*Cable not included.

JA Co	omponent	Description	
0	Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pause music when pressed.	
2	Volume up button	Increases the volume when pressed.	
€	Volume down button	Decreases the volume when pressed.	
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.	
6	Audio-in jack	Connects the speaker to a device.	

6 Micro USB port Connects the speaker to power. Be sure to charge the speaker before first use. Solid white: The speaker is paired Power light

or connected directly to an audio Blinking white and amber: The speaker is pairing Blinking amber: The battery is low. Solid amber: The speaker is

charging.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

Component Description

0	Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
2	Volume up button	Increases the volume when pressed.
3	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6	Audio-in jack	Connects the speaker to a device.
6	Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
0	Power light	Solid white: The speaker is paired or connected directly to an audio device.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

Blinking white and amber: The

Solid amber: The speaker is

Blinking amber: The battery is low.

speaker is pairing.

For regulatory and safety notices, refer to the *Product* Notices included with your product.

*Cable not included.

CN	Component	Description
	1 Call button	Answers or ends a call when pressed. If connected to a device through Bluetooth®, plays or pauses music when pressed.
	2 Volume up button	Increases the volume when pressed.
	3 Volume down button	Decreases the volume when pressed.
	4 Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
	6 Audio-in jack	Connects the speaker to a device.
	6 Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
	7 Power light	Solid white: The speaker is paired or connected directly to an audio device.
		Blinking white and amber: The speaker is pairing.

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door, IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

charging.

Blinking amber: The battery is low.

Solid amber: The speaker is

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

Description

Answers or ends a call when pressed. If connected to a device

TW Component

		through Bluetooth®, plays or pause music when pressed.
2	Volume up button	Increases the volume when pressed.
3	Volume down button	Decreases the volume when pressed.
4	Power button	Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.
6	Audio-in jack	Connects the speaker to a device.
6	Micro USB port	Connects the speaker to power. Be sure to charge the speaker before first use.
7	Power light	Solid white: The speaker is paired

Blinking amber: The battery is low. Solid amber: The speaker is charging. This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a guarantee of future performance. Coverage for damage under IP-64 test conditions or any accidental damage

speaker is pairing.

or connected directly to an audio

Blinking white and amber: The

Damage Protection Care Pack. For regulatory and safety notices, refer to the *Product* Notices included with your product.

requires the purchase of an optional HP Accidental

Component

*Cable not included.

Description ♠ Call button Answers or ends a call when

	Call Button	pressed. If connected to a device through Bluetooth®, plays or pause music when pressed.
2	Volume up button	Increases the volume when pressed.
8	Volume down button	Decreases the volume when pressed.
	Power hutton	Turns the speaker on or off when

Turns the speaker on or off when pressed. The speaker automatically connects to the last device paired through Bluetooth. If it cannot find that device, it automatically enters pairing mode. To connect to a device through Bluetooth, see device documentation.

6 Audio-in jack Connects the speaker to a device. **6** Micro USB port Connects the speaker to power. Be

sure to charge the speaker before first use. **7** Power light Solid white: The speaker is paired or connected directly to an audio

device.

Blinking white and amber: The speaker is pairing. Blinking amber: The battery is low. Solid amber: The speaker is

This product is rated IP-64, which means that it is protected against dust and splashing water. To maintain the IP-64 rating, close the I/O door. IP ratings are not a $guarantee\ of\ future\ performance.\ Coverage\ for\ damage$ under IP-64 test conditions or any accidental damage requires the purchase of an optional HP Accidental Damage Protection Care Pack.

For regulatory and safety notices, refer to the *Product* Notices included with your product. *Cable not included.

Complies with IDA Standards DB106008

RMN/型號/型号: BM1138

© Copyright 2016 HP Development Company, L.P. Bluetooth is a trademark owned by its proprietor and used by $\ensuremath{\mathsf{HP}}$

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein. First Edition: June 2016