

3-3. Using the Display Audio system

■ About the phonebook in this system

The following data is stored for every registered phone. When another phone is connecting, you cannot read the registered data.

- Phonebook data
- All of call history
- Speed dial

When you delete the phone, the above-mentioned data is also deleted.

■ When you release your car

Be sure to initialize your data. (→P. 311)

■ About Bluetooth®



Bluetooth is a registered trademark of Bluetooth SIG, Inc.

The Bluetooth wordmark and logo are owned by Bluetooth SIG, and permission has been granted to use the trademark of the licensee FUJITSU TEN LIMITED. Other trademarks and trade names are owned by various different owners.

■ Compatible models

This system supports the following service.

- Bluetooth® Specification:
Ver. 1.1 or higher (Recommended: Ver. 2.1 + EDR or higher)
- Profiles:
 - HFP (Hands Free Profile) Ver. 1.0 or higher (Recommended: Ver. 1.5 or higher)
This is a profile to allow hands-free phone calls using the cellular phone or head sets. It has an outgoing and incoming call function.
 - OPP (Object Push Profile) Ver. 1.1 or higher
This is a profile to exchange phonebook data. When the Bluetooth® phone has PBAP and OPP, OPP cannot be used.
 - PBAP (Phone Book Access Profile) Ver. 1.0 or higher
This is a profile to transfer phonebook data.

If your cellular phone does not support HFP, you cannot enter the Bluetooth® phone. You need to take OPP or PBAP service individually.

■ **Certification**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTION:

Radio Frequency Radiation Exposure

This equipment complies with FCC radiation exposure limits set forth for uncontrolled equipment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated with at least 20 cm and more between the radiator and person's body (excluding extremities: hands, wrists, feet and ankles).

Co-location:

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

3-3. Using the Display Audio system

CAUTION

■ **While driving**


Do not use the cellular phone or connect the Bluetooth[®] system.

NOTICE

■ **When leaving the vehicle**

Do not leave your cellular phone in the vehicle. The inside of the vehicle may become hot, causing damage to the phone.



3-3. Using the Display Audio system Using the Bluetooth® phone



1 Device name

2 Bluetooth® connection status

3 Make a call

To display the screen shown above, press  on the steering wheel or .

STNDA00041E

3


Interior features

3-3. Using the Display Audio system

Registering a Bluetooth® phone

To use the hands-free system, you must register a Bluetooth® phone in the system. You can register up to 5 phones in the system.

STEP 1 Display the “Telephone” screen. (→P. 381)



Touch “Yes”.



Input the passcode displayed on the screen into your phone.

For the operation of the phone, see the manual that comes with your cellular phone.

Passcodes are not required for SSP (Secure Simple Pairing) compatible Bluetooth® devices. Depending on the phone, you may need to select “Yes” to register, or “No” to cancel on your cellular phone.

If you want to cancel it, select “Cancel”.

If a completion message is displayed, registration is complete.

If an error message is displayed, follow the guidance on the screen to try again.


Selecting the Bluetooth® phone

If multiple Bluetooth® devices are registered, follow the procedure below to select the Bluetooth® device to be used. You may only use one device at a time.

STEP 1 Display the “Telephone” screen. (→P. 381)



Touch “Connect telephone”.



Touch the device to connect.

“Add new”: Registering a Bluetooth® device. (→P. 409)

The selection indicator is displayed on left side of the selected device name.

The Bluetooth® mark is displayed when you connected the device.

3

Interior features

Connecting a Bluetooth® phone

There are two connecting methods available-automatic and manual.

Automatic

When you register your phone, auto connection will be activated. Always set it to this mode and leave the Bluetooth® phone in a place where connection can be established.

Vehicles without a smart entry & start system:

When the engine switch is turned to the “ACC” or “ON” position, the system will search for a nearby cellular phone you have registered.

Vehicles with a smart entry & start system:

When the “ENGINE START STOP” switch is turned to ACCESSORY or IGNITION ON mode, the system will search for a nearby cellular phone you have registered.

Next, the system automatically connects with the most recent of the phones connected to in the past. Then, the connection result is displayed.

Manual


When the auto connection has failed or “Bluetooth* power” is turned off, you must connect Bluetooth® manually.

*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

STEP 1 Display the “Telephone” screen. (→P. 381)



Touch “Connect telephone”.



Touch the device to connect.

A message is shown if connection has been successful.

If connection fails, a message will be displayed and connection will be re-attempted.

3

Interior features

3-3. Using the Display Audio system

■ Reconnecting to the Bluetooth® phone

Vehicles without a smart entry & start system:

If the system cannot connect due to poor signal strength with the engine switch in the “ACC” or “ON” position, the system will automatically attempt to reconnect.

Vehicles with a smart entry & start system:

If the system cannot connect due to poor signal strength with the “ENGINE START STOP” switch in ACCESSORY or IGNITION ON mode, the system will automatically attempt to reconnect.

If the phone is turned off, the system will not attempt to reconnect. In this case, connection must be made manually, or the phone must be re-selected.

■ Connecting the phone while Bluetooth® audio is playing

- Bluetooth® audio will stop temporarily.
- It may take time to connect.

Making a call


Once the Bluetooth® phone is registered, you can make a call using the following procedure:

■ Dialing

STEP 1 Display the “Telephone” screen. (→P. 381)



Input the phone number.

To delete the inputted phone number, touch .

For the first digit, you can enter “+” by touching “*” for a while.


STEP 3 Press  on the steering wheel or touch .

■ **Dialing from the phonebook**

You can dial a number from the phonebook data imported from your cellular phone. The system has one phonebook for each telephone. Up to 1000 entries may be stored in each phonebook. (→P. 398)


STEP 1 Display the “Telephone” screen. (→P. 381)

STEP 2 Touch “Contacts” on the “Telephone” screen.



Choose the desired data to call from the list.

If the phonebook is empty, a message will be displayed. (→P. 388)



Choose the number and then press on the steering wheel or touch .

3

Interior features

3-3. Using the Display Audio system

- When the phonebook is empty

You can transfer the phone numbers in your Bluetooth® phone to the system.

Operation methods differ between PBAP compatible and PBAP incompatible Bluetooth® phones. If your cellular phone does not support either PBAP or OPP service, you cannot transfer contacts.

STEP 1 Touch “Contacts” on the “Telephone” screen.



If the phonebook is empty, a message will be displayed.

For PBAP compatible Bluetooth® phone

STEP 3 Touch “Yes” if you want to transfer new contacts from a cellular phone.

Touch “No” if you want to cancel transferring the contacts.

For PBAP incompatible and OPP compatible Bluetooth® phone

STEP 3 Touch “Transfer” if you want to transfer new contacts from a cellular phone.

Touch “Cancel” if you want to cancel transferring the contacts.


You need to operate your phone to transfer new contacts.

■ **Calling using speed dial**

You can make a call using numbers registered from the phone-book.

STEP 1 Display the “Telephone” screen. (→P. 381)

STEP 2 Touch “Speed dials” on the “Telephone” screen.



Select the desired tab and choose the desired number to make a call.

■ **Dialing from history**

You can call using the call history which has the 4 functions below.

“All”: all the calls below which were memorized


“Missed”: calls which you missed

“Incoming”: calls which you received

“Outgoing”: calls which you called


STEP 1 Display the “Telephone” screen. (→P. 381)



STEP 2 Touch “Call history” on the “Telephone” screen.



Select the desired tab and choose the desired data from the list.

3-3. Using the Display Audio system



Press  on the steering wheel or touch .

■ Call history list

- If you make a call to or receive a call from a number registered in the phonebook, the name is displayed in the call history.
- If you make multiple calls to the same number, only the last call made is displayed in the call history.


■ When driving


The functions “Dialing”, “Dialing from the phonebook”, and “Dialing from history” (only the 6th page of “All” tab) are unavailable.


■ International calls



You may not be able to make international calls, depending on the mobile phone in use.

■ Calling by using the latest call history item

STEP 1 Press  on the steering wheel to display the “Telephone” screen.


STEP 2 Press  on the steering wheel to display the “Call history” screen.

STEP 3 Press  on the steering wheel to select the latest history item.



STEP 4 Press  on the steering wheel or touch  to call the latest history item.

Receiving a call



When a call is received, the following screen is displayed together with a sound.



To answer the phone:

- Press  on the steering wheel.
- Touch .

■ To refuse a call

Press  on the steering wheel or touch .

■ To adjust the incoming call volume

Touch “-” or “+”. You can also adjust the volume using the steering switches or volume knob.


■ International calls

Received international calls may not be displayed correctly depending on the cellular phone in use.

3-3. Using the Display Audio system

Speaking on the phone

The following screen is displayed when speaking on the phone.



■ To adjust the incoming call volume

Touch “-” or “+”. You can also adjust the volume using the steering switches or the volume knob.


■ To prevent the other party from hearing your voice

Touch “Mute”.

■ Inputting tones

When using phone services such as an answering service or a bank, you can store phone numbers and code numbers in the phonebook.

STEP 1 Touch “0-9”.



Input the number.

3-3. Using the Display Audio system



If repeated tone symbols* are stored in the phone book, “Send” and “Exit” are displayed on the right side of the screen.

: Repeated tone symbols are symbols or numbers displayed as p or w, that come after the phone number. (e.g. 056133w0123p#1)

STEP 4 Confirm the number displayed on the screen, and touch “Send”.



If you touch “Exit”, this function will end.

■ To transfer a call

Touch “Handset Mode” to change from Hands-free call to cellular phone call.

Touch “Handsfree Mode” to change from cellular phone call to Hands-free call.

■ To hang up

Press  on the steering wheel or touch .


3

Interior features



3-3. Using the Display Audio system

■ Call waiting



When a call is interrupted by a third party while talking, the incoming call message will be displayed.





To talk with the other party:

- Press  on the steering wheel.
- Touch .

To refuse the call:

- Press  on the steering wheel.
- Touch .

Every time you press  on the steering wheel or touch  during call waiting, you will be switched to the other party.

■ Transferring calls


- It is not possible to transfer from hands-free to the cellular phone while driving.
- If you transfer from the cellular phone to hands-free, the hands-free screen will be displayed, and you can operate the system using the screen.
- Transfer method and operate may vary according to the cellular phone used.
- For operation of the cellular phone in use, see the phone's manual.

■ Call waiting operation

Call waiting operation may differ depending on your phone company and cellular phone.

3-3. Using the Display Audio system Setting the hands-free system

You can set the hands-free system to your desired settings.



- 1** Setting the sound
- 2** Phonebook settings

To display the screen shown above, press "SETUP", and touch "Telephone" on the "Setup" screen.

3


Interior features

3-3. Using the Display Audio system

Setting the sound

STEP 1 Display the “Telephone settings” screen. (→P. 395)

STEP 2 Touch “Sound settings” on the “Telephone settings” screen.



1 Changes the speaker volume (→P. 396)


2 Changes the ring tone volume (→P. 396)

3 Changes the ring tone (→P. 397)

4 Restore default settings

Setting the volume

STEP 1 Touch “Call volume” or “Ring tone volume” on the “Sound settings” screen.




Touch “-” or “+” to lower or raise the volume, and then “OK”.

STEP 3 When you complete all settings, touch “OK”.

■ **Setting the ring tone**

STEP 1 Touch “Ring tone” on the “Sound settings” screen.



Touch “Tone 1”, “Tone 2” or “Tone 3” to change the ring tone, and then “OK”.

STEP 3 When you complete all settings, touch “OK”.


■ **To return to the default volume settings**

Touch “Default”, and then “Yes”.

3-3. Using the Display Audio system

Phonebook settings

The phonebook manages a maximum of 5 phones in total. The data for 1000 contacts (up to 3 numbers per contact) can be registered in each phonebook.



- 1** Managing the contacts
- 2** Managing the speed dials
- 3** Deleting the call history

To display the screen above, follow the steps below.

STEP 1 Display the “Telephone settings” screen. (→P. 395)

STEP 2 Touch “Phonebook” on the “Telephone settings” screen.


■ **Managing the contacts**

● **Transferring a phone number**

You can transfer the phone numbers in your Bluetooth® phone to the system. Operation methods differ between PBAP compatible and PBAP incompatible Bluetooth® phones. If your cellular phone does not support either PBAP or OPP services, you cannot transfer contacts.

STEP 1 Display the “Phonebook settings” screen. (→P. 398)


STEP 2 Touch “Manage contacts” on the “Phonebook settings” screen.



Touch “Transfer contacts”.

3
Interior features

For PBAP compatible Bluetooth® phones



1 Automatic phonebook download on/off

The phonebook data can be automatically transferred.

Depending on the cellular phone, call history will be also transferred.


2 Update phonebook

The phonebook data can be updated.

3 Restore default settings

3-3. Using the Display Audio system

For PBAP incompatible Bluetooth® phones



1 Replace contacts

The phonebook data can be replaced.


2 Add contacts

The phonebook can be added.

● Deleting the phonebook data


STEP 1 Display the “Phonebook settings” screen. (→P. 398)

STEP 2 Touch “Manage contacts” on the “Phonebook settings” screen.



Touch “Delete contacts”.

If your phone supports PBAP service, “Automatic phonebook download” setting needs to be set to “Off”. (→P. 399)



Choose the data to delete.

To delete all data, touch “All delete”.

STEP 5 A confirmation message will be displayed. If everything is correct, touch “Yes”.

■ Phonebook data

Phonebook data is managed for every registered phone. When another phone is connecting, you cannot read the registered data.

■ Setting the phonebook in a different way (To display the “Contacts” screen)

STEP 1 Display the “Telephone” screen. (→P. 381)

STEP 2 Touch “Contacts” on the “Telephone” screen.

STEP 3 Touch “Options” on the “Contacts” screen.

STEP 4 Touch “Manage contacts” on the “Phonebook settings” screen.

■ When transferring a phone number

Transfer the phone number while engine is running.

If your cellular phone is OPP or PBAP compatible, you may need to input “1234” by your cellular phone for OBEX certification.

■ When you have selected “Update phonebook” to transfer the phone number

- If your cellular phone does not support PBAP service, you cannot use this function.

- If your phone supports PBAP service, you can transfer the phonebook data without operating your phone.

■ When you have selected “Replace contacts” or “Add contacts” to transfer the phone number

If your cellular phone does not support OPP service, you cannot use these functions. You can transfer the phonebook data only by operating your phone.

■ Transferring the phone number in a different way (To display the “Contact transfer method” screen)

STEP 1 Display the “Telephone” screen. (→P. 381)

STEP 2 Touch “Contacts” on the “Telephone” screen.

STEP 3 Touch “Transfer” on the “Contacts” screen.

■ Transferring the phone number while Bluetooth® audio is playing

Bluetooth® audio will disconnect. It will reconnect automatically when data transfer finishes. It will not be reconnected depending on the phone you are using.

3-3. Using the Display Audio system

■ Deleting the phonebook data in a different way

- STEP 1** Display the “Telephone” screen. (→P. 381)
- STEP 2** Touch “Contacts” on the “Telephone” screen.
- STEP 3** Choose the desired data from the list.
- STEP 4** Touch “Options” on the “Contact” screen.
- STEP 5** Touch “Delete” on the “Contact data” screen.
- STEP 6** A confirmation message will be displayed. If everything is correct, touch “Yes”.

If your phone supports PBAP service, “Automatic phonebook download” setting needs to be set to “Off”. (→P. 399)


When you delete a Bluetooth® phone, the phonebook data will be deleted at the same time.

■ Managing the speed dials

● Registering the speed dial from contacts


You can register the desired phone number from phonebook. Up to 18 numbers per phone can be registered.

- STEP 1** Display the “Phonebook settings” screen. (→P. 398)
- STEP 2** Touch “Manage speed dials” on the “Phonebook settings” screen.




Touch “New speed dial from contacts”.


3-3. Using the Display Audio system



Choose the data to register.



Touch the desired phone number.



Touch the switch you want to register the number in.

STEP 7 If you select a switch you registered before, a confirmation message will be displayed. If you want to replace it, touch "Yes".

3


Interior features

3-3. Using the Display Audio system


● Registering the speed dial from call history

STEP 1 Display the “Phonebook settings” screen. (→P. 398)


STEP 2 Touch “Manage speed dials” on the “Phonebook settings” screen.



Touch “New speed dial from call History”.



Choose the data to register.



Touch the switch you want to register the number in.


STEP 6 If you select a switch you registered before, a confirmation message will be displayed. If you want to replace it, touch “Yes”.

● Deleting the speed dial

STEP 1 Display the “Phonebook settings” screen. (→P. 398)

STEP 2 Touch “Manage speed dials” on the “Phonebook settings” screen.

STEP 3 Touch “Delete speed dials” on the “Speed dials” screen.



Choose the data to delete.

To delete all data, touch “All delete”.

STEP 5 A confirmation message will be displayed. If everything is correct, touch “Yes”.

■ Setting the speed dials in a different way (From “Speed dial” screen)

STEP 1 Display the “Telephone” screen. (→P. 381)

STEP 2 Touch “Speed dials” on the “Telephone” screen.

STEP 3 Touch “Options” on the “Speed dial” screen.

■ Setting the speed dials in a different way (From “Contacts” screen)

STEP 1 Display the “Telephone” screen. (→P. 381)

STEP 2 Touch “Contacts” on the “Telephone” screen.

STEP 3 Touch “Options” on the “Contacts” screen.

STEP 4 Touch “Manage speed dials” on the “Phonebook settings” screen.

3-3. Using the Display Audio system

■ Registering the speed dial in a different way (From “Speed dial” screen)

- STEP 1** Display the “Telephone” screen. (→P. 381)
- STEP 2** Touch “Speed dials” on the “Telephone” screen.
- STEP 3** Touch “(add new)” on the “Speed dial” screen.
- STEP 4** Touch “Contacts” or “History” to set new speed dial.
Touch “Cancel” to cancel it.
- STEP 5** Choose the desired data from the list.
- STEP 6** Touch the desired phone number.
- STEP 7** Follow the steps “Registering the speed dial from contacts” from “STEP6” (→P. 402) or “Registering the speed dial from call history” from “STEP5”. (→P. 404)

■ Registering the speed dial in a different way (From “Contact” screen)

- STEP 1** Display the “Telephone” screen. (→P. 381)
- STEP 2** Touch “Contacts” on the “Telephone” screen.
- STEP 3** Choose the desired data from the list.
- STEP 4** Touch “Options” on the “Contact” screen.
- STEP 5** Touch “Set speed dial” on the “Contact data” screen.
- STEP 6** Touch the desired telephone number.
- STEP 7** Follow the steps “Registering the speed dial from contacts” from “STEP6” (→P. 402) or “Registering the speed dial from call history” from “STEP5”. (→P. 404)

■ Registering the speed dial in a different way (From “Call history” screen)


- STEP 1** Display the “Telephone” screen. (→P. 381)
- STEP 2** Touch “Call history” on the “Telephone” screen.
- STEP 3** Choose the desired data from the list.
- STEP 4** Touch “Add speed dial” on the “Call history” screen.
- STEP 5** Follow the steps “Registering the speed dial from contacts” from “STEP6” (→P. 402) or “Registering the speed dial from call history” from “STEP5”. (→P. 404)

■ **Deleting the call history**


STEP 1 Display the “Phonebook settings” screen. (→P. 398)

STEP 2 Touch “Delete call history” on the “Phonebook settings” screen.

If your phone supports PBAP service, the “Automatic phonebook download” setting needs to be set to “Off”. (→P. 399)



Choose the desired history to delete.



Choose the data to delete. To delete all data, touch “All delete”.

STEP 5 A confirmation message will be displayed. If everything is correct, touch “Yes”.

■ **Deleting call history in a different way**

STEP 1 Display the “Telephone” screen. (→P. 381)

STEP 2 Touch “Call history” on the “Telephone” screen.

STEP 3 Touch “Delete” on the “Call history” screen.


STEP 4 Follow the steps “Deleting the call history” from “STEP4”. (→P. 407)

3

Interior features

3-3. Using the Display Audio system Bluetooth® settings

You can set the Bluetooth® system to your desired settings.



- 1** Registered devices settings
- 2** Connecting telephone
- 3** Connecting audio player
- 4** Detailed Bluetooth® settings

To display the screen shown above, press “SETUP”, and touch “Bluetooth*” on the “Setup” screen.

*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.


Registered devices settings

■ Registering a Bluetooth® device

Bluetooth® devices compatible with phones (HFP) and portable audio players (AVP) can be registered simultaneously. You can register up to 5 Bluetooth® devices.

STEP 1 Display the “Bluetooth* Settings” screen. (→P. 408)

STEP 2 Touch “Registered devices” on the “Bluetooth* Settings” screen.




Touch “Add new”.

3

Interior features

*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

3-3. Using the Display Audio system



When this screen is displayed, input the passcode displayed on the screen into your Bluetooth® device.

For the operation of the Bluetooth® device, see the manual that comes with your Bluetooth® device.

Passcodes are not required for SSP (Secure Simple Pairing) compatible Bluetooth® devices. Depending on the phone, you may need to select “Yes” to register, or “No” to cancel on your cellular phone.

If you want to cancel it, touch “Cancel”.

If a completion message is displayed, registration is complete.


If an error message is displayed, follow the guidance on the screen to try again.

■ Removing a Bluetooth® device


STEP 1 Display the “Bluetooth* Settings” screen. (→P. 408)

STEP 2 Touch “Registered devices” on the “Bluetooth* Settings” screen.

*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.



Touch "Remove".



Touch the device to remove.


STEP 5 A confirmation message will be displayed, touch "Yes" to remove the device.

■ **Displaying a Bluetooth® device details**

You can confirm and change the device details.

STEP 1 Display the "Bluetooth* Settings" screen. (→P. 408)


STEP 2 Touch "Registered devices" on the "Bluetooth* Settings" screen.



Touch "Details".


*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

3-3. Using the Display Audio system



Touch the device.


STEP 5 Following screen is displayed:



- 1 Display device name
- 2 Display device address
- 3 Display your telephone number

The number may not be displayed depending on the phones.


- 4 Display compatibility profile of the device
- 5 Change connection method (→P. 413)
- 6 Restore default settings



STEP 6 When you complete settings, touch "OK".

● Changing connection method

STEP 1 Touch “Connection method” on the “Device details” screen.



Touch “From vehicle” or “From audio player”.

“From vehicle”: Connect the audio system to the portable audio player.


“From audio player”: Connect the portable audio player to the audio system.

Selecting the Bluetooth® phone

If multiple Bluetooth® devices are registered, follow the procedure below to select the Bluetooth® device to be used. You may only use one device at a time.

STEP 1 Display the “Bluetooth* Settings” screen. (→P. 408)

STEP 2 Touch “Connect telephone” on the “Bluetooth* Settings” screen.



Touch the device to connect.

“Add new”: Registering a Bluetooth® device. (→P. 409)
The selection indicator is displayed on left side of the selected device name.

The Bluetooth® mark is displayed when you connected the device.

*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.


3-3. Using the Display Audio system

Selecting the audio player

If multiple Bluetooth® devices are registered, follow the procedure below to select the Bluetooth® device to be used. You may only use one device at a time.

STEP 1 Display the “Bluetooth* Settings” screen. (→P. 408)

STEP 2 Touch “Connect audio player” on the “Bluetooth* Settings” screen.



Touch the device to connect.

“Add new”: Registering a Bluetooth® device. (→P. 409)

The selection indicator is displayed on left side of the selected device name.

The Bluetooth® mark is displayed when you connected the device.

*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.


Detailed Bluetooth® settings

You can confirm and change the detailed Bluetooth® settings.

STEP 1 Display the “Bluetooth* Settings” screen. (→P. 408)

STEP 2 Touch “Detailed Bluetooth* settings” on the “Bluetooth* Settings” screen.

STEP 3 Following screen is displayed:



1 Change Bluetooth® power on/off

You can change Bluetooth® function to “On” or “Off”

2 Display device name

3 Change passcode (→P. 416)

4 Display device address

5 Display compatibility profile of the system

6 Change displaying telephone status on/off

You can set the system to show the status confirmation display when connecting telephone

7 Change displaying audio player status on/off

You can set the system to show the status confirmation display when connecting audio player

8 Restore default settings

STEP 4 When you complete settings, touch “OK”.


*: Bluetooth is a registered trademark of Bluetooth SIG. Inc.

3-3. Using the Display Audio system

■ Editing the passcode

You can change the passcode that you use to register your Bluetooth® device in the system.

STEP 1 Touch “Passcode” on the “Detailed Bluetooth* settings” screen.



Input a passcode, and touch “OK”.

*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.