

EXPAND YOUR SOUND.



Material: 250g - 300g Black Card Stock

Photo References



Material: 120g Glossy Coated Art Paper (120g 铜版纸过光油)



QUICK START GUIDE

FCC-ID - 2AANZAIR

Cool, you've got an Air by Quirky. Go you. Let's get you going so you can listen to all your favorite tunes like never before. This little guide has all the answers you need about your new speakers. It's super helpful, so you should keep it around.

What's Inside

- 1 AirBase Bluetooth® Speaker
4 AirConnect Speakers
USB Charging Cable
Quick Start Guide (What You're Reading Right Now)
Media Shortcut Keys
Aux Cable

Check Out These Features

- Play your music wirelessly on all 5 speakers up to 100' from the AirBase.
Speakers work together or on their own as Bluetooth® speakers.
Portable so your music goes where you do.
IPX4 water resistance (if they get splashed a little, no worries).
Works through most of the walls in your home.
Can be recharged using lithium-ion battery.

SAFETY INSTRUCTIONS

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids. Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit. Do not use the unit if it has been dropped or damaged in any way. Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk. Do not puncture or harm the exterior surface of the product in any way. Keep the unit free from dust, lint, etc. Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device. This product is not a toy. Keep out of reach of children. Do not use the speaker at excessive levels as this may damage hearing. Do not expose batteries, battery pack, or batteries to installed to excessive heat, such as direct sunlight, or open flame.

Charging Your Speakers

You're about to take your new speakers out for a spin. We get it. But before you do, charge them for four hours. As long as the speakers are connected you can plug the cable into any micro USB port.



Enjoying Your Speakers

The speakers work best if they're within 20' of your smart device. If you're out of range or your wireless connection is weak, your music may cut out briefly. Don't worry. Please make sure Bluetooth® is enabled before you start the pairing process.



But wait, there's more. You can also pair each AirConnect speaker to its own Bluetooth® source to use as a separate Bluetooth® Speaker. Whoa, sounds complex, right? It's not. Just 3 little steps.



Enjoying Your Speakers (continued)

Audio output of the Air can be used to connect to an alternate audio system, such as a home theater system, or a TV, by plugging the audio cable into the "OUT" jack on the Air to the "line in" of the audio playback device of your choice.



Connection Lost?

If pairing to the speakers does not work, turn off the speakers and repeat the steps again in "Using Speakers." Make sure your speakers are within range of your smart device. If you hear a long beep or a voice indicating low battery, you need to recharge your speakers. Connection may be lost due to low battery. When charging your speakers, only use the enclosed USB cable.

Specifications

- Bluetooth Version: V 5.0
Power: AirBase: 2x3 W, AirConnect: 1x4 W
Battery: AirBase: 2200 mAh/3.7V, AirConnect: 1400 mAh/3.7V
Frequency: AirBase: 88HZ-17KHZ, AirConnect: 100HZ-17KHZ
Separated Speakers Connectivity Range: Up to 100ft via 5.8ghz
Speaker Signal to Noise Ratio: (dB) >=60DB
Pink Noise at Max Volume (dB, distance 1M): AirBase:80DB, AirConnect:78DB
Dolby Support: No
Microphone Support: Yes
Play Time: AirBase: Up to 7.5H, AirConnect: Up to 6H

- Power Adapter: Micro USB 5V 5A
Charging Time: AirBase: Up to 2.5H, AirConnect: Up to 2.5H
Audio Input: AUX
Buttons: 5 Mechanical Buttons: Play/Pause; Vol+; Vol-; Mode/Power; Reset
Material: ABS + Rubberized Grill
Bluetooth® Names: AirBase: Air, AirConnect: Air left/Air right
Bluetooth® Range: <=32.8ft
Water Resistance Grade: IPX4
Dimensions: 11.53" x 4.02" x 3.68"
Weight: AirBase: .73lbs / .33kg, AirConnect (1 piece): .48lbs / .22kg

WARRANTY

The Air by Quirky One-Year Limited Warranty is a voluntary manufacturer's warranty. It provides rights separate to rights provided by consumer law, including but not limited to those relating to non-conforming goods. As such, the Air by Quirky One-Year Limited Warranty benefits are in addition to, and not instead of, rights provided by consumer law and it does not exclude, limit or suspend a buyer's rights arising from consumer law. Consumers have the right to choose whether to claim services under the Air by Quirky One-Year Limited Warranty or under their consumer law rights. Important! The Air by Quirky One-Year Limited Warranty terms and conditions shall not apply to consumer law claims. Please note: All claims made under the Air by Quirky will be governed by the terms set out in this warranty document.

Your Air by Quirky-branded product ("Product") is warranted against defects in materials and workmanship for a period of ONE (1) YEAR from the date of original retail purchase ("Warranty Period") when used in accordance with Air by Quirky start up guide. Under this warranty, you will be able to direct your claims to Air by Quirky even in situations where you purchased the Air by Quirky Product from a third party. If a defect arises during the Warranty Period, Air by Quirky, at its option will (i) repair the Product at no charge using new parts or parts that are equivalent to new in performance and reliability, (ii) exchange the Product with a product with equivalent functionality formed from new and/or previously used parts that are equivalent to new in performance and reliability, or with your consent, a product that is at least functionally equivalent to the product it replaces. This warranty excludes normal depletion of consumable parts such as batteries unless failure has occurred due to a defect in materials or workmanship and; damage resulting from abuse, accident, modifications, unauthorized repairs or other causes that are not defects in materials and workmanship.

Any limitations of liability in this warranty document shall not apply to (i) death or personal injury pursuant to any mandatory law on product liability; (ii) fraud or fraudulent misrepresentation; (iii) intentional misconduct or gross negligence; (iv) or a culpable breach of major contractual obligations. A damages claim based on a breach of major contractual obligations or gross negligence will be limited to foreseeable damage typical for the sale contract concerned. Proof of purchase may be required to verify eligibility.

WARNING

Keep away from water and moisture. Keep away from heat sources. Do not disassemble.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.