


Size: 215x70x5mm
Material: 250g - 300g
Black Card Stock

Photo References



Size: 210x65mm
Material: 120g Glossy, Coated Art Paper (120g 铜版 光油)
2 side printing and as a book (双面印刷, 装订成册)

Back

Cover



QUICK START GUIDE

BT-ID - D044966
Main FCC ID - 2AANZAIR
Secondary FCC ID - 2AANZAIR2

Cool, you've got an Air by Quirky. Go you.
Let's get you going so you can listen to all your favorite tunes like never before.
This little guide has all the answers you need about your new speakers. It's super helpful, so you should keep it around.

What's Inside

- 1 AirBase Bluetooth® Speaker
- 4 AirConnect Speakers
- USB Charging Cable
- Quick Start Guide (what you're reading right now)
- Aux Cable

Check Out These Features

Play your music wirelessly on all 5 speakers up to 75' from the AirBase. Speakers work together or on their own as Bluetooth® speakers. Portable so your music goes where you do. IPX4 water resistance (if they got splashed a little, no worries). Works through most of the walls in your home. Totally rechargeable. When speakers are connected they will charge from one cable.

SAFETY INSTRUCTIONS

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids. Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit. Do not use the unit if it has been dropped or damaged in any way. Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk. Do not puncture or harm the exterior surface of the product in any way. Keep the unit free from dust, lint, etc. Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device. This product is not a toy. Keep out of reach of children. Do not use the speaker at excessive levels as this may damage hearing. Do not expose batteries, battery pack, or batteries to installed to excessive heat, such as direct sunlight, or open flame.

1

Charging Your Speakers

You're anxious to take your new speakers out for a spin. We get it. But before you do, charge them for four hours. As long as the speakers are connected to each other you can plug the cable into any micro USB port.

Enjoying Your Speakers

The speakers work best if the AirBase is within 32' of your smart device. If you're out of range or your wireless connection is weak, your music may cut out briefly. Don't worry! Please make sure Bluetooth® is enabled on your device before you start the pairing process.

1. Turn on your speakers. When the speakers are connected to each other, pressing any of the power buttons will turn them all on. If separated you will need to turn on each one individually. Do you see a little green light on the back of each one? Good. That means they're all on and connected.
2. Now it's time to connect your AirBase to whatever Bluetooth® enabled device you'd like to use. You'll hear a friendly voice telling you your speakers are in "pairing mode."
3. Your smart phone or tablet will show a list of devices nearby, just choose "Air." Now you'll hear a friendly voice confirming you're paired.
4. You're all set. Now you can separate the speakers and put them wherever you want (just so long as they're within 75' of the AirBase).

2

Enjoying Your Speakers (continued)

**Disclaimer: Please note there are circumstances that may restrict the wireless connection from working to it's full 75' wireless capability like interference or thick walls.*

But wait, there's more. You can also pair each AirConnect speaker to its own Bluetooth® Source to use as a separate Bluetooth® Speaker. Whoa, sounds complex, right? It's not. Just 3 little steps.

1. While the speakers are off, press and hold the power button until you hear a chirp and then a beep.
2. Press the power button again to switch to Bluetooth® mode. The little indicator light will turn blue.
3. Your smart phone or tablet will show a list of devices nearby -- choose "Air Left" or "Air Right." You'll hear another beep and, presto, it's done.

**Disclaimer: Both right speakers and left speakers have the same pairing names. Some devices may not allow you to pair to one of the speakers when you have already paired to a different speaker with the same name. You might need to delete the pairing name and try to re-pair.*

3

Enjoying Your Speakers (continued)

Audio output of the Air can be used to connect to an alternate audio system, such as a home theater system, or a TV, by plugging the audio cable into the "OUT" jack on the Air and to the "line in" of the audio system of your choice.

Connection Lost?

If pairing to the speakers does not work, turn off the speakers and repeat the steps again in "Using Speakers."

Make sure your speakers are within range of your smart device.

If you hear a long beep or a voice indicating low battery, you need to recharge your speakers. Connection may be lost due to low battery.

When charging your speakers, only use the enclosed USB cable.

4

Pairing Extra AirConnect Speakers

Your Air works great, but you'd like to expand your sound even more. Air allows you to add up to another 75 AirConnect speakers to your AirBase! Pairing extra speakers is easy, all you need to do is click your extra AirConnect speaker to the AirBase and presto! You've just expanded your sound.

Disconnecting Your AirConnect Speaker from your AirBase

Air gives you the flexibility and versatility to listen to audio the way you want to. This is why you're able to disconnect AirConnect speakers from your AirBase and reconnect them to other AirBases. To disconnect an AirConnect speaker from your AirBase just follow these steps.

1. Turn off your AirConnect speakers.
2. Press and hold the power button on your AirConnect speaker for 10-15 seconds. The AirConnect speaker will power on and then back off. Make sure you continue to hold it until the AirConnect speaker powers itself off.
3. Your AirConnect Speaker is now disconnected from that AirBase and can be paired to any AirBase you heart desires.

5

Specifications

Bluetooth Version: V 5.0
Power: AirBase: 2x4 W, AirConnect: 1x4 W
Battery: AirBase: 2200 mAh/3.7V, AirConnect: 1400 mAh/3.7V
Frequency: AirBase: 88HZ-17KHZ, AirConnect: 100HZ-17KHZ
Separated Speakers Connectivity Range: Up to 75ft via 5.8ghz
Speaker Signal to Noise Ratio: (dB) >60DB
Peak Noise at Max Volume (dB, distance 1M): AirBase:80DB, AirConnect:78DB
Dolby Support: No
Microphone Support: Yes
Play Time: AirBase: Up to 7.5H, AirConnect: Up to 6H

USB Cable Input Volt: 5V 2A
Charging Time: AirBase: Up to 2.5H, AirConnect: Up to 2.5H
Audio Input: AUX
Buttons: 5 Mechanical Buttons: Play/Pause, Vol+, Vol-, Mode/Power, Reset
Material: ABS + Rubberized Grill
Bluetooth® Names: AirBase: Air, AirConnect: Air Left/Air right
Bluetooth® Range: >32.8ft
Water Resistance Grade: IPX4
Dimensions: 11.53" x 4.02" x 3.68"
Weight: AirBase: 73lbs / .33kg, AirConnect (1 piece): .48lbs / .22kg

6

WARRANTY

The Air By Quirky One-Year Limited Warranty is a voluntary manufacturer's warranty. It provides rights separate to rights provided by consumer law, including but not limited to those relating to non-conforming goods. As such, the Air By Quirky One-Year Limited Warranty benefits are in addition to, and not instead of, rights provided by consumer law and does not exclude, limit or suspend a buyer's rights arising from consumer law. Consumers have the right to choose whether to claim service under the Air By Quirky One-Year Limited Warranty or under their consumer law claims. Important: The Air By Quirky One-Year Limited Warranty terms and conditions shall not apply to consumer law claims. Please note: All claims made under the Air By Quirky will be governed by the terms set out in this warranty document.

Your Air by Quirky-branded product ("Product") is warranted against defects in materials and workmanship for a period of ONE (1) YEAR from the date of original retail purchase ("Warranty Period") when used in accordance with Air by Quirky start up guide. Under this warranty, you will be able to direct your claims to Air by Quirky even in situations where you purchased the Air by Quirky Product from a third party. If a defect arises during the Warranty Period, Air By Quirky, at its option will (i) repair the Product or no charge using new parts or parts that are equivalent to new in performance and reliability, (ii) exchange the Product with a product with equivalent functionality formed from new and/or previously used parts that are equivalent to new in performance and reliability or with your consent, a product that is at least functionally equivalent to the product it replaces. This warranty excludes normal depletion of consumable parts such as batteries unless failure has occurred due to a defect in materials or workmanship and damage resulting from abuse, accident, modifications, unauthorized repairs or other causes that are not defects in materials and workmanship.

Any limitations of liability in this warranty document shall not apply to (i) death or personal injury pursuant to any mandatory law or product liability, (ii) fraud or fraudulent misrepresentation, (iii) intentional misconduct or gross negligence, (iv) or a culpable breach of major contractual obligations. A damages claim based on a breach of major contractual obligations or gross negligence will be limited to foreseeable damage typical for the sale contract concerned. Proof of purchase may be required to verify eligibility.

For questions or help, feel free to contact us at help@airaudios.com

7

WARNING

Keep away from water and moisture. Keep away from heat sources. Do not disassemble.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.