

live love music™ QUICK START GUIDE

WIRELESS SPEAKER W/ PHONE MOUNT

CHARGING THE SPEAKER

⚡ Charge the speaker before using it for the first time.

⌚ Plug in the cable to the micro USB port and charge for at least 2 hours.

Connect the charging cable to charging port.



PAIRING YOUR SPEAKER

Your speaker will work best if it is within 30 ft. of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure Bluetooth is enabled on your smart phone or tablet before starting the pairing process.

live love music™ QUICK START GUIDE


WIRELESS SPEAKER W/ PHONE MOUNT

PAIRING YOUR SPEAKER (continued)

Make sure the speaker is turned off before attempting to pair it with a smart phone or tablet.



Press and hold the speaker on key to start the machine, and the blue light will flash when it is turned on.




At this time, turn on the Bluetooth of other devices such as mobile phones and tablet for searching. When "FB-BRQ" is found, click connect. After successful pairing, the blue light will be on for a long time.

live love music™ QUICK START GUIDE

WIRELESS SPEAKER W/ PHONE MOUNT

MEDIA KEY FUNCTIONS



live love music™ QUICK START GUIDE

WIRELESS SPEAKER W/ PHONE MOUNT

SPECIFICATIONS

Operation Range: Up to 33ft (10m)
Play Time: Up to 3 hours
Battery Capacity: 400mAh
Charging Time: Up to 2 Hours
FCC ID: 2AANZBRQ
BT ID: D051448

WARNING

• Keep the device away from heat, direct sunlight and sharp edges. • Keep the device away from heat sources or flames. • Do not insert any metal object into the device. • Risk of short circuit! • To avoid a static charge, do not use the device in an extremely dry climate. • Do not repair the unit yourself but contact an authorized specialist.

live love music™ QUICK START GUIDE

WIRELESS SPEAKER W/ PHONE MOUNT

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and

live love music™ QUICK START GUIDE

WIRELESS SPEAKER W/ PHONE MOUNT

used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.