

Size: 2.8 x 5.6"

DOUBLE SIDE PRINT



QUICK START GUIDE

GAMING LED WIRELESS EARBUDS

CHARGING THE EARBUDS

⚡ Charge the earbuds before using it for the first time.

🕒 Plug in the cable to the micro USB port and charge for at least 2 hours.

Connect the charging cable to charging port.



PAIRING YOUR EARBUDS

Your earbuds will work best if they are within 30 ft. of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure Bluetooth is enabled on your smart phone or tablet before starting the pairing process.



QUICK START GUIDE

GAMING LED WIRELESS EARBUDS

PAIRING YOUR EARBUDS (continued)

Make sure the earbuds are turned off before attempting to pair it with a smart phone or tablet.



Press and hold the "Multifunction" button for 5 seconds to turn on the earbuds. You will see the light flash red and blue. This indicates that your earbuds are ready to pair.



From your smart phone or tablet, find a list of nearby devices and choose "FB-GEBL." Enter "0000" if asked. The earbuds will flash a blue light when pairing is complete!



QUICK START GUIDE

GAMING LED WIRELESS EARBUDS

CONNECTION LOST?

- If pairing the earbuds does not work, turn off the earbuds and repeat the steps again in "Pairing your Earbuds."
- Make sure your earbuds are within range of your smart device.
- If you hear a long beep, you need to recharge your earbuds. Connection may be lost due to low battery.
- When charging your earbuds, only use the enclosed USB cable.

MEDIA KEY FUNCTIONS



Press & Hold - Increase volume

Press Once - Next Track



Press once-Play/Pause music/Answer call/hang up

Press twice-Redial
Press and hold-Turn device on/off and Reject call



Press & Hold - Decrease volume

Press Once - Previous Track



QUICK START GUIDE

GAMING LED WIRELESS EARBUDS

SPECIFICATIONS

Wireless Distance:	Up to 33ft (10m)
Play Time:	Up to 3 hours
Talk Time:	Up to 3 Hours
Standby Time:	Up to 50 hours
Battery Capacity:	3.7V 80MAH
Charging Time:	About 3 Hours
BT ID:	D051448
FCC ID:	2AANZGEBL

WARNING

Keep away from water and moisture.
Keep away from heat sources.
Do not disassemble.
operating temperature range: 0—45°C

CAUTION:

PCB of battery should not be crushed and twisted.
Battery body should not be Bended.
Do not disassemble and Do not dispose of in fire



QUICK START GUIDE

GAMING LED WIRELESS EARBUDS

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and



QUICK START GUIDE

GAMING LED WIRELESS EARBUDS

used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.