

Size: 59.14 x 57 mm

材质: 108g铜板纸, 正反面印刷, 覆亚膜

DOUBLE SIDE PRINT

Vibe™ QUICK START GUIDE

WIRELESS EARBUDS

CHARGING THE EARBUDS

⚡ Charge the earbuds before using it for the first time.

🕒 Plug in the cable to the micro USB port and charge for at least 1.5 hours.

Connect the charging cable to charging port.



Model: DG-677-ASST

Vibe™ QUICK START GUIDE

WIRELESS EARBUDS

PAIRING YOUR EARBUDS

Your earbuds will work best if they are within 33 ft. of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure Bluetooth is enabled on your smart phone or tablet before starting the pairing process.

PAIRING YOUR EARBUDS (continued)

Make sure the earbuds are turned off before attempting to pair it with a smart phone or tablet.

Vibe™ QUICK START GUIDE

WIRELESS EARBUDS



1 Press and hold the "Multifunction" button for 5 seconds to turn on the earbuds. You will see the light flash red and blue. This indicates that your earbuds are ready to pair.

2 From your smart phone or tablet, find a list of nearby devices and choose "DG-677". Enter "0000" if asked. The earbuds will flash a blue light when pairing is complete!

Vibe™ QUICK START GUIDE

WIRELESS EARBUDS

CONNECTION LOST?

- If pairing the earbuds does not work, turn off the earbuds and repeat the steps again in "Pairing your earbuds".
- Make sure your earbuds are within range of your smart device.
- If you hear a long beep, you need to recharge your earbuds. Connection may be lost due to low battery.
- When charging your earbuds, only use the enclosed USB cable.

MEDIA KEY FUNCTIONS



	Press & Hold - Increase Volume	Press Once - Next Track
	Press & Hold - Turn Device On/Off	Press Twice - Redial Last Number
	Press Once - Play/ Pause Music	
	Press & Hold - Decrease Volume	Press Once - Previous Track

Vibe™ QUICK START GUIDE

WIRELESS EARBUDS

SPECIFICATIONS

Bluetooth Version:	5.1
Wireless Distance:	Up to 33ft (10m)
Play Time:	Upto 3 Hours
Talk Time:	Up to 2 Hours
Standby Time:	Up to 75 Hours
Battery Capacity:	3.7V, 55mAh Lithium-ion
Charging Time:	About 1.5 Hours
BTID:	D051448
FCC ID:	2AANZHY-1446

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Vibe™ QUICK START GUIDE

WIRELESS EARBUDS

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

