DKnight

Contact Information

E-mail: customerservice@dknightllc.com


CE & FC X 43

DKnight




MagicBox II Quick Start up Manual

1. The Power Switch and Connectors



2. Control Buttons of the DKnight MagicBox II

• Control music play with the MagicBox II in Bluetooth mode



1) Rewind	 Press	0
2) Previous Track	 Double Press	•
3) Next track	 Press	0
4) Volume up	 Press	•
5) Volume down	 Press	•
6) Play/Pause	 Press	0

Control Buttons of the DKnight MagicBox II (Continued)

Answering Calls

You can use the MagicBox II as a portable speakerphone for incoming calls when connected wirelessly via Bluetooth.

To answer a call, press the 9 button.

To end the call, press the **3** button again. To refuse a call, press and hold the **3** button for 2 seconds. You can re-dial the last number called by the phone by double pressing the 9 button. Control the volume during the phone call:

Volume up ----- Press❶ Volume down ----- Press

IMPORTANT NOTE:

The Microphone is assembled on the back of the speaker. For better phone call quality, please face to the back of the speaker when you are calling.

3. How to charge the speaker

Before using your new wireless portable speaker, please charge it via the Micro charging cable included in the package. Charging through a computer USB port is Preferred. If you need to use an AC-DC adaptor/charger to charge the speaker, please use 5V, 1A USB wall charger.

1>Plug in the Micro USB pin into the charging port on the side of the speaker and the other end of the cable into any standard USB port. (Such as a computer USB charger)

2>The red LED indicator light will be turned on when it is charging.

- 3>After the speaker being fully charged, the red LED light will be turned off automatically.
 4>If the speaker is out of battery, the speaker will "beep" twice every 5 minutes to remind for a

The DKnight MagicBox II will take 3-4 hours to be fully charged. You can use your DKnight MagicBox II when it is charging

After being fully charged, the MagicBox II has a play time up to 12 hours depending on volume. The play time varies for a number of reasons including the volume (for Maximum volume, it could be played around 6 hours), device, connection, and music type

4. How to pair your Bluetooth device with the DKnight MagicBox II

- 1>Make sure the MagicBox II is fully charged. (refer to section 3 in the manual)
- 2>Make sure that the Aux cable is plugged out when you are trying the Bluetooth function. If the Aux cable is plugged in, the Bluetooth function will be disabled.
- 3>Turn on the Magicbox II, a blue LED light will be turned on and you can also hear a "brief message tone". And the blue LED will start flashing.
- 4>Turn on the Bluetooth function of your smart devices/PC.
- 5>Search available Bluetooth devices on your smart devices/PC. When the "MagicBox II" appears on the list, please select it and your device will pair, connecting with the MagicBox II. Very few devices will request a password, if your device does, please enter"0000" (four zeros).
- 6>After the speaker being paired successfully, you will hear a "brief message tone" again. The blue LED will stop flashing.

The MagicBox II could only pair with 1 device at once. When you turn on the MagicBoxII, the MagicBox II will be automatically connected with the last paired Bluetooth device if that Bluetooth device is available and within range.

If the MagicBox II successfully paired with the last device, it will prevent any other Bluetooth device from pairing to it. The best way is to disconnect the first device from the MagicBoxII before trying to pair to another device.

To disconnect a device from the DKnight MagicBox II, please press and hold the o for 5 seconds until the Blue light flashing. The Blue light flashing indicates the device is disconnected and the MagicBox II is in pairing mode.

5.Connecting to non-Bluetooth (Aux-IN) devices

For devices that do not have Bluetooth or support for Bluetooth audio, you can connect and play music and audio by connecting your device to the AUX IN jack on the the DKnight MigicBox II with the included 3.5mm audio cable.

- $1{>}Turn\ on\ the\ DK night\ Magic Box\ II\ by\ sliding\ on\ the\ ON/OFF\ switch\ to\ the\ on\ position.$
- 2>Plug one end of the 3.5 mm audio cable into the AUX IN jack on the right side of the DKnight MagicBox II and plug the other end into the headphone jack on your device. You can then play your music and audio on the DKnight MagicBox II.

IMPORTANT NOTE:

When in AUX IN mode the forward/backward and volume +/- is controlled from the device only. The • , • , • and • will not function on the DKnight MagicBox II.

6. Troubleshooting.

Problem	Solution
MagicBox II will not turn on	Make sure the MagicBox II has sufficient charge. Make sure the power switch is fully in the on position.
Cannot pair the MagicBox II with my Bluetooth device	Please make sure that audio cable is plugged out when you are trying the Bluetooth function. Please make sure the speaker is not connected with any other devices. (the speaker could only pair with 1 device at once) The MagicBox II will be automatically connected with the last paired Bluetooth device. The best way is to disconnect the Bluetooth of your other devices at first and try it again. (refer to section 4)
MagicBox II appears on my device, but will not connect	Please make sure the speaker is not connected with any other devices. Disconnect the other device from the DKnight MagicBox II. Turn the MagicBox II on and off. Remove the MagicBox II from the pairing list on the device and then repair.

Could not find Bluetooth driver for my Laptop	For some older generation laptop/desktop, the Bluetooth driver on the laptop/desktop might not supported. We are suggesting you to buy an external Bluetooth USB adaptor for your computer to support Bluetooth usage.
Could not pair with my Magic box ll	Please update your MacBook to the new OS X 10.9 (Mavericks) When you use BT connection between your MacBook and the Bluetooth speaker, make sure that the Mac uses the Speaker as an audio device.
Bluetooth range is short	For smartphone/pad, the straight line Bluetooth range varies from 15-30ft depending on the Bluetooth driver and OS of the paired device. For laptop/desktop, the Bluetooth range will drop significantly depending on the Bluetooth drive on the computer. Since Bluetooth is a low power solution, obstacle between speaker and the paired device will degrade the Bluetooth range significantly.