

## TABLE OF CONTENTS

### manual conventions



**NOTE:** Describes special issues you should be aware of while using a particular function.



**WARNING:** Calls out situations in which equipment could be damaged or a process could be incorrectly implemented, but in which operator safety is not a factor.



**TIP:** Describes application hints.

Quick Start .....	4-5
Complete These Steps .....	4
Thermal Issues .....	4
Introduction .....	6
Operation .....	7
Using your Palladium Transmitter .....	7
Changing your Transmitter Configuration .....	7
Components .....	8-9
Programming .....	10-15
System PC Controller Application Software .....	10
Getting Started .....	10
Transmitter Control Application .....	11
Specifications .....	16-17
Warranty .....	18
Contact Us .....	19

### RF EXPOSURE STATEMENT

A separation distance of at least 20 cm must be maintained between the antenna and the body of the user or nearby persons.



**NOTE:** This device is for occupational use only. Occupational users are those persons who are exposed as a consequence of their employment, provided these persons are fully aware of and exercise control over their exposure.

### ANTENNA SELECTION

In order to maintain compliance with FCC regulations concerning maximum permissible exposure, the gain of the attached transmitting antenna must be no greater than 5 dBi.