




OPERATION INSTRUCTION



MODEL:
TX015
TX015-L
TX015-R
TX015-C
TX015-LR
TX015-LC
TX015-RC
TX015-LRC

Note: Install the 12-volt battery to the remote control.




Remote Control Functions:

1. Fan speed control button: To control the ceiling fan speed HIGH, MEDIUM, LOW.
2. FAN/OFF Button: To turn the fan on/off.
3. Sleep Timer Button.
4. LIGHT ON/OFF/DIMMING Button: To control light on/off/dimming.
5. Reverse Setting Switch: To control fan direction.

Remote Control Functions:


1. Fan speed control button: To control the ceiling fan speed HIGH, MEDIUM, LOW.
2. FAN/OFF Button: To turn the fan on/off.
3. Sleep Timer Button.
4. LIGHT ON/OFF/DIMMING Button: To control light on/off/dimming.
5. Reverse Setting Switch: To control fan direction.
6. ① Learning code pairing function;
② Customization.

OPERATION INSTRUCTION




Remote Control Functions:

1. Fan speed control button: To control the ceiling fan speed HIGH, MEDIUM, LOW.
2. FAN/OFF Button: To turn the fan on/off.
3. Sleep Timer Button.
4. LIGHT ON/OFF/DIMMING Button: To control light on/off/dimming.
5. Reverse Setting Switch: To control fan direction.
6. ① Select Light ON/OFF Mode or Light ON/OFF/DIMMING Mode;
② Customization.




Remote Control Functions:

1. Fan speed control button: To control the ceiling fan speed HIGH, MEDIUM, LOW.
2. FAN/OFF Button: To turn the fan on/off.
3. Sleep Timer Button.
4. LIGHT ON/OFF/DIMMING Button: To control light on/off/dimming.
5. Reverse Setting Switch: To control fan direction.
6. ① Select Common Code / Private Code System;
② Customization.



Remote Control Functions:


1. Fan speed control button: To control the ceiling fan speed HIGH, MEDIUM, LOW.
2. FAN/OFF Button: To turn the fan on/off.
3. Sleep Timer Button.
4. LIGHT ON/OFF/DIMMING Button: To control light on/off/dimming.
5. Reverse Setting Switch: To control fan direction.
6. ① Learning code pairing function;
② Customization.
7. ① Select Light ON/OFF Mode or Light ON/OFF/DIMMING Mode;
② Customization.



Remote Control Functions:


1. Fan speed control button: To control the ceiling fan speed HIGH, MEDIUM, LOW.
 2. FAN/OFF Button: To turn the fan on/off.
 3. Sleep Timer Button.
 4. LIGHT ON/OFF/DIMMING Button: To control light on/off/dimming.
 5. Reverse Setting Switch: To control fan direction.
 6. ① Learning code pairing function;
② Customization.
 7. ① Select Common Code / Private Code System;
② Customization.
-

OPERATION INSTRUCTION



Remote Control Functions:

1. Fan speed control button: To control the ceiling fan speed HIGH, MEDIUM, LOW.
2. FAN/OFF Button: To turn the fan on/off.
3. Sleep Timer Button.
4. LIGHT ON/OFF/DIMMING Button: To control light on/off/dimming.
5. Reverse Setting Switch: To control fan direction.
6. ①Select Light ON/OFF Mode or Light ON/OFF/DIMMING Mode;
②Customization.
7. ①Select Common Code / Private Code System;
②Customization.



Remote Control Functions:

1. Fan speed control button: To control the ceiling fan speed HIGH, MEDIUM, LOW.
2. FAN/OFF Button: To turn the fan on/off.
3. Sleep Timer Button.
4. LIGHT ON/OFF/DIMMING Button: To control light on/off/dimming.
5. Reverse Setting Switch: To control fan direction.
6. ①Learning code pairing function;
②Customization.
7. ①Select Light ON/OFF Mode or Light ON/OFF/DIMMING Mode;
②Customization.
8. ①Select Common Code / Private Code System;
②Customization.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.