


Dell Wyse 5050 All-in-One Zero Client with PCoIP

Wyse 5000 Series


Quick Start Guide



1 Install the stand



2 Connect the keyboard and mouse



 **NOTE:** To connect a wireless keyboard or mouse, see the documentation that shipped with it.

Product support and manuals

dell.com/support
dell.com/support/manuals

Contact Dell

dell.com/contactdell

Regulatory and safety

dell.com/regulatory_compliance

Regulatory model

N01A

Regulatory type

N01A001


Computer model

Dell Wyse 5050 All-in-One
Zero Client with PCoIP





0BARCODE0


3 Connect the network cable (sold seperately)



4 Connect the power cable and press the power button



Features



- | | |
|---|--------------------------|
| 1. Power light | 14. Headphone connector |
| 2. Power button | 15. Microphone connector |
| 3. On Screen Display (OSD) control buttons | |
| 4. On Screen Display (OSD) menu button | |
| 5. On Screen Display (OSD) auto/exit button | |
| 6. VGA connector | |
| 7. DVI connector | |
| 8. Network connector | |
| 9. USB 2.0 connectors | |
| 10. Power connector | |
| 11. Stand | |
| 12. Security lock slot | |
| 13. USB 2.0 connectors | |

On Screen Display (OSD) Menu

- Color
- Image Setting
- Signal Source
- Language

 **NOTE:** The power adapter is internal and you must connect the power cable to the power connector.