

Locking/Unlocking the doors of the vehicle

INSTRUCTIONS

When the engine switch is off and you push the lock button on the outside door handle while carrying Smart Card Key, all doors will be locked.

Make sure all the doors are locked when you leave the vehicle.

When you take hold the back side of the outside door handle on the driver's door carrying Smart Card Key, the driver's door will be unlocked. When you take hold the back side of the outside door handle except on the driver's door, carrying Smart Card Key, all the doors will be unlocked.

When you push the trunk button on the trunk lid while carrying Smart Card Key, the trunk lid will be unlocked.

NOTE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.