

**DRAFT**

## **Disney Infinity: Toy Box Challenge Nintendo 3DS™ system Start Up Guide**

**\*\*\*\*ALL IMAGERY IS PLACEHOLDER/PRELIMINARY\*\*\*\***

### **Disney Infinity Start Up Guide -- Table Of Contents**

- Safety Precautions
- Package Contents
- Disney Infinity Base Instructions
  - Set Up
  - Using the Disney Infinity Base
- Troubleshooting
- Tech/Customer Support Information
- Legal

## **Safety Precautions:**

WARNING! CHOKING HAZARD Small parts.

Not suitable for children under 3 years

For your safety and the safety of others, please read the following product care information and the game manual before using this product. Keep all game manuals because they contain important information about using and caring for the product.

**Product Care:** (1) Only use the products with the gaming system for which they are designed. (2) Keep the products dry and away from open flames or other heat sources. (3) Do not modify or take apart the products. (4) Use a dry cloth to clean the products.

Questions or issues when setting up your new products?

Please refer to the game manual in your Disney Starter Pack for Customer Support details.

**Product Disposal Information:** Dispose of this product in accordance with local and national disposal regulations (if any), including those governing the recovery and recycling of waste electrical and electronic equipment (WEEE Directive 2002/96/EC).

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short circuited.

Retain package for future reference as it contains important information.

## Package Contents:

The Disney Infinity Starter Pack includes the following components:



- A) Disney Infinity Base
- B) Disney Infinity Figure
- C) Disney Infinity Figure
- D) Disney Infinity Figure
- E) Disney Infinity Play Set Piece
- F) Disney Infinity Power Disc (each Disney Infinity Starter Pack contains a randomly selected Power Disc)
- G) Disney Infinity Web code Card

Use the Disney Infinity web code at [disney.com/infinity](http://disney.com/infinity) to unlock new content on the web! Just enter the Disney Infinity web code provided with your interactive Disney Infinity Figure. Terms and Conditions apply. [disney.com/infinity](http://disney.com/infinity).

## Setting Up the Disney Infinity Base:



Circle: Disney Infinity Figure and/or Power Disc spot

Hexagon: Disney Infinity Play Set Piece and/or Power Disc spot


DR



## QUICK START GUIDE

### Setting Up the Disney Infinity Base:

- 1) Once removed from the packaging, turn the Base over and use a Phillips #1 screwdriver (turning to the right) to open the battery compartment. Insert three (3) AAA/R03 (1.5V) batteries (not included) into the battery compartment of the Disney Infinity Base bottom (pictured below) and close the compartment using a Phillips #1 screwdriver (turning to the left).

*Nintendo 3DS system Disney Infinity Base bottom*





(3) AAA/R03 (1.5V) batteries (not included)

- 2) The Disney Infinity Base (pictured below) needs to be placed on a stable, secure and even surface that is near the Nintendo 3DS, so that the infrared transceiver can be aligned.
  - a. Round pad: Disney Infinity Figure and/or Power Disc spot
  - b. Hexagonal pad: Disney Infinity Play Set Piece and/or Power Disc spot

#### Using the Disney Infinity Base:

- 1) Note that the Disney Infinity Base does not have a switch to turn it on/off. The Base is automatically awakened when in communication with the game, via the infrared transceiver.
- 2) The Disney Infinity Base only communicates with the game when the game is placed in specific Scan modes.
  - a. In the game, navigate to the Scan Menu.
  - b. Select "Scan"
  - c. Align the Disney Infinity Base and the Nintendo 3DS so that the infrared transceiver are aligned.
  - d. Place a Disney Infinity Figure on the round pad of the Base
  - e. Base should light up, indicating a Disney Infinity Figure is detected
- 3) Equip your character with additional powers using the Disney Infinity Power Discs
  - a. Equip your characters with bonuses by placing up to two Power Discs on the Circle slot beneath your Disney Infinity Figure.
  - b. Place Hex Power Discs or play set pieces on the Hex Slot to unlock new content in the catalog.



### **Troubleshooting:**

#### **Disney Infinity Figure is not appearing in-game:**

- 1) Be sure the Disney Infinity Base is on a flat surface.
- 2) Be sure the Disney Infinity Figure is placed completely flush with the circular spot with nothing in between the Base and the Disney Infinity Figure (unless a Power Disc is being used).
  - a. Only one Power Disc may be used at a time on the Hex Slot.
- 3) Be sure the infrared transceiver on the Base is aligned with the infrared transceiver on the Nintendo 3DS.
- 4) Please make sure you have enough battery power.

### **Customer Support Information**

#### **Internet Support**

To access support for Disney Interactive Studios on the World Wide Web, point your browser to **[DisneyInteractiveStudios.custhelp.com](http://DisneyInteractiveStudios.custhelp.com)**.

#### Game Hints and Tips

Game hints and tips are available on our Customer Support website. To access Game Hints and Tips on the World Wide Web, point your browser to [DisneyInteractiveStudios.custhelp.com](http://DisneyInteractiveStudios.custhelp.com).

#### Mailing Address

If you wish to write us, our address is: **Disney Interactive Studios Customer Support, 500 South Buena Vista Street, Burbank, CA 91251-9323.**

#### Telephone Support

You may contact Customer Support at **(888) 817-2962**. If you need additional information, our Customer Support staff for the U.S. and Canada is available Monday through Friday from 9:00 a.m. to 6:00 p.m. (Pacific Time).

#### TTY/TDD Users

Please contact us by telephone through your local relay service. Customer Support staff for TTY/TDD users is available Monday through Friday 9:00 a.m. to 6:00 p.m. (Pacific Time). Our toll free number is **(888) 817-2962**.

Model No.: INF-8032383

CE0890

#### FCC Information

FCC ID: QOF-8032383

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## IC Information

IC: 10749A-8032383

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts. L'exploitation est autorisée aux deux conditions suivantes :  
(1) l'appareil ne doit pas produire de brouillage, et  
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

© Disney. © Disney/Pixar.