

Mobile Accessories

1. Remote Commanders

RM-VD1

Features:
Remote commander for
Cam & DSC

02131950

RM-X114

Features:
Credit card remote controller for: CDX-CA750,
CDX-CA750X, CDX-CA650, CDX-CA650x,
CDX-CA650V, CDX-C5000R, NDX-C800REC,
MDX-CA680, MDX-CA680X, MDX-CA580,
MDX-CA580/1, XR-CA600, XR-CA600X, XR-
CA600V, XR-L500, XR-500X, XR-L500V

36406190

RM-X47

Features:
Also for new CDX-
C580R, CDX-X580RW,
CDX-C780R, XR-
C7200R, XR-C8100R,
XR-C8100RW



36226950

RM-X4S

Features:
Also for new CDX-3180, CDX-
3183, CDX-4170R, CDX-4180R,
CDX-4483ESP, CDX-C570R,
CDX-C580R, CDX-C580RW,
MDX-C7890R, XR-2803, XR-
4790, XR-4800, XR-C5080R,
XR-C5790R



36206052

2. Changers

XA-10B

Features:
10 CD changer
for all 10-CD
players for
models before
1996



95270010

XA-250


Features:
10 CD
changer for:
CDX-505RF,
CDX-605,
CDX-705,
CDX-715,
CDX-805



27145010

XA-300

Features:
AUX selector



27149295

XA-4

Features:
4 MD
changer for:
MDX-
400RDS,
MDX-40



X33675811

XA-T7

Features:
Magazine for 6
CD changer,
separate tray for
each CD, models:
CDX-T68X,
CDX-T67



27149110

3. Cables and Plugs

RC-46

Features:
Feeder cable for high
power amplifier

27060210

RC-89

Features:
RCA pin cable for 4
channel amplifier



27090910

RC-91

Features:
Sony bus line cable for
CD/MD changers 5.5m



27090810

RC-97

Features:
Optical cable with
lock type connectors
2m



27091810

RC-98

Features:
Optical cable with lock
type connectors 5m



27091910

XA-18MK2

Features:
Interface with Sony bus
type dashboard units &
older CDX-A

27093410

XA-C30

Features:
Selector for car stereo



27143350

XA-D210

Features:
Optical cable adapter
for MDX-400RDS &
CDX-C910RDS

27092510

4. Security Brackets

GMD-303  <i>Discontinued</i> Features: For use with XR-7200, XR-7201, XR-7202, XR-7307, XR-7400 91977110	GMD-304  <i>Discontinued</i> Features: For use with XR-7080, XR-7081, XR-7082, XR-7180 91978410	GMD-305  <i>Discontinued</i> Features: For use with CDX-R79, CDX-R79L, CDX-6060, CDX-6061, CDX-6062 91978510	GMD-306  <i>Discontinued</i> Features: For use with XR-7190, XR-7191, XR-7192, XR-7280 27060410
GMD-307  <i>Discontinued</i> Features: For use with CDX-5080, CDX-5081, CDX-5082, CDX-7560, CDX-7561, CDX-7562, CDX-7580, CDX-7581, CDX-7582 27062310	GMD-309  <i>Discontinued</i> Features: For use with XR-7070, XR-7071, XR-7072, XR-7077 27062710	GMD-312  <i>Discontinued</i> Features: For use with XR-7140, XR-7142, XR-7170, XR-7171, XR-7172 27065410	GMD-313  <i>Discontinued</i> Features: For use with XR-4250, XR-4252, XR-4257, XR-4301, XR-4350, XR-4351, XR-4357, XR-5150, XR-5151, XR-5152, XR-5250 27065510
GMD-314  <i>Discontinued</i> Features: For use with XR-500, XR-502, XR-A55 27090210	GMD-616 Features: Car compo rack (protects front side against water, sand or dust) 91976710		

5. Front Panels: Radio Cassette

	Model	Partnumber	Replacement	Description
	XR-1300R	A3315102A		Amber
	XR-1300R	A3315103A		Green
	XR-1800	F36207956		Amber
	XR-1800	A3301431A		Green
	XR-1800R	A3301652A		Amber
	XR-1800R	A3301654A		Green
	XR-1803	F36207958		
	XR-3100R	A3301987A		Green
	XR-3100R	A3301986A		Amber
	XR-3200	F27153455		
	XR-3200	F27153457		Green
	XR-3201	F27153456		
	XR-3202	F27153475		
Ⓢ Discontinued	XR-3208Mk2	F27801456		
	XR-3209	F27159755		
	XR-3310	F27153057		
	XR-3312	F27153076		
	XR-3490	F27161055		
	XR-3490	F27161057		Green
	XR-3491	F27161056		
	XR-3492	F27161075		
	XR-3500	F27159055		
	XR-3500	F27159057		Green
	XR-3501	F27159056		
	XR-3501Mk2	F27801256		Amber
	XR-3501Mk2	F27801257		Green
	XR-3502	F27159075		
	XR-3503	F27159058		
	XR-3503Mk2	F27801258		
	XR-3509	F27801355		
	XR-3690RDS	F27801655		
	XR-3700RDS	F27167855		Amber
	XR-3700RDS	F27167856		Green
	XR-3750	F36201557		

5. Front Panels: Radio Cassette

	Model	Partnumber	Replacement	Description
	XR-3753	F36201553		
	XR-3758	F36260557		Amber
	XR-3758	F36260558		Green
	XR-3759	F36260556		Green
	XR-4200R	A3315019A		Amber/Green
	XR-4300R	A3315020A		
	XR-4300RV	A3315022A		
	XR-4300RX	A3315024A		
	XR-4400	F27018052		Green
	XR-4400	F27018030		
	XR-4403	F27018080		
Ⓢ Discontinued	XR-4409	F27018256		Green
Ⓢ Discontinued	XR-4409	F27018259		
	XR-4410	F27152958		Green
	XR-4410	F27152957		
	XR-4501	F27017751		
	XR-4740RDS	F27803055		Amber
	XR-4740RDS/1	F27803056		Green
	XR-4750RDS	F27802956		Green
	XR-4750RDS	F27802955		Amber
	XR-4758RDS	F36260458		Green
	XR-4759RDS	F36260456		Green
	XR-4790	F36207255		Amber
	XR-4790	F36207256		Green
	XR-4800	F36207156		Green
	XR-4800	F36207155		Amber
	XR-4803	F36207157		
	XR-4880	A3301763A		Amber/Green
	XR-4890	A3301720A		
	XR-4950X	A3315409A		Red
	XR-5350	F27010850		
	XR-5352	F27010870		
	XR-5450	F27010950		
	XR-5451	F27010951		

5. Front Panels: Radio Cassette

	Model	Partnumber	Replacement	Description
	XR-5500RDS	F27017952		Green
	XR-5500RDS	F27017970		
Ⓢ Discontinued	XR-5520RDS	F27152855		
	XR-5550	F27011050		
	XR-5600RDS	F27017870		
	XR-5700RDS	F27011150		
	XR-5701RDS	F27011151		
Ⓢ Discontinued	XR-5790R	F36206956		Green
Ⓢ Discontinued	XR-5790R	F36206955		Amber
Ⓢ Discontinued	XR-5800R	F36206856		Green
Ⓢ Discontinued	XR-5800R	F36206855		Amber
	XR-5800RV	A3301670A		
	XR-5820R	F36206878		Green
	XR-5880R	A3301707A		
	XR-5890R	A3301703A		
	XR-6430	F27160270		
	XR-6440RDS	F27159170		
	XR-6453	F27158653		
Ⓢ Discontinued	XR-6459	F27159555		
	XR-6503	F27165957		
	XR-6559	F27800376		Green
	XR-6600RDS	F27800855		
	XR-6600RDS	F27800876		Green
Ⓢ Discontinued	XR-6650RDS	F27158055		
Ⓢ Discontinued	XR-6659RDS	F27158156		Green
	XR-6690RDS	F27801055		
	XR-6700RDS	F27800955		
	XR-6759RDS	F27800475		
	XR-6759RDS	F27800476		Green
	XR-6859RDS	F27802155		
	XR-7031	F27019351		

5. Front Panels: Radio Cassette

	Model	Partnumber	Replacement	Description
	XR-7032	F27019370		
	XR-7040	F27018350		
	XR-7041	F27018351		
	XR-7042	F27018370		
	XR-C100	F27167456		Green
	XR-C100	F27167455		Amber
	XR-C101	F27167457		
	XR-C110	F27167356		Green
	XR-C110	F27167355		Amber
	XR-C111	F27167357		
	XR-C113	F27167358		Amber
	XR-C180	F27801756		Green
	XR-C180	F27801755		Amber
	XR-C200	F27155650		
	XR-C200	F27155652		Green
	XR-C200Mk2	F27160670		
	XR-C200Mk2	F27160672		Green
Ⓢ Discontinued	XR-C202	F27155670		
	XR-C202Mk2	F27160671		
Ⓢ Discontinued	XR-C210	F27155350		
	XR-C210/1	F27155352		
	XR-C210MK2	F27160572		Green
	XR-C210MK2	F27160570		
	XR-C212	F27155370		
	XR-C212MK2	F27160571		
	XR-C213	F27155353		
	XR-C213Mk2	F27160550		
	XR-C220	F27800256		Green
	XR-C220	F27800255		
	XR-C223	F27801153		
	XR-C2300R	A3315059A		Green
	XR-C2300R	A3315000A		Amber
	XR-C290RDS	F27800175		

5. Front Panels: Radio Cassette

	Model	Partnumber	Replacement	Description
Ⓢ Discontinued	XR-C300RDS	F27800075		
Ⓢ Discontinued	XR-C33R	A3301988A		Amber
Ⓢ Discontinued	XR-C33R	A3301989A		Green
	XR-C350	F36202256		Green
	XR-C350	F36202255		Amber
	XR-C353	F36202253		
	XR-C370J	A3337111A		Amber
	XR-C410	F27155452		Green
	XR-C410	F27155450		
Ⓢ Discontinued	XR-C4100	F36207056		Green
	XR-C4103	F36207057		
	XR-C412	F27155470		
	XR-C412	F27155472		Green
	XR-C4120	A3301719A		
Ⓢ Discontinued	XR-C420RDS	F27158255		
	XR-C440RDS	F27802555		
	XR-C453RDS	F36202157		
	XR-C503	F27165853		
	XR-C5080R	F36206755		Amber
	XR-C5080R	F36206776		Green
	XR-C5090R	F36206655		
	XR-C5100R	F36206555		
	XR-C5103R	F36206557		
	XR-C5109R	F36214355		
	XR-C5110R	A3301706A		
	XR-C5120R	A3301705A		
	XR-C5120RA	A3315002A		Red
	XR-C5300R	A3315013A		Amber/Green
	XR-C5300RV	A3315015A		Amber/Green
	XR-C5300RX	A3315016A		Red
	XR-C540RDS	F27802355		
	XR-C553SP	F36202053		
	XR-C6090R	F36206455		

5. Front Panels: Radio Cassette

	Model	Partnumber	Replacement	Description
Ⓢ Discontinued	XR-C6100R	F36206355		
	XR-C6103SP	F36206353		Amber
	XR-C620RDS	F27158470		
	XR-C6210R	A3301710A		
	XR-C6220R	A3301712A		
	XR-C650RDS	F36202456		Wood
	XR-C650RDS	F36202455		
	XR-C653SP	F36202453		
	XR-C700RDS	F27800655		
	XR-C7200R	F36209255		
	XR-C7203SP	A3301612A		
Ⓢ Discontinued	XR-C720RDS	F27158370		
Ⓢ Discontinued	XR-C7220R	A3307306A		Amber/Green
	XR-C7500R	A3315064A		Amber/Green
	XR-C7500RX	A3315065A		
Ⓢ Discontinued	XR-C750RDS	F27803250		
	XR-C8100R	A3220651A		
	XR-C8100RW	A3220650A		Wood
Ⓢ Discontinued	XR-C8220R	A3307299A		Amber/Green
	XR-C850RDS	F27803150		
Ⓢ Discontinued	XR-C850RDS	F27803151		Wood
	XR-C900RDS	F27801550		
	XR-C9100R	A3220667A		
	XR-CA300	A3315299A		
	XR-CA310	A3315341A		Green
	XR-CA310	A3315340A		Amber
	XR-CA400	A3307728A		W. Yellow
	XR-CA410	A3307732A		Green
	XR-CA410	A3307729A		Amber
	XR-CA430X	A3337064A		Red
	XR-CA430X	A3337043A		Red
	XR-CA440	A3337047A		Green

5. Front Panels: Radio Cassette

	Model	Partnumber	Replacement	Description
	XR-CA440	A3337093A		Green
	XR-CA440X	A3337069A		Red
	XR-CA600	A3307753A		Amber/Green
	XR-CA600V	A3307763A		Red
	XR-CA600X	A3307766A		Red
	XR-CA630X	A3337050A		Red
	XR-CA630X	A3337080A		Red
	XR-CA800	A3307905A		
	XR-L200	A3315305A		
	XR-L210	A3315343A		Green
	XR-L210	A3315342A		Amber
	XR-L240	A3315467A		Amber
	XR-L240	A3315479A		Green
	XR-L500	A3307747A		Amber/Green
	XR-L500V	A3307765A		
	XR-L500X	A3307750A		
Ⓢ Discontinued	XR-U300RDS	F27017652		Green
	XR-U301RDS	F27017651		
	XR-U330	F27011556		Green
	XR-U330	F27011550		
	XR-U331	F27011551		
	XR-U401RDS	F27017551		
	XR-U440RDS	F27011250		
	XR-U551RDS	F27011451		
	XR-U661RDS	F27011351		
Ⓢ Discontinued	XR-U700RDS	F27017270		

6. Front Panels: CD Player

	Model	Partnumber	Replacement	Description
	CDX-2500R	A3301968A		Amber
	CDX-2500R	A3301969A		Green
	CDX-3000	F36220355		
	CDX-3002	F36220455		
	CDX-3100	F27137055		Green
	CDX-3100	F27137075		Amber
	CDX-3103	F27137058		
	CDX-3150	F36221255		Amber
	CDX-3150	F36221276		Green
	CDX-3160	F36221155		Amber
	CDX-3250	A3301725A		Amber
	CDX-3250	A3301777A		Green
Ⓢ Discontinued	CDX-3900R	A3315025A		
	CDX-4000R	A3315026A		Amber/Green
	CDX-4000RV	A3315030A		Red
	CDX-4000RX	A3315029A		Red
Ⓢ Discontinued	CDX-4100RDS	F27136355		
	CDX-4100RDS	F27802055		Green
Ⓢ Discontinued	CDX-4150RDS	F36220655		Amber
	CDX-4180RV	A3301651A		
	CDX-4240R	A3301728A		
	CDX-4250R	A3301726A		
Ⓢ Discontinued	CDX-4250R	A3301727A		Green
	CDX-4260	A3301929A		Amber
	CDX-4270R	A3301928A		Green
	CDX-5032	F27134070		
	CDX-5060	F14159551		
	CDX-5070	F27131152		Green
	CDX-5070	F27131151		
	CDX-5072	F27131170		
	CDX-5090	F27132750		
	CDX-5090	F27132751		Green
	CDX-5100RDS	F27136255		
	CDX-5180	F27001850		
	CDX-5181	F27001851		
	CDX-5270	F27131250		
	CDX-5272	F27131270		
	CDX-5290RDS	F27133150		

6. Front Panels: CD Player

	Model	Partnumber	Replacement	Description
	CDX-5460RDS	F14159370		
	CDX-600DSP	F27131370		
	CDX-900RDS	F14159070		
	CDX-C470X	A3337105A		
	CDX-C4840R	A3301731A		
	CDX-C4850R	A3301730A		
	CDX-C4900R	A3315028A		Amber/Green
Ⓢ Discontinued	CDX-C490RDS	F27133355		
	CDX-C5000R	A3315027A		
	CDX-C5000RV	A3315032A		
	CDX-C5000RX	A3315031A		
	CDX-C560RDS	F36222570		
	CDX-C570R	F36225458		
	CDX-C580R	F36225358		
	CDX-C5850R	A3301746A		
	CDX-C5850RW	A3307345A		Wood
	CDX-C610RDS	F27137650		
	CDX-C6850R	A3301744A		
	CDX-C760RDS	F36222370		
	CDX-C780R	F36227550		Amber
	CDX-C7850R	A3301825A		Green
	CDX-C8000RX	A3315088A		Red
	CDX-C810DSP	F27137450		
	CDX-C860RDS	F36222270		
Ⓢ Discontinued	CDX-C880R	F36227650		
	CDX-C8850R	A3301914A		Amber
	CDX-C90R	A3301656A		
	CDX-C910RDS	F36222150		
	CDX-CA400	A3337073A		Green
	CDX-CA530X	A3337074A		Red
	CDX-CA580	A3337075A		Red
	CDX-CA600	A3337076A		Amber/Green
	CDX-CA600	A3337077A		Red

6. Front Panels: CD Player

Model	Partnumber	Replacement	Description
CDX-CA650	A3307775A		Amber/Green
CDX-CA650V	A3307780A		Red
CDX-CA650X	A3307777A		Red
CDX-CA700	A3337021A		Amber/Green
CDX-CA700X	A3337023A		Red
CDX-CA700X	A3337052A		
CDX-CA750	A3307828A		Amber/Green
CDX-CA750X	A3307831A		Red
CDX-CA850	A3307872A		Red
CDX-CA900	A3290857A		Red
CDX-CA900X	A3290866A		Red
CDX-L350	A3307745A		W. Yellow
CDX-L360	A3307748A		Amber
CDX-L360	A3307742A		Green
CDX-L400X	A3307998A		Red
CDX-L410	A3337001A		Green
CDX-L410	A3307999A		Amber
CDX-L420V	A3337003A		Blue
CDX-L450	A3315311A		Amber/Green
CDX-L450X	A3307929A		
CDX-L550	A3307773A		Amber/Green
CDX-L550V	A3307771A		Red
CDX-L550X	A3307769A		Red
CDX-L600X	A3337014A		Red
CDX-M730	A3315515A		
CDX-M770	A3315362A		
CDX-MP30	A3290928A		Red
CDX-MP30	A3290933A		Red
CDX-MP30X	A3315778A		Red
CDX-MP70	A3337058A		
CDX-MP70	A3290880A		Red
CDX-U6180RDS	F27130070		
CDX-U8001RDS	F27001551		

7. Front Panels: MD Player

	Model	Partnumber	Replacement	Description
Ⓢ Discontinued	MDX-100RDS(AE)	F27100950		
	MDX-400RDS	F27100870		
	MDX-C150RDS	F27101770		
	MDX-C5960R	A3301828A		
	MDX-C5970R	A3301824A		
	MDX-C5970R/1	A3301827A		Only green display
	MDX-C6400R	A3315051A		
	MDX-C6500R	A3315004A		
	MDX-C6500RX	A3315049A		
	MDX-C7890R	F27105250		
	MDX-C7900	F27105150		
	MDX-C7970R	A3301920A		
	MDX-C800REC	A3315149A		
	MDX-C8500R	A3315094A		
	MDX-C8900R	A3220670A		
	MDX-C8970R	A3301906A		
	MDX-CA580	A3315308A		
	MDX-CA580/1	A3307807A		
	MDX-CA680	A3315272A		
	MDX-CA680X	A3315276A		

8. Others

	Model	Partnumber	Replacement	Description
	MDX-U1RDS	F27100370		
	XK-R100RDS	F11972670		
	XTC-102	F27000870		
	XTC-C200RDS	F27144150		Amber
	XTC-C200RDS	F27144180		Green
	XTC-U201RDS	F27001951		