

# HOT SHOE CONVERTER


HSA-CSASM

Sony/Minolta Hot Shoe  
to Sony MIS Flash adapter

USER MANUAL

## THANK YOU FOR CHOOSING VELLO

The Vello HSA-CSASM adapter makes your Sony/Minolta hot-shoe camera compatible with Sony MIS flashes. This adapter bridges the gap between these two technologies to fully support Sony's ADI/P-TTL metering system and provides complete flash functionality.



Release  
button

## MOUNTING THE ADAPTER

Insert the adapter's mounting foot into the camera's hot-shoe. The shoe adapter will click into place.

## MOUNTING YOUR FLASH

1. Insert the flash's mounting foot into the adapter's shoe mount.
2. Lock and secure the flash to the adapter.

*Note: For more detailed information, refer to your flash's manual for instructions.*

## REMOVING A FLASH UNIT AND THE ADAPTER

1. Unlock the flash and slide it out of the adapter's shoe mount.
2. Press the release button on the adapter and slide it out of the camera's shoe mount.

## PRECAUTIONS

- Please read and follow these instructions, and keep this manual in a safe place.
- There are no user-serviceable parts inside any of these devices. Do not attempt to disassemble or perform any unauthorized modification.
- Do not allow the adapter or converter to come into contact with either oil or saltwater.
- Keep all contacts clean.

## ONE-YEAR LIMITED WARRANTY

This VELLO product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR

ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Vello Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Vello along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit [www.vellogear.com](http://www.vellogear.com) or call Customer Service at 212-594-2353.

Product warranty is provided by the Gradus Group.

[www.gradusgroup.com](http://www.gradusgroup.com)

VELLO is a registered trademark of the Gradus Group. © 2015 Gradus Group LLC. All Rights Reserved.