



# Illustrated Parts List

## Model Series

# 243400

TYPE NUMBERS:


0010, 0020, 0021, 0022, 0023, 0024,  
0110 through 0201,  
0510 through 0561,  
0610 through 0801,  
1111, 1116, 1117,  
1130 through 1164,  
1166, 1167, 1168, 1169, 1170, 1172, 1173, 1174,  
2520, 2522, 2524, 2528, 2529, 2530, 2531,  
2540, 2541, 2550, 2561, 2580, 2581.

Not for  
Reproduction



PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted,  
in any form or by any means, electronic or mechanical, including photocopying,  
recording or by any information storage and retrieval system, without permission  
in writing from Briggs & Stratton Corporation.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1		Cylinder Assembly <b>(NO LONGER AVAILABLE)</b>	14	691690	Stud (Cylinder Head) Used on Type No(s). 0661, 0743, 0763, 0801, 1111, 1116, 1130, 1131, 1133, 1136, 1137, 1160, 1163, 1164, 1166, 1167, 1170, 1172, 2520, 2524, 2528, 2529, 2540, 2550, 2561.	635	66538S	Boot-Spark Plug
5	691150	Head-Cylinder	279	690294	Screw (Valve Cover)	645	692880	Bushing-Plunger
6	691261	Washer (Cylinder Head)	308	690609	Cover-Cylinder Head	869	21880	Seat-Valve (Intake)
7	692230	Gasket-Cylinder Head	337	796112s	Plug-Spark	870	691583	Seat-Valve (Exhaust)
8	495738	Breather Assembly	362	793351	Shield-Spark Plug	871	231218	Bushing-Valve Guide
8A	297704	Breather Assembly	383	89838s	Wrench-Spark Plug	989	690578	Stop Switch-Spark Plug
9	27803s	Gasket-Breather	406	690533	Spring-Breather Tube	----- <b>Note</b> -----		
9A	66214	Gasket-Breather	550	22353	Washer (Valve Cover)	298926 Stop Switch-Spark Plug (With Switch Point) Used on Type No(s). 0657, 0660, 0708, 0710, 0725, 0726, 0728, 0743, 0757, 1145, 2530, 2541, 2550.		
10	691666	Screw (Breather Assembly)	551	22795	Cover-Valve			
11	691512	Tube-Breather	552	393666	Bushing-Governor Crank			
11A	67068	Tube-Breather						
13	691441	Screw (Cylinder Head)						

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
215	291871	Guide-Air	473	692198	Screw (Rod Guide)	722	68768	Seal-Plunger
306	690399	Shield-Cylinder	621	297472s	Switch-Stop	724	93516	Retainer-Seal
307	692198	Screw (Cylinder Shield)	627		Bracket-Stopswitch <b>(NO LONGER AVAILABLE)</b>	724A	221873	Retainer-Seal
342	298125s	Plunger-Breaker						

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121


# 243400




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	391086S	Seal-Oil (Magneto Side)	27	691073	Lock-Piston Pin	571	291672	Support-Bearing
25	792361	Piston Assembly (Standard)	28	298401	Pin-Piston (Standard)			----- <b>Note</b> -----
		----- <b>Note</b> -----			----- <b>Note</b> -----			<b>394178</b> Support-Bearing
	792363	Piston Assembly (.020 Oversize)		294681	Pin-Piston (.005 Oversize)			Used on Type No(s). 0528, 0529, 0530, 0614, 0621, 0772, 0774, 0775, 0776, 0778, 0783, 0784, 0792, 0799, 0800, 1139, 1147, 1148, 1153, 1156, 1162, 1163, 1167, 1173, 2528, 2529, 2530, 2550.
26	792362	Ring Set (Standard)	29	299080	Rod-Connecting (Standard)	593A	690268	Gasket-Bearing Support (.015 Thick)
		----- <b>Note</b> -----			----- <b>Note</b> -----			----- <b>Note</b> -----
	792364	Ring Set (.020 Oversize)	30	691726	Dipper-Connecting Rod			<b>27374</b> Gasket-Bearing Support (.005 Thick)
			31	690396	Lock-Rod Screw			<b>27375</b> Gasket-Bearing Support (.009 Thick)
			32	691765	Screw (Connecting Rod)			
			228	691681	Screw (Bearing Support)			

Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121



593




228 



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION								
20	291675s	Seal-Oil (PTO Side) Used on Type No(s). 1111, 1130, 1133, 1135, 1136, 1137, 1164, 1170, 1172, 1174, 2520, 2524, 2528, 2529, 2531, 2561, 2581. ----- <b>Note</b> ----- <b>299539</b> Seal-Oil (PTO Side) Used on Type No(s). 1131, 1132, 1142, 1145, 1146, 1149, 1154, 1155, 1160, 1166, 1167, 1168, 1172, 1173, 1174, 2522, 2530. <b>691948</b> Seal-Oil (PTO Side) Used on Type No(s). 0626, 0627, 0630, 0665, 0709, 2580.	571	291710	Cover-Crankcase Used on Type No(s). 0024, 0124, 0139, 0149, 0166, 0170, 0200, 0524, 0529, 0655, 0671, 0684, 0712, 0724, 0759, 0772, 0784, 1111, 1130, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1143, 1144, 1147, 1148, 1150, 1151, 1152, 1153, 1156, 1157, 1158, 1159, 1161, 1162, 1163, 1164, 1169, 1170, 1172, 1173, 1174, 2520, 2524, 2528, 2529, 2531, 2561, 2581.	571A	291665	Support-Bearing ----- <b>Note</b> ----- <b>390054</b> Support-Bearing Used on Type No(s). 0022, 0143, 0167, 0172, 0177, 0194, 0635, 0647, 0688, 0700, 0705, 0733, 0746, 0754, 0755, 0757, 0766, 0775, 0777, 0778, 0781, 0791, 0792, 1131, 1132, 1142, 1145, 1146, 1149, 1154, 1155, 1160, 1166, 1167, 1168, 2522, 2530.	228	691681	Screw (Bearing Support)	593	691311	Gasket-Bearing Support (.015 Thick)	390114	Support-Bearing Used on Type No(s). 0173, 0174, 0185, 0190, 0198, 0525, 0527, 0530, 0615, 0622, 0631, 0636, 0641, 0659, 0664, 0669, 0670, 0674, 0676, 0677, 0678, 0686, 0687, 0689, 0697, 0699, 0704, 0707, 0715, 0716, 0717, 0718, 0720, 0721, 0729, 0732, 0734, 0735, 0739, 0743, 0748, 0761, 0763, 0765, 0769, 0770, 0771, 0776, 0779, 0782, 0785, 0793, 0794, 0795, 0796, 0801, 1131, 1132, 1142, 1145, 1146, 1149, 1154, 1155, 1160, 1166, 1167, 1168, 2522, 2530. <b>391062</b> Support-Bearing Used on Type No(s). 0626, 0627, 0630, 0665, 0709, 2580.

Engine Gasket Set-Reference 358







Carburetor Overhaul Kit-Reference 121



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	690530	Crankshaft ----- <b>Note</b> ----- <b>260887</b> Crankshaft Used on Type No(s). 0022, 0143, 0167, 0172, 0173, 0174, 0177, 0185, 0190, 0194, 0198, 0522, 0615, 0631, 0635, 0636, 0641, 0647, 0659, 0664, 0669, 0670, 0686, 0697, 0705, 0717, 0721, 0732, 0743, 0748, 0755, 0763, 0765, 0769, 0771, 0776, 0779, 0781, 0785, 0793, 0796, 1132, 1142, 1149, 1166, 1167, 1168, 2522, 2530. <b>690532</b> Crankshaft Used on Type No(s). 0626, 0627, 0630, 0665, 0709, 2580. <b>261240</b> Crankshaft Used on Type No(s). 0525, 0527, 0674, 0676, 0687, 0689, 0707, 0716, 0729, 0775, 0778, 0782, 0792, 1154, 1155.			<b>690539</b> Crankshaft Used on Type No(s). 0561, 0624, 0736, 0737, 0738, 0744, 0749, 0762, 0768, 0780, 0786, 0797, 1136, 1139, 1141, 1151, 1156, 1159, 1164, 2561. <b>261295</b> Crankshaft Used on Type No(s). 0560, 0619, 0660, 0661, 0666, 0675, 0685, 0693, 0702. <b>261421</b> Crankshaft Used on Type No(s). 0733, 0734, 0735, 0739, 0754, 0757, 0761, 0770, 0794, 0801, 1131, 1145, 1146, 1160. <b>261493</b> Crankshaft Used on Type No(s). 0746, 0766, 0777, 0791, 1154.			<b>261549</b> Crankshaft (Used After Code Date 77072400). Used on Type No(s). 1117, 1134, 1152, 1170, 1172, 2524, 2529. <b>260885</b> Crankshaft (Used Before Code Date 77072500). Used on Type No(s). 0021, 0024, 0112, 0116, 0139, 0165, 0166, 0186, 0524, 0529, 0612, 0616, 0644, 0671, 0706, 0724, 0727, 0759, 0772, 0784, 0798, 1170, 1172, 2524, 2529. Crankshaft <b>(NO LONGER AVAILABLE)</b> Used on Type No(s). 1116, 2540, 2550. <b>262021</b> Crankshaft Used on Type No(s). 2541.
	17	691938						Bearing-Ball
	24	222698s						Key-Flywheel
	357	691483						Key-Drive Pulley

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
33	394436	Valve-Exhaust	45	691594	Tappet-Valve	553	690269	Retainer-Valve Spring
34	394434	Valve-Intake	46	211335	Camshaft	591	691070	Plug-Camshaft
35	691597	Spring-Valve (Intake)	219	393720	Gear-Governor			Used on Type No(s). 1133, 1135, 1137, 1170, 1172, 1173, 1174, 2524, 2540.
36	691597	Spring-Valve (Exhaust)	219A	291192	Gear-Governor (Used Before Code Date 78062000).	626	690512	Spacer-Governor Crank
40	691939	Retainer-Valve	221	841026	Cup-Governor	900	691071	Shaft-Gear
		----- <b>Note</b> -----	225	691357	Shaft-Governor Gear			
		690274 Retainer-Valve	552	393666	Bushing-Governor Crank			
		Used on Type No(s). 2550.						
42	494553	Keeper-Valve						
		----- <b>Note</b> -----						
		68283 Keeper-Valve (Used Before Code Date 81062410).						

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121

# 243400




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
15	690946	Plug-Oil Drain (Square Head)	568	291404	Base-Engine	569	691569	Gasket-Engine Base
15A	691680	Plug-Oil Drain (Hex Socket)			<b>Note</b> -----	665	298860	Minder-Oil
21	281658s	Cap-Oil Fill			294751 Base-Engine	998	690502	Pipe-Oil
338	690270	Gasket-Dipstick Used on Type No(s). 0196, 0626, 0627, 0630, 0665, 0709, 2580.			Used on Type No(s). 0020, 0023, 0129, 0132, 0135, 0137, 0146, 0160, 0163, 0164, 0183, 0194, 0195, 0197, 0199, 0520, 0522, 0524, 0527, 0632, 0637, 0640, 0644, 0651, 0652, 0658, 0662, 0670, 0673, 0675, 0676, 0682, 0683, 0684, 0689, 0695, 0696, 0702, 0703, 0707, 0712, 0716, 0740, 0750, 0760, 0764, 1174, 2524.	998A	690307	Pipe-Oil
523	691352	Dipstick			294751 Base-Engine	1054	280275	Tie-Cable
523A	690620	Dipstick Used on Type No(s). 2580.			Used on Type No(s). 0147, 0196, 0620 0626, 0627, 0630, 0653, 0656, 0657, 0660, 0665, 0680, 0685, 0690, 0692, 0709, 0722, 0731, 0738, 0739, 0768, 0771, 0776, 1131, 1148, 1149, 1150, 1160, 2580.			
524	281370s	Seal-Dipstick Tube						
525	690624	Tube-Dipstick ----- <b>Note</b> ----- 690623 Tube-Dipstick Used on Type No(s). 1160.						
567	691104	Screw (Engine Base)						

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121






REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
91	391034	Body- Upper Carburetor ----- <b>Note</b> ----- <b>299098</b> Body- Upper Carburetor Used on Type No(s). 0010, 0131, 0137, 0150, 0152, 0165, 0201, 0510.	109	691353	Shaft-Choke			1133, 1136, 1137, 1164, 1166, 1167, 1170, 1172, 2520, 2524, 2528, 2529, 2540, 2561, 2580.
			109A	690617	Shaft-Choke Used on Type No(s). 0123, 0124, 0132, 0133, 0147, 0148, 0149, 0156, 0169, 0176, 0178, 0191, 0192, 0193, 0196, 0626, 0627, 0630, 0639, 0648, 0649, 0651, 0652, 0653, 0656, 0665, 0667, 0718, 0722, 0735, 2580.			<b>392182</b> Carburetor Used on Type No(s). 0709.
						127	690627	Plug-Welch
93	691769	Bushing-Throttle Shaft				130	691727	Valve-Throttle
94	292681	Kit-Idle Mixture				132	691708	Stop-Throttle
95	691437	Screw (Throttle Valve)				133	692265	Float-Carburetor
97	691944	Shaft-Throttle				134	394681	Kit-Needle/Seat ----- <b>Note</b> -----
101	691616	Pin-Shaft	119	691090	Screw (Upper Body to Lower Carburetor Body)			<b>394682</b> Kit- Needle/ Seat (Includes Brass Seat)
102	692215	Gasket- Carburetor Body						<b>394683</b> Kit- Needle/ Seat (Includes Brass Seat) (Use With Impulse Pump)
104	691775	Pin-Float Hinge						
107	391069	Body- Lower Carburetor	125	391073	Carburetor ----- <b>Note</b> -----			
108	690621	Valve-Choke ----- <b>Note</b> ----- <b>298730</b> Valve-Choke Used on Type No(s). 0131, 0137, 0150, 0152, 0165.			<b>391074</b> Carburetor Used on Type No(s). 0123, 0124, 0132, 0133, 0147, 0148, 0149, 0156, 0169, 0176, 0178, 0191, 0192, 0193, 0196, 0626, 0627, 0630, 0639, 0648, 0649, 0651, 0652, 0653, 0656, 0665, 0667, 0718, 0722, 0735, 1111, 1116, 1132,			<b>231</b> 691437 Screw (Choke Valve)
						689A	691591	Spring-Friction
						1149	691615	Screw (Throttle Shaft)
						1354	691929	Seal-O Ring (Lower Carburetor Body)

Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
110	691186	Washer (Choke Shaft)	142	691966	Nozzle-Carburetor (Standard) (Labeled B) (Used After Code Date 81101100).	150	691610	Gasket-Nozzle
125		Carburetor (See Previous Page)			----- <b>Note</b> ----- 390950 Nozzle-Carburetor (Standard) (Labeled B) (#40 Jet) (Used Before Code Date 81101200).	158	27590	Plug-Carburetor Filter/Drain
						689	691590	Spring-Friction Retainer-Carburetor Drain <b>(NO LONGER AVAILABLE)</b>
						800		
						1146	691587	Screw (Choke Shaft)
						1227	99525s	Valve-High Speed

Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
50	692525	Manifold-Intake ----- <b>Note</b> ----- 691152 Manifold-Intake Used on Type No(s). 0147, 0148, 0178, 0192, 0193, 0626, 0627, 0630, 0639, 0648, 0649, 0653, 0656, 0665, 0709, 0718, 0722, 0735, 2580.	163	67247	Gasket-Air Cleaner	535	270093	Filter-Air Cleaner Foam
51	692214	Gasket-Intake (Manifold to Carburetor)	166	691241	Stud (Air Cleaner) ----- <b>Note</b> ----- 231206 Stud (Air Cleaner) Used on Type No(s). 0131, 0137, 0150, 0152, 0165. 231207 Stud (Air Cleaner) Used on Type No(s). 0189. 230840 Stud (Air Cleaner) Used on Type No(s). 0123, 0176, 0196.	536	391063	Cleaner-Air ----- <b>Note</b> ----- 393858 Cleaner-Air (Air Cleaner Elbow Kit No. 545032 Supplied by Equipment Manufacturer When Using Briggs & Stratton Service Carburetor 391073) (Replaces Oil Bath) Used on Type No(s). 0122.
51A	27381s	Gasket-Intake (Manifold to Engine)	185	690284	Nut (Air Cleaner Base)	570	280001	Support-Foam Element
54	691681	Screw (Intake Manifold) ----- <b>Note</b> ----- 690953 Screw (Intake Manifold) Used on Type No(s). 0147, 0148, 0178, 0192, 0193, 0626, 0627, 0630, 0639, 0648, 0649, 0653, 0656, 0665, 0709, 0718, 0722, 0735, 2580.	412	691331	Nut (Air Cleaner Cover)	643	691730	Retainer-Air Filter
			445	393957s	Filter- Air Cleaner Cartridge	862	297749	Strap/Stud- Air Cleaner Mounting Used on Type No(s). 0122.
			467	691668	Knob-Air Cleaner	967	271794s	Filter-Pre Cleaner
						968	691755	Cover-Air Cleaner
						968A	221468	Cover-Air Cleaner

Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
162	690267	Collar-Bell Crank	211	691790	Spring-Governed Idle Used on Type No(s). 1111, 1133, 1136, 1164, 1170, 2520, 2528, 2561, 2580.	232	692207	Spring-Governor Link ----- <b>Note</b> ----- 690545 Spring-Governor Link Used on Type No(s). 0627, 0630, 0639, 0648, 0709, 2580.
203	690263	Crank-Bell	212	691595	Link-Throttle ----- <b>Note</b> ----- 691791 Link-Throttle Used on Type No(s). 0147, 0148, 0178, 0192, 0193, 0626, 0627, 0630, 0639, 0648, 0649, 0653, 0656, 0665, 0709, 0722, 2580.	404	690264	Washer (Governor Crank)
205	690810	Screw (Bell Crank)	227	690607	Lever-Governor Control ----- <b>Note</b> ----- 690616 Lever-Governor Control Used on Type No(s). 1111, 1133, 1136, 1164, 1170, 2520, 2528, 2561, 2580.	505	691251	Nut (Governor Control Lever)
206	691079	Nut-Governor Adjusting				562	92613	Bolt (Governor Control Lever)
206A	691584	Nut-Governor Adjusting				614	691620	Pin-Cotter
208	393613	Rod-Governor Control				616	291364	Crank-Governor
209	691596	Spring-Governor				668	690313	Spacer (Governor Control Rod)
209A	691789	Spring-Governor Used on Type No(s). 1111, 1133, 1136, 1164, 1170, 2520, 2528, 2561, 2580.						

Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
186	691764	Connector-Hose	245	692190	Gasket-Fuel Bowl	268	691025	Casing-Control Wire (Cut to Required Length)
186A	691609	Connector-Hose (Fuel Pump)	246	298683	Bowl-Fuel Filter	269	691026	Wire-Control (Cut to Required Length)
187	841589	Line-Fuel	247	691700	Yoke-Bowl	270	691027	Nut (Control Wire Casing)
187A	298861	Line-Fuel (Metal)	265	692179	Clamp-Casing	271	691028	Lever-Control
		----- <b>Note</b> -----	266	494554	Control-Throttle	385	692198	Screw (Fuel Pump)
		299322 Line-Fuel (Metal) (20" Long)			----- <b>Note</b> -----	387	808656	Pump-Fuel
		89248 Line-Fuel (Metal) (2 1/4" Long)			Control-Throttle Used on Type No(s). 1144.	587	690389	Pump-Cable
210	691962	Strainer-Fuel			<b>(NO LONGER AVAILABLE)</b>	601	791850	Clamp-Hose
240	690612	Filter-Fuel	267	93107	Screw (Casing Clamp)	628		Screw <b>(NO LONGER AVAILABLE)</b>
240A	298090s	Filter-Fuel	267A	690305	Screw (Casing Clamp) Used on Type No(s). 1139, 1156, 1162.	628A	691058	Screw (Fuel Pump Bracket)
		----- <b>Note</b> -----			Used on Type No(s). 1139, 1156, 1162.	628B	690661	Screw (Fuel Pump Bracket)
		394358s Filter-Fuel (White)			----- <b>Note</b> -----	629	690538	Spring-Throttle Return
241	99909	Cover-Fuel Filter (Used With Metal Fuel Line)			691044 Screw (Casing Clamp) Used on Type No(s). 0120, 0121, 0162, 0163, 0713.	788	224123	Bracket-Fuel Pump
		----- <b>Note</b> -----	267B	691082	Screw (Casing Clamp) Used on Type No(s). 1143, 1147, 1153.	788A	223610	Bracket-Fuel Pump
		Cover-Fuel Filter (Used With Flexible Fuel Line. See Reference 240)				788B	690458	Bracket-Fuel Pump
						861	791885	Kit-Fuel Pump

Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
179	690280	Screw (Fuel Tank Strap)	181	791545	Cap-Fuel Tank	199	692302	Valve-Fuel Shut Off
180	291488	Tank-Fuel (6 Quart)	182	690262	Bracket-Fuel Tank	199A	691940	Valve-Fuel Shut Off
		<b>Note</b> -----	182A	691068	Bracket-Fuel Tank	674	691058	Screw (Fuel Tank Bracket)
		290816 Tank-Fuel (4 Quart) Used on Type No(s). 0130, 0190, 0636, 0661, 0736, 0797, 1136.	183	691937	Strap-Fuel Tank	707	690279	Nut (Fuel Tank Strap)
		292415 Tank-Fuel (8 Quart) Used on Type No(s). 0125, 0140, 0154, 0157, 0179, 0187, 0644, 0654, 0657, 0660, 0679, 0686, 0689, 0697, 0707, 0720, 0731, 0732, 0749, 0750, 0758, 0760, 0765, 0768, 0773, 1131, 1137, 1138, 1141, 1150, 1168, 1173.			<b>Note</b> -----	917	691737	Handle-Shut Off Valve
			186B	231238	Connector-Hose (Used With Metal Fuel Line)			

Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION		
81	691178	Lock-Muffler Screw	303	91296	Elbow-Exhaust	725	690420	Shield-Heat		
264	691105	Nut (Muffler Adapter)			<b>Note</b> -----	728	690810	Screw (Heat Shield)		
298	691808	Locknut-Muffler/Elbow			690281	Elbow-Exhaust	823	691108	Screw (Muffler Adapter)	
300	299477s	Muffler					Used on Type No(s). 1141, 1151, 2580.	834	691075	Washer (Muffler Adapter)
300A	498984s	Muffler (Super Lo Tone)			91415	Elbow-Exhaust		864	394584	Adapter-Muffler
300B	399635	Muffler					Used on Type No(s). 0771, 0776, 1149.	864A	690637	Adapter-Muffler
300C	291519	Muffler	346	794845	Screw (Spark Arrestor) (Metric)	883	692236	Gasket-Exhaust		
301	91416	Pipe-Exhaust	346A	690661	Screw (Spark Arrestor) (SAE)	944	691690	Stud (Muffler Adapter)		
			613	691416	Screw (Muffler)	994	794945	Arrestor-Spark		
			676	795036	Deflector-Muffler					
			677	794845	Screw (Muffler Deflector) (Metric)					
			677A	690661	Screw (Muffler Deflector) (SAE)					

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23	395250	Flywheel	74	691655	Screw	440	691076	Screw
23A		Flywheel <b>(NO LONGER AVAILABLE)</b>	321	691151	Fan-Booster	726	391362	Gear-Ring (Includes Mounting Hardware)
73	690628	Screen-Rotating	331	691075	Washer (Booster Fan)	773	690265	Retainer
73A	691171	Screen-Rotating	332	691059	Nut (Flywheel)	1044	691058	Screw (Flywheel)
		----- <b>Note</b> ----- <b>690404</b> Screen-Rotating Used on Type No(s). 0627, 0630, 0665, 0709, 2580.	363	19203	Puller-Flywheel			

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121






REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	691355	Housing- Rewind Starter	60	490652	Grip- Starter Rope	65	691044	Screw (Rewind Starter)
56	392630	Pulley- Starter (Includes 63" Rope)	61	68848s	Bumper- Starter Pulley	289	230228s	Pin- Starter Grip
57	490179	Spring- Rewind Starter	63	690547	Spring- Ratchet	458	69932s	Kit- Handle/ Rope (55 1/2" Rope)
58	692188	Rope- Starter (63" Long) (Use With Plastic Pulley) 695002 Rope- Starter (99" Long) (Cut To Required Length)	64	691920	Adapter- Ratchet Spring	592	230796	Nut (Rewind Starter)
		----- <b>Note</b> -----			Adapter- Ratchet Spring <b>(NO LONGER AVAILABLE)</b> Used on Type No(s). 0561, 0624, 0733, 0734, 0735, 0736, 0737, 0738, 0739, 0744, 0746, 0749, 0754, 0757, 0761, 0762, 0766, 0768, 0770, 0797, 0801, 1131, 1136, 1139, 1141, 1145, 1146, 1151, 1154, 1156, 1159, 1160, 1164, 2541, 2561.	608	691958	Starter- Rewind
		66564 Rope- Starter (63" Long) (Use With Metal Pulley)				655	221014	Anchor- Rewind Spring
		66574 Rope- Starter (99" Long) (Cut to Required Length)				678	490817	Spacer- Rewind
						1140	690286	Washer (Rewind Starter)
						1168	93254	Screw (Starter Pulley Bumper)

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121


# 243400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
310	691614	Bolt (Starter Motor)	329	692198	Screw (Belt Guard)	574	295158	Ammeter (Stewart Warner Number 357-W)
318	690303	Screw (Mounting Bracket)	331	691075	Washer (Booster Fan)	606	221442	Strap-Adjusting (Support Bracket)
323	68878	Belt-Vee (High Position Mount) (36 3/4" Length) Used on Type No(s). 0118, 0147, 0159, 0186, 0618. ----- <b>Note</b> ----- <b>68898</b> Belt-Vee (Low Position Mount) (35 3/4" Length) Used on Type No(s). 0656, 0722. <b>280032</b> Belt-Vee (High Position Mount) Used on Type No(s). 0148, 0193.	413	691105	Nut (Starter Motor)	652	693972	Screw (Support Bracket)
			465	92268	Washer (Mounting Bracket)	652B	91468	Screw (Support Bracket)
			501		Regulator (Delco Remy Number 1119577) <b>(NO LONGER AVAILABLE)</b>	694	220863	Washer (Belt Guard)
			501A		Regulator (Delco Remy Number 1118988) <b>(NO LONGER AVAILABLE)</b>	773	690265	Retainer
						890	221472	Bracket-Support
			532	691105	Nut (Mounting Bracket)	1150	691058	Screw (Adjusting Strap)
325	299308	Pulley-Rope Starter	545	691075	Washer Set (Starter Motor)	1151	690282	Washer (Adjusting Strap)
328	221531	Guard-Belt				1151A	691075	Washer (Adjusting Strap)
						1153	90832	Washer (Support Bracket)
						1153A	691075	Washer (Support Bracket)

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
356	692390	Wire-Stop	641A	690282	Washer (Starting Switch)	945	692132	Bracket-Starter Motor
356A	398808	Wire-Stop	775	690315	Nut (Toggle Switch)	990	691959	Key Set (Used Before Code Date 81102100).
361	691681	Screw (Starting Switch)	795	496590	Switch-Toggle	1142	692329	Screw (Starter Motor Bracket) (5 3/8" Housing Length)
478	395410	Panel	795A	298590	Switch-Toggle			
575	692303	Switch-Starting	840	395408	Kit-Panel (Toggle Switch)			
577	690630	Cable-Starter			<b>Note</b>			<b>Note</b>
578	690647	Wire Assembly			395409 Kit-Panel (Key Switch) (Used Before Code Date 81102100).			690323 Screw (Starter Motor Bracket) (4 1/2" Housing Length)
578D	298582	Wire Assembly	840A	298561	Kit-Panel	1217	691075	Washer (Starting Switch)
579	691029	Nut (Starter Cable)	892	392833	Switch-Key			

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121


# 243400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
66	399671	Clutch-Starter ----- <b>Note</b> ----- <b>393127s</b> Clutch-Starter Used on Type No(s). 0561, 0624, 0733, 0734, 0735, 0736, 0737, 0738, 0739, 0744, 0746, 0749, 0754, 0757, 0761, 0762, 0766, 0768, 0770, 0797, 0801, 1131, 1136, 1139, 1141, 1145, 1146, 1151, 1154, 1156, 1159, 1160, 1164, 2541, 2561.	67	394897	Housing-Clutch ----- <b>Note</b> ----- <b>690542</b> Housing-Clutch Used on Type No(s). 0561, 0624, 0733, 0734, 0735, 0736, 0737, 0738, 0739, 0744, 0746, 0749, 0754, 0757, 0761, 0762, 0766, 0768, 0770, 0797, 0801, 1131, 1136, 1139, 1141, 1145, 1146, 1151, 1154, 1156, 1159, 1160, 1164, 2541, 2561.	257	691078	Screw (Starter Clutch)
			68	691604	Ball-Clutch	316	691612	Nut (Back Plate)
			69	690271	Washer (Starter Clutch)	325A	690261	Pulley-Rope Starter
			70	691945	Ratchet-Clutch	344	93410	Screw (Cable Clamp)
			71	691359	Cover-Ratchet	384	90832	Washer (Back Plate)
			75	691056	Washer (Flywheel)	405	690290	Screw (Back Plate)
			197	90072	Screw (Back Plate)	452A	26404	Washer (Back Plate)
						452B	92864	Washer (Back Plate)
						458	69932	Kit-Handle/Rope (55 1/2" Rope)
						573	298159	Plate-Back
						573A		Plate-Back (Used on Engines With Electric Start Only)
								<b>(NO LONGER AVAILABLE)</b>
						588	690375	Bracket-Armature
						589	690300	Screw (Armature Bracket)
						729	690432	Clip-Wire

Engine Gasket Set-Reference 358


Carburetor Overhaul Kit-Reference 121




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
304	291407	Housing-Blower ----- <b>Note</b> ----- <b>294698</b> Housing-Blower Used on Type No(s). 0118, 0121, 0123, 0124, 0140, 0147, 0148, 0149, 0159, 0176, 0178, 0184, 0186, 0189, 0192, 0193, 0200, 0618, 0626, 0627, 0630, 0639, 0642, 0648, 0649, 0655, 0665, 0692, 0700, 0709, 0773, 0800, 1150, 1162, 1163, 2580. <b>297010</b> Housing-Blower (Rewind Starter) Used on Type No(s). 0560, 0619, 0622, 0661, 0666, 0677, 0678, 0685, 0688, 0690, 0693, 0699, 0704, 0715, 0718, 0720.			<b>297453</b> Housing-Blower Used on Type No(s). 0023, 0129, 0132, 0135, 0137, 0146, 0160, 0163, 0164, 0183, 0194, 0199, 0523, 0527, 0632, 0637, 0640, 0652, 0653, 0656, 0662, 0670, 0676, 0680, 0682, 0683, 0695, 0703, 0712, 0716, 0722, 0750, 0760. <b>297766</b> Housing-Blower Used on Type No(s). 0020, 0195, 0197, 0524, 0644, 0651, 0657, 0673, 0684, 0689, 0696, 0707, 0764, 2524.			<b>391229</b> Housing-Blower (Electric Start) Used on Type No(s). 0528, 0614, 0621, 0772, 0774, 0775, 0783, 1147, 1148, 1153, 1155, 1167, 2528, 2529, 2530, 2550. <b>392343</b> Housing-Blower Used on Type No(s). 0561, 0624, 0733, 0734, 0735, 0736, 0737, 0738, 0739, 0740, 0744, 0746, 0749, 0754, 0757, 0761, 0762, 0766, 0768, 0770, 0777, 0780, 0786, 0791, 0794, 0801, 1131, 1136, 1139, 1141, 1145, 1146, 1151, 1154, 1156, 1159, 1160, 1164, 2541, 2561.
						305	692198	Screw (Blower-Housing)
						895	692309	Switch-Rotary

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121




USED BEFORE CODE DATE: 81080100



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
333	398811	Armature-Magneto (Used After Code Date 81073100). ----- <b>Note</b> ----- 298968 Armature-Magneto (Used Before Code Date 81080100).	470	692836	Screw (Breaker Cover)	714	691612	Nut (Stop Wire)
334	691061	Screw (Magneto Armature)	484	690295	Screw (Condenser)	729A	690588	Clip-Wire
340	26018	Spring-Breaker Arm	507	690584	Insulator	744	690277	Washer (Breaker Cover)
343	298060	Condenser	507A	66895	Insulator ----- <b>Note</b> ----- 299598 Insulator Used on Type No(s). 0168, 0175, 0179, 0628, 0629.	851	493880s	Terminal-Spark Plug
345		Cover-Breaker <b>(NO LONGER AVAILABLE)</b>	521	291508	Shield-Cable	888	690292	Screw (Insulator)
356B	690650	Wire-Stop	639	692913	Gasket-Breaker Box	888A	90200	Screw (Insulator)
359	691077	Washer (Ground Terminal)				888B	690295	Screw (Insulator)
375	298185	Breaker-Ignition				897	394970	Kit-MAGNETRON® Ignition

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121




DC ONLY	AC ONLY	DUAL CIRCUIT	10/16 AMP
<p>474</p> <p>877</p> <p>1059</p>	<p>474A</p> <p>877</p> <p>1059</p>	<p>474B</p> <p>877A</p> <p>1059</p>	<p>474C</p> <p>877A</p> <p>1059</p>
<p>578A</p>	<p>578B</p>	<p>789</p>	



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
474	696578	Alternator (DC Only)	501B	691185	Regulator	1059	698516	Kit-Screw/Washer (Alternator)
474A	391595	Alternator (AC Only)	526	690297	Screw (Regulator)	1119	691183	Screw (Alternator)
474B	696459	Alternator (Dual Circuit)	578A	692306	Wire Assembly			
474C	696458	Alternator (10/16 Amp)	578B	390867	Wire Assembly			
			789	398661	Harness-Wiring			
			877	393814	Wire/Connector-Alternator (DC Only)			
			877A	393456	Wire/Connector-Alternator (Dual Circuit)			
			877B	399916	Wire/Connector-Alternator (Tri-Circuit)			

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
20A	299819s	Seal-Oil (PTO Side)	85	691076	Screw (Gear Cover To Gear Reduction Case)	272	690391	Lock-Screw Head (Gear Reduction Case)
79		Case-Gear Reduction <b>(NO LONGER AVAILABLE)</b>	86	690606	Cover-Gear	277	691075	Washer (Gear Case To Gear Reduction)
82	691058	Screw (Gear Reduction Case)	87	391086s	Seal-Gear Reduction	415	794903	Plug (Gear Cover)
83	690387	Shaft-Auxiliary Drive	88	691601	Gasket-Gear Reduction Cover			

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	396306	Motor-Starter (4 3/8" Housing Length)	668A	396515	Spacer (Starter Motor)	801		Cap-Drive (4 3/8" Housing Length) <b>(NO LONGER AVAILABLE)</b>
310B	691263	Bolt (Starter Motor)	675	691261	Washer (Brush Retainer)	802	691286	Cap-End
311	497608	Brush Set	697	691058	Screw (Drive Cap)	803		Housing-Starter (Serviced With 396306 Starter Motor Only)
510	696541	Drive-Starter	727	692338	Cover-Starter Drive (Starter Drive Cover)	1051	691265	Ring-Retaining
513	692024	Clutch-Drive	732	93410	Screw (Starter Drive Cover)	1090	691293	Retainer-Brush
544		Armature-Starter (Serviced By 396306 Starter Motor Only)	783	695708	Gear-Pinion			
			797	691029	Nut (Brush Retainer)			

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121



# 243400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>309A</b>		Motor-Starter (For Replacement Starter Motor, See Reference 309, Previous Page)	<b>442</b>	<b>691693</b>	Screw (Starter Strap)	<b>773A</b>	<b>391462</b>	Retainer
			<b>503</b>	<b>690406</b>	Strap-Starter	<b>783</b>	<b>695708</b>	Gear-Pinion
			<b>510A</b>	<b>696540</b>	Drive-Starter (4 3/8" Housing Length)	<b>801</b>		Cap-Drive (4 3/8" Housing Length) <b>(NO LONGER AVAILABLE)</b>
<b>310A</b>	<b>692329</b>	Bolt (Starter Motor) (5 3/8" Housing Length)	<b>510B</b>	<b>696535</b>	Drive-Starter (3 3/4" Housing Length)			----- <b>Note</b> ----- <b>394859</b> Cap-Drive (3 3/4" Housing Length)
<b>311A</b>	<b>395538</b>	Brush Set (4 3/8" Housing Length)	<b>513</b>	<b>692024</b>	Clutch-Drive	<b>802A</b>	<b>395537</b>	Cap-End
		----- <b>Note</b> ----- <b>391705</b> Brush Set (3 3/4" Housing Length)	<b>544A</b>		Armature-Starter <b>(NO LONGER AVAILABLE)</b>	<b>803A</b>	<b>494205</b>	Housing-Starter
			<b>697</b>	<b>691058</b>	Screw (Drive Cap)	<b>876</b>	<b>696539</b>	Kit-Pinion Spring
						<b>896</b>	<b>691641</b>	Pin-Drive Retainer (Copper)
						<b>896A</b>	<b>94192</b>	Pin-Drive Retainer (Black)

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
7	692230	Gasket-Cylinder Head	127	690627	Plug-Welch	524	281370s	Seal-Dipstick Tube
9	27803s	Gasket-Breather	134	394681	Kit-Needle/Seat	550	22353	Washer (Valve Cover)
9A	66214	Gasket-Breather	142	691966	Nozzle-Carburetor (Standard) (Labeled B) (Used After Code Date 81101100).	569	691569	Gasket-Engine Base
20	291675s	Seal-Oil (PTO Side)				593	691311	Gasket-Bearing Support (.015 Thick)
20A	299819s	Seal-Oil (PTO Side)				593A	690268	Gasket-Bearing Support (.015 Thick) ----- <b>Note</b> -----
51	692214	Gasket-Intake						27374 Gasket- Bearing Support (.005 Thick)
51A	27381s	Gasket-Intake						27375 Gasket- Bearing Support (.009 Thick)
87	391086s	Seal-Gear Reduction						639 692913 Gasket-Breaker Box
94	292681	Kit-Idle Mixture						883 692236 Gasket-Exhaust
102	692215	Gasket-Carburetor Body						1227 99525 Valve-High Speed
104	691775	Pin-Float Hinge	150	691610	Gasket-Nozzle			
121	394989	Kit- Carburetor Overhaul (Used After Code Date 81101100). ----- <b>Note</b> ----- 391071 Kit- Carburetor Overhaul (Used Before Code Date 81101200).	245	692190	Gasket-Fuel Bowl			
			358	299101	Gasket Set-Engine			

Engine Gasket Set-Reference 358

Carburetor Overhaul Kit-Reference 121