

3.5 MM SHUTTER RELEASE CABLES

CABLE COMPATIBILITY INFORMATION



This chart provides a list of 3.5 mm shutter release cables from Vello and the camera models they are compatible with.

These shutter release cables enable you to use a remote to trigger your camera's shutter. The 3.5 mm end of the cable plugs into the remote, and the other end plugs into your camera. Your remote can work with many different camera models as long as you match it to the correct cable.

The cables in this chart are compatible with remotes that contain a 3.5 mm output socket. If your remote contains a 2.5 mm socket, refer to our compatibility chart for 2.5 mm shutter release cables.

For additional cables and camera models, visit:

www.vellogear.com

Cable Model #	Cable Compatibility
RCC-C1-3.5 	Canon Rebel: Digital Rebel / XT / XTi / XS / XSi / T1i / T2i / T3 / T3i / T4i / T5 / T5i / T6i / T6s / SL1 / EOS 60D / EOS 60Da / EOS 70D PowerShot: G10 / G11 / G12 / G15 / G16 / G1 X / G1 X II / G3 X / G5 X / SX50 HS / SX60 HS Contax N/645 Pentax *Ist D / *Ist DL / *Ist DS / *Ist DS2 / *Ist DL2 / K100D / K110D / K200D / K-500 / K10D / K20D / K-30 / K-50 / K-7 / K-5 / K-5II / K-5 IIs / K-3 / K3II Samsung GX-1S / GX-1L / GX-10 / GX-20 / NX-10 / NX-100 Sigma SD1 Hasselblad H series
RCC-C2-3.5 	Canon EOS 10D / EOS 20D / EOS 30D / EOS 40D / EOS 50D / EOS 5D / EOS 5D Mark II / EOS 5D Mark III / EOS 5DS / EOS 5DS R / EOS 6D / EOS 7D / EOS 7D Mark II / EOS 1D / EOS 1Ds / EOS 1D Mark II / EOS 1Ds Mark II / EOS 1D Mark II N / EOS 1D Mark III / EOS 1Ds Mark III / EOS 1D Mark IV / EOS 1D X / EOS 1D C
RCC-N1-3.5 	Nikon D1 / D1H / D1X / D2 / D2H / D2Hs / D2x / D2Xs / D3 / D3s / D3x / D4 / D4s / D200 / 300 / 300s / D700 / D800 / D800e / D810 / D810A Fujifilm S3 Pro / S5 Pro Kodak DCS-14N
RCC-N2-3.5 	Nikon D3100 / D3200 / D3300 / D5000 / D5100 / D5200 / D5300 / D5500 / D90 / D7000 / D7100 / D7200 / D600 / D610 / D750 / Df / Nikon 1 V3 / Coolpix: P7700 / P7800 / Coolpix A

Cable Model #	Cable Compatibility
RCC-N3-3.5 	Nikon D70s / D80
RCC-O2-3.5 	Olympus E-1 / E-3 / E-5
RCC-O3-3.5 	Olympus E400 / E410 / E420 / E450 / E510 / E520 / E620 / SP-510UZ / SP-550UZ / SP-560UZ / SP-570UZ / Pen E-P2 / Pen E-P3 / Pen E-P5 / Pen E-PL2 / E-PL5 / Pen E-PL6 / Pen E-PL7 / Stylus 1 / Pen E-PM1 / XZ-1 / OM-D E-M1 / OM-D E-M5 / OM-D E-M5 II / OM-D E-M10 / OM-D E-M10 II
RCC-P1-3.5 	Panasonic DMC-G1 / DMC-G2 / DMC-G3 / DMC-G5 / DMC-G6 / DMC-G7 / DMC-G10 / DMC-GF1 / DMC-GH1 / DMC-GH2 / DMC-GH3 / DMC-GH4 / DMC-GX1 / DMC-GX7 / DMC-GX8 / DMC-L1 / DMC-L10 / DMC-FZ100 / DMC-FZ150 / DMC-FZ200 / DMC-FZ300 Leica V-Lux 4
RCC-S1-3.5 	Sony Alpha: a100 / a200 / a300 / a350 / a500 / a550 / a560 / a580 / a700 / a850 / a900 / SLT a33 / SLT a35 / SLT a37 / SLT a55 / SLT a57 / SLT a65 / SLT a67 / SLT a77 / a77 II / SLT a99 Minolta 5D / 7 / 7D / 7i / A1 / A2
RCC-S2-3.5 	Sony Alpha: a7 / a7II / a7R / a7RII / a7S / a7S II / a3000 / a5000 / a5100 / a6000 / a77II / a58 Cyber-shot: DSC-RX1 / DSC-RX1R / RX1R II / DSC-RX10 / DSC-RX10 II / DSC-RX100 II / DSC-RX100 III / DSC-RX100 IV / HX300 / HX400 / HX400V / HX50V / HX90V

Vello is a registered trademark of the Gradus Group.
All other trademarks are the property of their respective
owners.

© 2015 Gradus Group LLC. All Rights Reserved. GG12