

## AC-208 Universal Air Conditioner Remote Control

### Model Setting of Remote Control

1. Gently pull side cover of remote control down past the reset button to expose the battery compartment. Install 2 AAA batteries as per polar indicated on battery cabin.
2. Find the model code from Model Code List. If there are more than one numbers for one brand, you will have to try each one until you find the correct code. e.g., for SANYO, try model codes O35 to O39 starting with 35.
3. Press the SET keyhole gently with the end of a bent paper clip, MODEL code on LCD will flash, then press the + CODE SEL key to your selected code number. You can hold the key down for faster access. Once your desired number appears press the ENTER key, the MODEL code stops flashing. Aim the remote at the air conditioner by pressing ON/OFF key. If the AC turns on your remote is ready to use. If not, try the next number.

### Remote Control Auto Search

If you do not know model of air conditioner and/or remote control or you cannot find required model from Model Code List, please operate as per the following steps:

1. Press the SET keyhole gently with the end of a bent paper clip, model code on LCD will flash. Aim the remote control at air conditioner. Press the AUTO search key once, model code adds 1 automatically and emit corresponding ON/OFF signal. Press and release until air conditioner receives signal and

## AC-208 Universal Air Conditioner Remote Control

produces buzzer sound. Then press ENTER key.

2. After turning on the air conditioner, try other function key .If they do not work, repeat above steps until it is correct.

### Attention

1. *You will have to set the model number again if you remove the batteries.*

Therefore check the code on the remote for quick and easy change over and code setting. If it is not used for a long time, remove the battery to prevent possible battery leakage. When the LCD looks dim, change the batteries (do not mix new and old batteries)

2. If abnormal situation appears because of incorrect use, please put pen tip or other thin item into "Reset" hole. Press it to restore to original factory settings. It is necessary to set model code again.
3. The manufacturer keeps the right to change the parameter and function of the product.

### Technical Parameters

Controllable distance: Large than 8 meters

Power supply voltage: DC 3V

Battery Battery AAA(UM-4.R03)\*2

Dimension: L 160mm W 58mm D18mm

Weight: Approx.95g (excl.the batteries)