

alcatel TETRA



Let's Get Started




AT&T Eco Rating 2.0 only applies to Alcatel TETRA™. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

Alcatel is a trademark of Nokia used under license by TCL Communication LTD. TETRA is a trademark of TCL Communication LTD. © 2018 TCT Mobile Limited. All rights reserved. 2018 AT&T Intellectual Property. All rights reserved. LTE is a trademark of ETSI. 4G LTE not avail. everywhere. Contains Lithium ion battery - recycle or dispose of properly. ©2018 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.

Surf & Stream in no time


Connect to Wi-Fi Network

1. From the home screen, **Swipe up on Home screen > Settings > Network & internet > Wi-Fi.**
2. Tap to turn **Wi-Fi** on.
3. Tap a network name. Enter a password if required > **CONNECT.**



Connect to a Bluetooth® Headset

1. From the home screen, **Swipe up on Home screen > Settings > Connected devices > Bluetooth.**
2. Tap to turn **Bluetooth** on.
3. Tap **Pair new device** to display a list of available devices.
4. Tap the name of the device to initiate pairing.



Data rates may apply. The Bluetooth word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such by TCL Communication Ltd. is under license.

What else is in the box?

- Alcatel TETRA™
- Lithium ion battery
- USB cable
- Wall charger
- Pre-installed SIM card
- Safety and warranty information

Useful Apps *



AT&T Visual Voicemail

Review and manage your voicemail from your phone.



DriveMode

Silence notifications, set an auto-reply so people will know you are driving, and more.



myAT&T

Managing your account, track your usage, review and pay your bill, and update your data plan service.



AT&T Smart Wi-Fi

Helps you make your data plan last longer. Remembers and connects to your favorite hotspots and finds more Wi-Fi options when you're on the go.




AT&T Smart Limits

Set up text alerts to switch to Wi-Fi and allows you to manage your kids' phone usage.

Find More Information

Manage Your Account with myAT&T

- On your phone: **Swipe up on Home screen >** 
- On the web: att.com/myATT

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need More Help?

- On the web: att.com/DeviceHowTo

Give us a call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878

*Compatible device and subscription may be required
Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to <https://att.com/shop/apps>.



Need more help?

On the web: att.com/DeviceHowTo


Call Family & Friends

Make a Call

1. From the home screen, tap
2. Tap , then enter the desired number from the keyboard directly or select a contact from **FAVORITES** , **CONTACTS** , or **RECENT** by sliding or touching tabs, then tap to place the call.

Check Voicemail

1. From the home screen, tap
2. Tap to open dialpad and long press
3. Follow voice prompts to listen to messages.



Call Waiting

Call waiting allows you to answer a second call while you are on an existing call. While on a call, you will hear a tone if another call comes in.

- Tap to answer first call. Tap again to answer second call.
- Tap to switch between active calls.
- Tap to merge calls.
- Tap to end a call.

Capture Life's Moments

Take a Picture


1. From the Home screen, Tap **Camera**.
2. Tap to take a picture.

Record a Video

1. From the Home screen, Tap **Camera** > **Video**.
2. Tap to start/stop recording.

Share a Picture or Video


1. From the Home screen, Tap **Gallery**.
2. Select a photo or video, Tap to send the picture or video.



Let's Setup Your Phone

Install a SIM/microSD Card*

1. Remove back cover by gently pulling up on the indentation on the bottom left of the cover.
2. Insert the SIM card and microSD cards as shown in the illustration below. (NOTE: SIM slot is located above the microSD slot.)
3. Ensure that the SIM and microSD cards have been properly secured.



Turn on your new phone

- Place the back cover on your phone and press around all sides to securely snap back into place.
- Press and hold Power/Lock key until the device turns on.

Messaging & Email

Email setup (Gmail™, Yahoo®, etc.)

1. From the Home screen, tap Email .
2. Enter your email address, tap **NEXT**, enter your password, tap **NEXT**.
3. Confirm email account settings, tap **NEXT**.
4. Enter your name which will be displayed on outgoing emails, tap **FINISH**.


Text and Picture Messaging

1. From the Home screen, tap **Messaging** .
2. Tap to begin a new message.
3. In the To field, enter a number or a contact name, or tap **Contacts** to select a contact from the address book.
4. Tap the "**Type message**" field and enter your text.
5. To send an attachment, tap the paper clip icon to select the attachment.
6. Tap the **SMS** or **MMS** to send the message..

Easily Adjust Settings


Settings Menu

Swipe up on Home screen > **Settings**



Quick Settings

Tap the top of the home screen and drag your finger down to view the Notifications panel. With the Notifications panel open, drag your finger down again to see the Quick Settings menu.



*microSD Card sold separately