

# BTR-300 — Standard Frequency Ordering Information

## BTR-300 FREQUENCY GROUPS BASE STATION TO PORTABLE TRANSCEIVER CONFIGURATION (Show in five compatible groups but may be purchased separately)

CHANNEL GROUP	TRANSMIT	RECEIVE 1	RECEIVE 2	RECEIVE 3	RECEIVE 4
7-10A	174.150	193.950	193.475	192.950	192.150
7-10B	174.575	197.925	197.450	196.925	196.125
7-12A	177.125	205.925	205.450	204.925	204.125
7-12B	174.875	209.950	209.475	208.950	208.150
7-11A	174.350	199.950	199.475	198.950	198.150
7-11B	174.525	203.925	203.450	202.925	202.125
7-13A	179.725	211.950	211.475	210.950	210.150
7-13B	177.375	215.925	215.450	214.925	214.125
8-11A	180.275	199.950	199.475	198.950	198.150
8-11B	180.100	203.925	203.450	202.925	202.125
8-13A	182.550	211.950	211.475	210.950	210.150
8-13B	183.125	215.925	215.450	214.925	214.125
8-12A	182.000	205.925	205.450	204.925	204.125
8-12B	180.600	209.950	209.475	208.950	208.150
9-12A	186.100	205.925	205.450	204.925	204.125
9-12B	186.275	209.950	209.475	208.950	208.150
9-13A	191.550	211.950	211.475	210.950	210.150
9-13B	186.825	215.925	215.450	214.925	214.125
NOTE: The following traveling groups may be used alone or in place of any of the above frequency groups, but may not be used together.					
Traveling Group A	154.570	171.905	171.045	170.245	169.505
Traveling Group B	154.600	169.445	170.305	171.105	171.845

Note: When placing orders for the BTR-300, use the standard part number followed by the "Channel Group" number shown above in the left column. For "Travelling Groups," replace the "Channel Group" number (7-10A) with TRVA or TRVB.

For example: 71276-XXXX would be "71276710A" (BTR-300 on Channel Group 7-10A).

Note: When placing orders for the TR-300, use the standard part number followed by the "Channel Group" number shown above in the left column, then the "Receive" number (1, 2, 3, or 4) shown in the columns to the right. The "Receive" frequencies are with respect to the base and are, in fact, the belt-pack transmit frequencies. For "Travelling Groups," replace the "Channel Group" number (7-10A) with TRVA or TRVB followed by the "Receive" number (1, 2, 3, or 4).

For example: 7127-XXXXX would be "7127710A1" (TR-300 on Channel Group 7-10A, #1 Transmitter).

## PORTABLE TO PORTABLE CONFIGURATION (mirror image pairs)

MODEL	TRANSMIT	RECEIVE	ORDER BY CATALOG NO.	MODEL	TRANSMIT	RECEIVE	ORDER BY CATALOG NO.
<b>Channel 7-12 A Group</b>				<b>Channel 8-13 A Group</b>			
TR-300	205.925	177.125	7127M712	TR-300	211.950	182.550	7127M813
TR-300	177.125	205.925	7127M127	TR-300	182.550	211.950	7127M138
<b>Channel 7-13 A Group</b>				<b>Traveling A Group</b>			
TR-300	211.950	179.725	7127M713	TR-300	171.905	154.570	7127MTVA
TR-300	179.725	211.950	7127M137	TR-300	154.570	171.905	7127MAVT
<b>Channel 8-12 A Group</b>				<b>Note: Mirror image portables are not compatible with BTR-300 base stations</b>			
TR-300	205.925	182.000	7127M812				
TR-300	182.000	205.925	7127M128				