

## DC4000 Clearing the E-Prom

1. Press and hold SPEED UP and ELEVATION DOWN until **“FACTORY SETUP”** appears. Release buttons.
2. Press and hold SPEED UP and ELEVATION DOWN again until **“TEST MODE”** appears. Release buttons.
3. Press and hold SPEED UP and ELEVATION DOWN again until **“UPDATING”** appears. Release buttons.
4. **“UNDEFINED”** will appear in the TOP window.
5. Follow DC4000 Software Set Up procedure.