

BRAND	MODEL	LCM
ACCESS	Virus KC	140
ACCESS	Virus TI Desktop	70
ACCESS	Virus TI Keyboard	150
ACCESS	Virus TI Polar	100
ACCESS	Virus TI Snow	50
AKAI	ADVANCE 61	130
AKAI	ADVANCE 49	110
AKAI	ADVANCE 25	90
AKAI	APC Key 25	50
AKAI	AX73	0
AKAI	MAX25	80
AKAI	MAX49	110
AKAI	MINIAK	100
AKAI	MPK Mini	50
AKAI	MPK Mini MkII	50
AKAI	MPK225	90
AKAI	MPK249	110
AKAI	MPK25	90
AKAI	MPK261	130
AKAI	MPK49	110
AKAI	MPK61	130
AKAI	MPK88	180
ALESIS	Andromeda	160
ALESIS	Micron	80
ALESIS	Q25	70
ALESIS	Q49	100
ALESIS	Q61	130
ALESIS	Q88	170
ALESIS	QS8.1	170
ALESIS	QX25	90
ALESIS	QX49	110
ALESIS	QX61	130
ALESIS	V25	110
ALESIS	V49	130
ALESIS	V61	150
ALESIS	VI25	110
ALESIS	VI49	140
ALESIS	VI61	150
ALESIS	VORTEX	120
ALESIS	VORTEX Wireless	120
BEHRINGER	U-CONTROL UMA25S	70
BEHRINGER	U-CONTROL UMX25	80
BEHRINGER	U-CONTROL UMX250	80
BEHRINGER	U-CONTROL UMX49	110
BEHRINGER	U-CONTROL UMX490	110
BEHRINGER	U-CONTROL UMX610	130
CASIO	AT1	140
CASIO	AT-3	190
CASIO	CDP100	170

BRAND	MODEL	LCM
NOVATION	x station 61	130
NOVATION	xio 25	70
NOVATION	xio 49	110
NOVATION	Bass Station 2	80
NOVATION	IMPULSE 25	100
NOVATION	IMPULSE 49	130
NOVATION	IMPULSE 61	150
NOVATION	Launch Key 25	80
NOVATION	Launch Key 49	110
NOVATION	Launch Key 61	130
NOVATION	Launch Key Mini	50
NOVATION	MiniNova	90
NOVATION	Ultra Nova	130
NOVATION	X STATION 25	80
NOVATION	X STATION 48	110
NOVATION	X STATION 61	130
NOVATION	ZERO SL mk2	70
OPEN LABS	MiKo LXD	150
OPEN LABS	MiKo QC6	150
OPEN LABS	NeKo QX6	190
OPEN LABS	NeKo XXL	190
RHODES	mk-60	170
RHODES	Mk7 73	180
RHODES	mk-80	210
ROLAND	A30	160
ROLAND	A33	150
ROLAND	a37	160
ROLAND	A300PRO	90
ROLAND	A49	110
ROLAND	A500PRO	120
ROLAND	a70	170
ROLAND	A800PRO	130
ROLAND	A88	180
ROLAND	A-90	200
ROLAND	A90 EX	200
ROLAND	ATELIER Combo AT-350C	200
ROLAND	AX synth [remote]	150
ROLAND	ax1	130
ROLAND	AX7	130
ROLAND	AX9 LUCINA	120
ROLAND	BK-3	150
ROLAND	BK-5	150
ROLAND	BK-5 OR	150
ROLAND	BK-9	170
ROLAND	D15	120
ROLAND	D50	140
ROLAND	D70	160
ROLAND	DISCOVER 5	170
ROLAND	E09	150

CASIO	CDP200r	170
CASIO	CTK2000	140
CASIO	CTK220	0
CASIO	CTK230	130
CASIO	CTK2400	130
CASIO	CTK3000	140
CASIO	CTK3200	130
CASIO	CTK4000	150
CASIO	CTK401	0
CASIO	CTK4400	140
CASIO	CTK480	0
CASIO	CTK496	140
CASIO	CTK5000	150
CASIO	CTK6200	150
CASIO	CTK6250	150
CASIO	CTK651	150
CASIO	CTK671	150
CASIO	CTK700	140
CASIO	CTK7200	150
CASIO	CTK731	150
CASIO	CTK810	150
CASIO	CTK810n	150
CASIO	CTK811EX	170
CASIO	LK120	130
CASIO	LK165	170
CASIO	LK175	150
CASIO	LK240	130
CASIO	LK260	130
CASIO	LK280	140
CASIO	MZ2000	180
CASIO	Privia PX-410R	180
CASIO	PS20	180
CASIO	PX-160	180
CASIO	PX-360	180
CASIO	PX-560	180
CASIO	PXA-100	170
CASIO	PX-150	170
CASIO	PX300	170
CASIO	PX-350	170
CASIO	SA76	110
CASIO	WK110	170
CASIO	WK110	170
CASIO	WK1600	180
CASIO	WK1800	180
CASIO	WK200	170
CASIO	WK210	170
CASIO	WK2100	140
CASIO	WK225	200
CASIO	WK245	190
CASIO	WK3300	180

ROLAND	E50	170
ROLAND	E500	170
ROLAND	E60	200
ROLAND	E600	170
ROLAND	E66	150
ROLAND	E70	170
ROLAND	E80	190
ROLAND	E96	170
ROLAND	EA7	150
ROLAND	EM09	150
ROLAND	em10	140
ROLAND	em15	140
ROLAND	em25	140
ROLAND	em55	160
ROLAND	ep70	160
ROLAND	ep75	180
ROLAND	EP760	170
ROLAND	EP77	160
ROLAND	ep85	180
ROLAND	ep95	180
ROLAND	EP97	180
ROLAND	exr-3	150
ROLAND	exr-5	150
ROLAND	exr-7	180
ROLAND	exr-7s 76 keys	180
ROLAND	FA-06	140
ROLAND	FA-08	190
ROLAND	fantom	180
ROLAND	fantom FA76	180
ROLAND	fantom G6	160
ROLAND	fantom G7	180
ROLAND	fantom G8	210
ROLAND	fantom s	150
ROLAND	fantom s88	200
ROLAND	FANTOM X6	150
ROLAND	fantom x6	150
ROLAND	fantom x6	150
ROLAND	FANTOM X7	170
ROLAND	fantom x7	170
ROLAND	fantom x7	170
ROLAND	FANTOM X8	200
ROLAND	fantom x8	200
ROLAND	fantom x8	200
ROLAND	fantom xa	150
ROLAND	fantom xr	150
ROLAND	FP1	180
ROLAND	fp2	170
ROLAND	FP2 88 note	170
ROLAND	fp3	170
ROLAND	FP4	180

CASIO	WK3800	180
CASIO	WK500-F5	170
CASIO	WK6600	170
CASIO	WK7600	170
CASIO	WK8000	200
CASIO	XW-G1	160
CASIO	XW-P1	160
CME	UF70	170
EMU	LONGboard 61	140
EMU	SHORTboard 49	120
ENSONIQ	MIRAGE	140
ENSONIQ	TS10	150
ENSONIQ	TS12	180
GEM	Equinox 88 Pro	210
GEM	GENESYS	180
GEM	GENESYS PRO	170
GEM	GK340	140
GEM	PROMEGA	200
GEM	PROMEGA 2	180
GEM	WK1	150
GEM	WK1000	150
GEM	WK2000	160
GEM	WK8 SE	160
HAMMOND	SK1	130
HAMMOND	SK1-73	150
HAMMOND	SK1-88	170
HAMMOND	SK2	160
HAMMOND	XB1	160
HAMMOND	XB2	160
HAMMOND	XE1	180
HAMMOND	XE2	140
HAMMOND	XK1	160
HAMMOND	XK-1C	140
HAMMOND	XK2	170
HAMMOND	XK3	170
HAMMOND	XK3C	170
HAMMOND	XK-3C	170
HAMMOND	XLK3	190
KAWAI	CA-X	200
KAWAI	ES1	180
KAWAI	ES-100	170
KAWAI	ES3	180
KAWAI	ES4	180
KAWAI	ES6	180
KAWAI	ES-7	190
KAWAI	ES8	180
KAWAI	ESX	180
KAWAI	K5000W	150
KAWAI	MP10	200
KAWAI	MP11	200

ROLAND	FP-50	180
ROLAND	fp7	190
ROLAND	fp7F	190
ROLAND	FP8	180
ROLAND	FP-80	190
ROLAND	FP9	180
ROLAND	G1000	180
ROLAND	G70	190
ROLAND	G800	180
ROLAND	GAIA SH-01	110
ROLAND	GAIA SH101	110
ROLAND	gw7	150
ROLAND	gw8	150
ROLAND	JD800	160
ROLAND	JD-XA	140
ROLAND	JD-X1	90
ROLAND	JP8000	140
ROLAND	JUNO 106	140
ROLAND	JUNO 6/60	160
ROLAND	JUNO stage	170
ROLAND	JUNO-d	140
ROLAND	JUNO-di	140
ROLAND	JUNO-Di	140
ROLAND	JUNO-g	140
ROLAND	JUNO-Gi	140
ROLAND	JUNO-Gi	140
ROLAND	JUNO-STAGE	170
ROLAND	JUPITER 50	170
ROLAND	JUPITER 6	160
ROLAND	JUPITER 80	180
ROLAND	JV30	130
ROLAND	JV35	140
ROLAND	JV50	140
ROLAND	JV80	140
ROLAND	JV90	160
ROLAND	JX305	140
ROLAND	kf90	190
ROLAND	LUCINA AX-09	120
ROLAND	p2f	170
ROLAND	PRELUDE	150
ROLAND	rd100	180
ROLAND	rd150	180
ROLAND	rd170	180
ROLAND	rd200	170
ROLAND	rd300GX	190
ROLAND	RD300NX	190
ROLAND	RD300SX	190
ROLAND	RD500	190
ROLAND	rd600	200
ROLAND	RD-64	150

KAWAI	MP6	190	ROLAND	rd700	190
KAWAI	MP7	190	ROLAND	rd700GX	200
KAWAI	MP8	210	ROLAND	rd700GXF	200
KAWAI	MP9500	210	ROLAND	rd700nX	200
KAWAI	X130	130	ROLAND	rd700SX	190
KAWAI	X30	130	ROLAND	RD800	190
KAWAI	X50D	120	ROLAND	rolandFP5	180
KORG	CX3	160	ROLAND	rs5	140
KORG	I1	220	ROLAND	rs50	140
KORG	I2	180	ROLAND	rs70	140
KORG	I3	160	ROLAND	rs9	180
KORG	I30	160	ROLAND	S50	150
KORG	I4S	170	ROLAND	s88	200
KORG	I5S	150	ROLAND	SH101 GAIA	110
KORG	IS40	160	ROLAND	SH101 ORIGINAL	100
KORG	IS50	160	ROLAND	SH-201	130
KORG	IX300	150	ROLAND	System-1	80
KORG	Karma	150	ROLAND	V PIANO	210
KORG	KingKORG	140	ROLAND	V SYNTH	160
KORG	Kontrol 49	110	ROLAND	V SYNTH gt	160
KORG	Krome 61	140	ROLAND	V SYNTH v2	160
KORG	Krome 88	200	ROLAND	va3	160
KORG	Kronos 61	150	ROLAND	va5	180
KORG	Kronos 73	170	ROLAND	va7	180
KORG	Kronos 88	200	ROLAND	VA76	180
KORG	Kronos X 61	150	ROLAND	va76	180
KORG	Kronos X 73	180	ROLAND	V-Combo VR-09	140
KORG	Kronos X 88	200	ROLAND	V-Combo VR700	180
KORG	Kross 61	130	ROLAND	VK7	160
KORG	Kross 88	200	ROLAND	VK8	160
KORG	M1	160	ROLAND	vp770	140
KORG	M3xp-61 note	150	ROLAND	vp770	130
KORG	M3xp-73 note	170	ROLAND	VP-770	140
KORG	M3xp-88 note	200	ROLAND	Vr760	180
KORG	M50-61 note	140	ROLAND	XP10	140
KORG	M50-73 note	160	ROLAND	XP30	140
KORG	M50-88 note	190	ROLAND	XP50	150
KORG	MICRO KORG	80	ROLAND	XP60	150
KORG	MICRO STATION	110	ROLAND	XP80	170
KORG	microKORG XL+	90	ROLAND	XV88	200
KORG	MICROSTATION XL	90	ROLAND	EP760	170
KORG	Monopoly	130	ROLAND	EP77	160
KORG	MS-20 Mini	100	ROLAND	VCOMBO 76 note	180
KORG	MS2000	130	STUDIOLOGIC	ACUNA 73	150
KORG	N1	190	STUDIOLOGIC	ACUNA 88	170
KORG	N264	170	STUDIOLOGIC	NUMA	180
KORG	N364	150	STUDIOLOGIC	NUMA COMPACT	160
KORG	N5	140	STUDIOLOGIC	NUMA CONCERT	170
KORG	O1W-61	150	STUDIOLOGIC	NUMA NANO	170
KORG	O1W-88NOTE-PRO	210	STUDIOLOGIC	NUMA NERO	180

KORG	Oasis 76	190	STUDIOLOGIC	NUMA ORGAN	160
KORG	Oasis 88	210	STUDIOLOGIC	NUMA ORGAN 2	150
KORG	Oasis 88	210	STUDIOLOGIC	NUMA STAGE	170
KORG	Pa-1 x pro	180	STUDIOLOGIC	SL990 PRO / sl990 xp	180
KORG	PA-2 x pro	170	STUDIOLOGIC	SLEDGE	150
KORG	PA300	150	STUDIOLOGIC	TMK49 PLUS	110
KORG	Pa3X	150	STUDIOLOGIC	VMK-149 PLUS	120
KORG	PA50	160	STUDIOLOGIC	VMK-161 ORGAN	140
KORG	PA500	170	STUDIOLOGIC	VMK-161 PLUS	140
KORG	PA50SD	160	STUDIOLOGIC	VMK-176 PLUS	160
KORG	PA588	200	STUDIOLOGIC	VMK-188 PLUS	180
KORG	PA60	170	STUDIOLOGIC	VMK-88 PLUS	160
KORG	PA600	150	TECHNICS	KN1000	160
KORG	PA600QT	150	TECHNICS	KN1400	160
KORG	PA80	170	TECHNICS	KN2000	160
KORG	PA800	160	TECHNICS	KN2400	160
KORG	PA900	150	TECHNICS	KN2600	170
KORG	Polysix	150	TECHNICS	kn3000	170
KORG	PROPHECY 3 OCT.	110	TECHNICS	KN5000	160
KORG	PS60	130	TECHNICS	KN501/701	150
KORG	R3	100	TECHNICS	KN6000	170
KORG	Radius	140	TECHNICS	KN7000	170
KORG	SGPROX-88	190	TECHNICS	KN701	150
KORG	SP100	180	TECHNICS	KN901	150
KORG	SP170	180	TECHNICS	KZ250	160
KORG	SP200	170	TECHNICS	p50	180
KORG	SP250	180	TECHNICS	wsa1	150
KORG	SP250	180	YAMAHA	PSR160	140
KORG	SP300	180	YAMAHA	PSR170	140
KORG	SP500	170	YAMAHA	PSR172	140
KORG	TRINITY V3-61 NOTE	160	YAMAHA	PSR175	140
KORG	TRINITY-61 NOTE	160	YAMAHA	9000 pro	180
KORG	TRINITY-76 PRO	180	YAMAHA	an1x	140
KORG	TRINITY-88 Prox	220	YAMAHA	CP1	200
KORG	Triton LE 61	140	YAMAHA	CP300	200
KORG	Triton LE 76	170	YAMAHA	CP33	180
KORG	Triton le 88	190	YAMAHA	CP4 STAGE	180
KORG	Triton le61	140	YAMAHA	CP40 STAGE	180
KORG	Triton le76	170	YAMAHA	CP5	200
KORG	Triton le88	190	YAMAHA	CP50	190
KORG	Triton studio 61	160	YAMAHA	CS1X	140
KORG	Triton studio 76	180	YAMAHA	CS2X	140
KORG	Triton studio 88	210	YAMAHA	CS6X	150
KORG	Triton TR 61	140	YAMAHA	DGX200	170
KORG	TRITON-61 Extreme	160	YAMAHA	DGX202	180
KORG	TRITON-61(not LE)Classic	150	YAMAHA	DGX203	170
KORG	TRITON-76	180	YAMAHA	DGX205	170
KORG	TRITON-76 Extreme	180	YAMAHA	DGX220	170
KORG	TRITON-88 Extreme	200	YAMAHA	dgx300	180
KORG	TRITON-88 STUDIO88	210	YAMAHA	DGX305	180

KORG	TRITONPROX-88	210	YAMAHA	DGX500	200
KORG	TRITON-Taktile	90	YAMAHA	DGX505	200
KORG	X2	170	YAMAHA	DGX520	190
KORG	X2 : 76 NOTE	170	YAMAHA	DGX620	200
KORG	X3	150	YAMAHA	DGX640	200
KORG	X5-	130	YAMAHA	djx-ii	140
KORG	X50	130	YAMAHA	dx11	130
KORG	Z1	160	YAMAHA	DX7	140
KORG	KingKORG	140	YAMAHA	EX5 / ex5s	180
KORG	KROME 61	140	YAMAHA	EX7	160
KORG	KROME 73	160	YAMAHA	Ez150	140
KORG	Krome 73	160	YAMAHA	EZ20	140
KORG	KROME 88	200	YAMAHA	EZ220	140
KORG	KRONOS 61	150	YAMAHA	EZ250-i	140
KORG	KRONOS 73	180	YAMAHA	EZ30	140
KORG	KRONOS 88	200	YAMAHA	KX88	190
KORG	KRONOS-X 61	150	YAMAHA	m-06	150
KORG	KRONOS-X 73	180	YAMAHA	m-08	190
KORG	KRONOS-X 88	200	YAMAHA	mm6	140
KORG	KROSS 61	130	YAMAHA	mm8	190
KORG	microARRANGER	120	YAMAHA	MO 6	150
KORG	MicroArranger	120	YAMAHA	MO 8	190
KORG	Microkorg	80	YAMAHA	Motif XF6	160
KORG	Microkorg XL	90	YAMAHA	Motif 6	160
KORG	microKORG XL+	90	YAMAHA	Motif 7	180
KORG	Micro-x	90	YAMAHA	Motif 8	210
KORG	MS-20 Mini	100	YAMAHA	Motif ES6	160
KORG	Pa300	150	YAMAHA	Motif ES7	180
KORG	Pa3X 61	150	YAMAHA	Motif ES8	210
KORG	Pa3X 76	170	YAMAHA	Motif XF6	160
KORG	Pa3X LE	170	YAMAHA	Motif XF7	180
KORG	Pa50SD	160	YAMAHA	motif XF8	210
KORG	PA60	170	YAMAHA	Motif XS6	160
KORG	Pa600	150	YAMAHA	Motif XS7	180
KORG	Pa600QT	150	YAMAHA	Motif xs8	210
KORG	Pa900	150	YAMAHA	MOX6	150
KORG	R3	100	YAMAHA	MOX8	190
KORG	RK-100S	120	YAMAHA	MOXF6	150
KORG	RK-100S Keytar	120	YAMAHA	MOXF8	190
KORG	SV-1 73	160	YAMAHA	MX49	120
KORG	SV-1 88	190	YAMAHA	MX61	140
KORG	Triton Taktile	90	YAMAHA	NP-11	140
KORG	X50	130	YAMAHA	NP30 portable grand	160
KORK	Pa3X LE	170	YAMAHA	NP-31	160
KURZWEIL	ARTIS	190	YAMAHA	NP-V60	170
KURZWEIL	FORTE	190	YAMAHA	NP-V80	170
KURZWEIL	K1200	200	YAMAHA	P35	180
KURZWEIL	K2000/K2000VP	150	YAMAHA	P45	180
KURZWEIL	K2500-76 NOTE	180	YAMAHA	P1000	160
KURZWEIL	K2500-88 NOTE	200	YAMAHA	P105	180

KURZWEIL	K2600-76 note	180	YAMAHA	P115	180
KURZWEIL	K2600-88 note	200	YAMAHA	P120	180
KURZWEIL	K2600X	200	YAMAHA	P120	180
KURZWEIL	K2661	150	YAMAHA	P120	180
KURZWEIL	K2VX	150	YAMAHA	p140	180
KURZWEIL	KME61	130	YAMAHA	P140	180
KURZWEIL	PC161	160	YAMAHA	P150	200
KURZWEIL	PC1SE	170	YAMAHA	P155	180
KURZWEIL	PC1X	190	YAMAHA	P155	180
KURZWEIL	PC2	170	YAMAHA	p200	200
KURZWEIL	PC2X	190	YAMAHA	p250	200
KURZWEIL	PC3	180	YAMAHA	P255	180
KURZWEIL	PC361	150	YAMAHA	P300	200
KURZWEIL	PC3K6	150	YAMAHA	P60	180
KURZWEIL	PC3K7	170	YAMAHA	P60	180
KURZWEIL	PC3K8	180	YAMAHA	P60S	180
KURZWEIL	PC3LE6	150	YAMAHA	P65	180
KURZWEIL	PC3LE7	180	YAMAHA	P70	180
KURZWEIL	PC3LE8	190	YAMAHA	P70S	180
KURZWEIL	PC3X	180	YAMAHA	P80	180
KURZWEIL	PC88	180	YAMAHA	P85	180
KURZWEIL	RG100	190	YAMAHA	p90	180
KURZWEIL	RG200	190	YAMAHA	PF1000	210
KURZWEIL	SP2	190	YAMAHA	PF500	210
KURZWEIL	SP4-7	150	YAMAHA	PF85	190
KURZWEIL	SP4-8	190	YAMAHA	PROMIX 01	100
KURZWEIL	SP5-8	190	YAMAHA	PSR1000	160
KURZWEIL	SP76	160	YAMAHA	PSR1100	150
KURZWEIL	SP88	170	YAMAHA	PSR140	130
KURZWEIL	SP88x	190	YAMAHA	PSR150	140
KURZWEIL	SPS4-8	180	YAMAHA	PSR1500	150
MAUDIO	axiom 25	90	YAMAHA	PSR190	140
MAUDIO	axiom 49	120	YAMAHA	PSR195	140
MAUDIO	axiom 61	130	YAMAHA	PSR2000	150
MAUDIO	Axiom AIR 25	100	YAMAHA	PSR2100	160
MAUDIO	Axiom AIR 49	100	YAMAHA	psr220	140
MAUDIO	Axiom AIR 61	150	YAMAHA	PSR225GM	140
MAUDIO	Axiom AIR Mini 32	60	YAMAHA	PSR230	140
MAUDIO	axiom PRO 25	80	YAMAHA	PSR240	140
MAUDIO	axiom pro 49	120	YAMAHA	PSR248	130
MAUDIO	axiom pro 61	130	YAMAHA	psr260	150
MAUDIO	ekeys 37	60	YAMAHA	PSR262	140
MAUDIO	Keystation 49 Mk2	110	YAMAHA	PSR27	130
MAUDIO	keystation 49e	130	YAMAHA	PSR270	140
MAUDIO	Keystation 61 Mk2	130	YAMAHA	PSR273	140
MAUDIO	keystation 61es	150	YAMAHA	PSR275	140
MAUDIO	Keystation 88 Mk2	170	YAMAHA	psr280	150
MAUDIO	keystation 88es	170	YAMAHA	psr282	140
MAUDIO	Keystation Mini 32	60	YAMAHA	PSR290	150
MAUDIO	Keystation pro 88	190	YAMAHA	PSR292	150

MAUDIO	keystation pro88	190	YAMAHA	PSR293	150
MAUDIO	midair 37	100	YAMAHA	PSR295	150
MAUDIO	mk 449c	110	YAMAHA	PSR3000	150
MAUDIO	Oxygen 25 Mk4	80	YAMAHA	PSR320	140
MAUDIO	oxygen 49	110	YAMAHA	PSR330	140
MAUDIO	Oxygen 49 Mk4	120	YAMAHA	PSR340	150
MAUDIO	oxygen 61	130	YAMAHA	PSR350	150
MAUDIO	Oxygen 61 Mk4	130	YAMAHA	PSR38	140
MAUDIO	Oxygen 88	180	YAMAHA	PSR400	160
MAUDIO	oxygen 8v2	70	YAMAHA	PSR4000	170
MAUDIO	ozone	70	YAMAHA	PSR420	140
MAUDIO	ozonic	100	YAMAHA	PSR450	150
MAUDIO	prokeys 88sx	180	YAMAHA	PSR4500	180
MAUDIO	radium 49	110	YAMAHA	PSR500	150
MAUDIO	radium 61	120	YAMAHA	PSR520	150
MAUDIO	Venom	120	YAMAHA	PSR530	150
NORD	C1 Combo Organ	160	YAMAHA	PSR540	150
NORD	c2 organ	160	YAMAHA	PSR550	150
NORD	c2 oRGAN	160	YAMAHA	PSR5700	160
NORD	C2D	160	YAMAHA	PSR630	150
NORD	electro 2 61 note	130	YAMAHA	PSR640	150
NORD	electro 2 73 note	150	YAMAHA	PSR7000	170
NORD	electro 2 seventythree	150	YAMAHA	PSR730	150
NORD	electro 2 sixtyone	130	YAMAHA	PSR740	150
NORD	electro 3 SEVENTY SIX	150	YAMAHA	PSR77	140
NORD	electro 3 SIXTY ONE	130	YAMAHA	psr78	140
NORD	electro 3 seventythree	150	YAMAHA	PSR79	130
NORD	electro 3 sixtyone	130	YAMAHA	PSR8000	170
NORD	Electro 4 HP	150	YAMAHA	PSR805	140
NORD	Electro 4 SW73	150	YAMAHA	PSR90	130
NORD	Electro 4D SW61	130	YAMAHA	psr9000	180
NORD	Electro 5 HP	150	YAMAHA	PSR-A2000	160
NORD	Electro 5D 61	130	YAMAHA	PSRD1	140
NORD	Electro 5D 73	150	YAMAHA	PSRD1DJX	140
NORD	Lead 2	120	YAMAHA	psr-e203	140
NORD	LEAD 2X	120	YAMAHA	PSR-E243	140
NORD	Lead 4	120	YAMAHA	psr-e303	140
NORD	Lead 4R	80	YAMAHA	PSR-E343	140
NORD	Lead A1	120	YAMAHA	psr-e403	150
NORD	Lead A1R	80	YAMAHA	PSR-E443	150
NORD	PIANO	170	YAMAHA	psr-S500	150
NORD	PIANO	170	YAMAHA	PSR-S650	150
NORD	Piano 2 HA88	170	YAMAHA	PSR-S670	150
NORD	Piano 2 HP	150	YAMAHA	PSR-S750	160
NORD	PK27 Pedals	200	YAMAHA	PSR-S770	160
NORD	STAGE 2 EX 88	170	YAMAHA	PSR-S950	160
NORD	STAGE 2 EX HP76	160	YAMAHA	PSR-S970	160
NORD	STAGE 2 EX COMPACT	150	YAMAHA	QS300	160
NORD	Stage 2 HA76	160	YAMAHA	rs7000	90
NORD	Stage 2 HA88	170	YAMAHA	s03 bl	130

NORD	Stage 2 SW73	150
NORD	STAGE 76	160
NORD	STAGE 88	180
NORD	Stage Compact	150
NORD	Wave	120
NOVATION	A Station	100
NOVATION	bass station keyboard	70
NOVATION	k STATION	90
NOVATION	KS4	120
NOVATION	KS4	130
NOVATION	KS5	140
NOVATION	KS5	140
NOVATION	NOCTURN 25	80
NOVATION	NOCTURN 49	110
NOVATION	NOVA II	120
NOVATION	REMOTE 25	80
NOVATION	REMOTE 49	110
NOVATION	REMOTE 61	130
NOVATION	remote le 25	70
NOVATION	remote le 49	110
NOVATION	remote le 61	120
NOVATION	REMOTE SL 25	80
NOVATION	REMOTE SL 49	110
NOVATION	remote sl25	80
NOVATION	remote sl25 compact	80
NOVATION	remote sl37	100
NOVATION	remote sl49 compact	110
NOVATION	remote sl61	130
NOVATION	SL MARK II 25	80
NOVATION	SL MARK II 49	120
NOVATION	SL MARK II 61	130
NOVATION	Super Nova II	150
NOVATION	x station 25	80
NOVATION	x station 49	110

YAMAHA	s03-BL	130
YAMAHA	s08	190
YAMAHA	s30	140
YAMAHA	S70 XS	190
YAMAHA	S80	190
YAMAHA	S90	190
YAMAHA	S90 ES	200
YAMAHA	S90 XS	200
YAMAHA	SY77	160
YAMAHA	SY99	180
YAMAHA	TYROS 4	170
YAMAHA	TYROS v2	170
YAMAHA	TYROS [original]	170
YAMAHA	TYROS 3	170
YAMAHA	TYROS 5 - 61	170
YAMAHA	TYROS 5 - 76	190
YAMAHA	VL1/VL7	140
YAMAHA	W5-76 NOTE	180
YAMAHA	W5-76 NOTE V2	180
YAMAHA	W7-61 NOTE	160
YAMAHA	W7-61 NOTE V2	160
YAMAHA	ypg225	170
YAMAHA	ypg525	190
YAMAHA	YPG535	190
YAMAHA	ypg625	200
YAMAHA	YPP15	150
YAMAHA	YPP35	150
YAMAHA	YPP55	180
YAMAHA	YPT200	140
YAMAHA	YPT240	140
YAMAHA	YPT300	140
YAMAHA	YPT340	140
YAMAHA	YPT400	150