

Cross Reference

Ordering & Information

How to Use

This reference section lists competitive devices in alpha-numeric order and the comparable replacement product available through **Siemens Building Technologies**.

Refer to the Key at the bottom of each page for each individual manufacturer's ID Code.

For more information:

For technical or installation instructions and locations, visit the web site at: **www.sbt.siemens.com/hvp/components**.

For further assistance, please contact a Siemens Building Technologies representative at: **1.888.593.7876**.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
A11A-1	PJC	Low Temp. Detection Thermostat	134-1511	AF24-SR-S US	BL	Elec. Damper Actuator 0-10 V w/ fb & aux.	GCA156.1U/P
A11B-1	PJC	Low Temp. Detection Thermostat	134-1510	AF24-SR-S US	BL	Elec. Damper Actuator 0-10 V all options	GCA164.1U/P
A19AAC-9	JC	Elec. Line Voltage Bulb Thermostat	141-0521	AF24-SR-S US	BL	Elec. Damper Actuator 0-10 V w/ fb & aux.	GCA166.1U/P
A1H250/I	ST	Elec. Damper Actuator	GBB171.1U+ ASK71.2	AK-40613	INV	Reverse-Acting Relay	243-0024
A-201-01	INV	Pressure Gauge	142-0373	AK-4605	INV	Positioning/Gradual Switch	151-142
A25AN-1	JC	High Temp. Limit Thermostat	141-0530	AK-50613	INV	Reverse-Acting Relay	243-0024
A28AA-28	JC	Controller	RWD82U	AKS-6221	INV	Receiver Gauge	142-0242
A28AA-29	JC	Controller	RWD82U	AKS-9022	INV	Receiver Gauge	142-0284
A28AA-36	JC	Controller	RWD82U	AKS-9022	INV	Receiver Gauge	142-0433
A28AA-37	JC	Controller	RWD82U	AL-100	INV	EP Switch	265-1001
A28AA-8	JC	Controller	RWD82U	AL-109	INV	EP Switch	265-1008
A28AA-9	JC	Controller	RWD82U	AL-110	INV	EP Switch	265-1002
A28AJ-4	JC	Controller	RWD82U	AL-120	INV	EP Switch	265-1003
A350AA-1C	JC	Controller	RWD82U	AL-125	INV	EP Switch	265-1004
A350AA-2C	JC	Controller	RWD82U	AL-130	INV	EP Switch	265-1005
A350AA-3C	JC	Controller	RWD82U	AL-140	INV	EP Switch	265-1006
A350BA-1C	JC	Controller	RWD82U	AL-170	INV	EP Switch	265-1007
A350BA-2C	JC	Controller	RWD82U	AL-171	INV	EP Switch	265-1008
A350EA-4C	JC	Controller	RWD82U	AL-180	INV	EP Switch	265-1001
A350PS-1C	JC	Controller	RWD62U	AL-181	INV	EP Switch	265-1002
A350PS-2C	JC	Controller	RWD62U	AL-182	INV	EP Switch	265-1003
A350PT-1C	JC	Controller	RWD62U	AL-183	INV	EP Switch	265-1004
A36AHA-50	JC	Controller	RWD44U	AL-185	INV	EP Switch	265-1006
A36AHA-52	JC	Controller	RWD44U	AL-242	INV	Reverse-Acting Relay	243-0024
A36AHA-58	JC	Controller	RWD44U	AL-282	INV	Highest Pressure Relay	243-0018
A36AHB-33	JC	Controller	RWD44U	AL-362	INV	Pressure Gauge	142-0373
A-4000-137	JC	Air Filter	908-033	AL-99	INV	EP Switch	265-1007
A-4000-138	JC	Pressure Reducing Valves	201-1001	AM24	BL	Elec. Damper Actuator	GEB131.1P
A-4000-139	JC	Pressure Reducing Valves	908-048	AM24-S US	BL	Elec. Damper Actuator	GEB166.1U
A-4000-140	JC	Pressure Reducing Valves	908-049	AM24-SR	BL	Elec. Damper Actuator	GEB161.1P
A40EA-1	JC	High/Low Temp. Detection Thermostat	134-1700	ARR-262	HW	Pressure Reducing Valve	195-104
A40HA-2	JC	High/Low Temp. Detection Thermostat	134-1710	AS1D15	ST	Elec. Damper Actuator	GBB131.1U
A70HA-1	JC	High/Low Temp. Detection Thermostat	134-1700	AS1D15F/A	ST	Elec. Damper Actuator	GCA121.1U
A70KA-1	JC	High/Low Temp. Detection Thermostat	134-1710	AS1D15FS/A	ST	Elec. Damper Actuator	GCA126.1U
AF120 US	BL	Elec. Damper Actuator 120V SR 2P	GCA221.1U	AS1D30	ST	Elec. Damper Actuator	GIB171.1U
AF120-S US	BL	Elec. Damper Act. 120V SR 2P w/ aux.	GCA226.1U	AS1D8	ST	Elec. Damper Actuator	GBB131.1U
AF24 US	BL	Elec. Damper Actuator 133 lb.-in. SR 2P	GCA121.1U/P	ASU1D30	ST	Elec. Damper Actuator	GIB161.1U
AF24-3 US	BL	Elec. Damper Actuator 133 lb.-in. SR 3P	GCA131.1U/P	B209B+LF24	BL	Elec. Ball Valve	171E10204
AF24-3 US	BL	Elec. Damper Actuator 133 lb.-in. SR 3P w/aux.	GCA135.1U	B209B+LF24-3	BL	Elec. Ball Valve	171F10204
AF24-S US	BL	Elec. Damper Actuator 24V 2P	GCA126.1U/P	B209B+LF24-SR	BL	Elec. Ball Valve	171G10204
AF24-SR US	BL	Elec. Damper Actuator 4-20 mA w/ fb	GCA151.1U/P	B209B+LR24	BL	Elec. Ball Valve	171A10204
AF24-SR US	BL	Elec. Damper Actuator 0-10 V w/ fb	GCA161.1U/P	B209B+LR24-SR	BL	Elec. Ball Valve	171C10204
AF24-SR US	BL	Elec. Damper Actuator 0-10 v w/ fb & span	GCA163.1U/P	B209B+NM24	BL	Elec. Ball Valve	171A10204

AC Accustat	INV Invensys (Robertshaw/ Barber Colman/Siebe/ Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/ Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
B209B+ NM24-SR	BL	Elec. Ball Valve	171C10204	B214B+LR24	BL	Elec. Ball Valve	171A10209
B210B+LF24	BL	Elec. Ball Valve	171E10205	B214B+ LR24-SR	BL	Elec. Ball Valve	171C10209
B210B+LF24-3	BL	Elec. Ball Valve	171F10205	B214B+NM24	BL	Elec. Ball Valve	171A10209
B210B+ LF24-SR	BL	Elec. Ball Valve	171G10205	B214B+ NM24-SR	BL	Elec. Ball Valve	171C10209
B210B+LR24	BL	Elec. Ball Valve	171A10205	B215B+LF24	BL	Elec. Ball Valve	171E10208
B210B+ LR24-SR	BL	Elec. Ball Valve	171C10205	B215B+ LF24-3	BL	Elec. Ball Valve	171F10208
B210B+NM24	BL	Elec. Ball Valve	171A10205	B215B+ LF24-SR	BL	Elec. Ball Valve	171G10208
B210B+ NM24-SR	BL	Elec. Ball Valve	171C10205	B215B+LR24	BL	Elec. Ball Valve	171A10208
B211B+LF24	BL	Elec. Ball Valve	171E10205	B215B+ LR24-SR	BL	Elec. Ball Valve	171C10208
B211B+ LF24-3	BL	Elec. Ball Valve	171F10205	B215B+NM24	BL	Elec. Ball Valve	171A10208
B211B+ LF24-SR	BL	Elec. Ball Valve	171G10205	B215B+ NM24-SR	BL	Elec. Ball Valve	171C10208
B211B+LR24	BL	Elec. Ball Valve	171A10205	B217B+ AF24-SR	BL	Elec. Ball Valve	171G10209
B211B+ LR24-SR	BL	Elec. Ball Valve	171C10205	B217B+LF24	BL	Elec. Ball Valve	171E10207
B211B+NM24	BL	Elec. Ball Valve	171A10205	B217B+ LF24-3	BL	Elec. Ball Valve	171F10207
B211B+ NM24-SR	BL	Elec. Ball Valve	171C10205	B217B+ LF24-SR	BL	Elec. Ball Valve	171G10207
B212B+LF24	BL	Elec. Ball Valve	171E10206	B217B+LR24	BL	Elec. Ball Valve	171A10207
B212B+ LF24-3	BL	Elec. Ball Valve	171F10206	B217B+ LR24-SR	BL	Elec. Ball Valve	171C10207
B212B+ LF24-SR	BL	Elec. Ball Valve	171G10206	B217B+ NF24-SR	BL	Elec. Ball Valve	171G10207
B212B+LR24	BL	Elec. Ball Valve	171A10206	B217B+NM24	BL	Elec. Ball Valve	171A10207
B212B+ LR24-SR	BL	Elec. Ball Valve	171C10206	B217B+ NM24-SR	BL	Elec. Ball Valve	171C10207
B212B+NM24	BL	Elec. Ball Valve	171A10206	B218B+ AF24-SR	BL	Elec. Ball Valve	171G10209
B212B+ NM24-SR	BL	Elec. Ball Valve	171C10206	B218B+LF24	BL	Elec. Ball Valve	171E10209
B213B+LF24	BL	Elec. Ball Valve	171E10207	B218B+ LF24-3	BL	Elec. Ball Valve	171F10209
B213B+ LF24-3	BL	Elec. Ball Valve	171F10207	B218B+ LF24-SR	BL	Elec. Ball Valve	171G10209
B213B+ LF24-SR	BL	Elec. Ball Valve	171G10207	B218B+LR24	BL	Elec. Ball Valve	171A10209
B213B+LR24	BL	Elec. Ball Valve	171A10207	B218B+ LR24-SR	BL	Elec. Ball Valve	171C10209
B213B+ LR24-SR	BL	Elec. Ball Valve	171C10207	B218B+ NF24-SR	BL	Elec. Ball Valve	171G10209
B213B+NM24	BL	Elec. Ball Valve	171A10207	B218B+NM24	BL	Elec. Ball Valve	171A10209
B213B+ NM24-SR	BL	Elec. Ball Valve	171C10207	B218B+ NM24-SR	BL	Elec. Ball Valve	171C10209
B214B+LF24	BL	Elec. Ball Valve	171E10209	B219B+ AF24-SR	BL	Elec. Ball Valve	171G10209
B214B+ LF24-3	BL	Elec. Ball Valve	171F10209	B219B+LF24	BL	Elec. Ball Valve	171E10209
B214B+ LF24-SR	BL	Elec. Ball Valve	171G10209				

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
B219B+LF24-3	BL	Elec. Ball Valve	171F10209	B223B+LR24	BL	Elec. Ball Valve	171A10211
B219B+LF24-SR	BL	Elec. Ball Valve	171G10209	B223B+LR24-SR	BL	Elec. Ball Valve	171C10211
B219B+LR24	BL	Elec. Ball Valve	171A10209	B223B+LR24-SR	BL	Elec. Ball Valve	171C10211
B219B+LR24-SR	BL	Elec. Ball Valve	171C10209	B223B+NF24-SR	BL	Elec. Ball Valve	171G10211
B219B+NF24-SR	BL	Elec. Ball Valve	171G10209	B223B+NM24	BL	Elec. Ball Valve	171A10211
B219B+NM24	BL	Elec. Ball Valve	171A10209	B223B+NM24-SR	BL	Elec. Ball Valve	171C10211
B219B+NM24-SR	BL	Elec. Ball Valve	171C10209	B224B+AF24-SR	BL	Elec. Ball Valve	171G10213
B220B+AF24-SR	BL	Elec. Ball Valve	171G10210	B224B+LF24	BL	Elec. Ball Valve	171E10213
B220B+LF24	BL	Elec. Ball Valve	171E10210	B224B+LF24-3	BL	Elec. Ball Valve	171F10213
B220B+LF24-3	BL	Elec. Ball Valve	171F10210	B224B+LF24-SR	BL	Elec. Ball Valve	171G10213
B220B+LF24-SR	BL	Elec. Ball Valve	171G10210	B224B+LR24	BL	Elec. Ball Valve	171A10213
B220B+LR24	BL	Elec. Ball Valve	171A10210	B224B+LR24-SR	BL	Elec. Ball Valve	171C10213
B220B+LR24-SR	BL	Elec. Ball Valve	171C10210	B224B+NF24-SR	BL	Elec. Ball Valve	171G10213
B220B+NF24	BL	Elec. Ball Valve	171E10210	B224B+NM24	BL	Elec. Ball Valve	171A10213
B220B+NF24-SR	BL	Elec. Ball Valve	171G10210	B224B+NM24-SR	BL	Elec. Ball Valve	171C10213
B220B+NM24	BL	Elec. Ball Valve	171A10210	B225B+AF24-SR	BL	Elec. Ball Valve	171G10214
B220B+NM24-SR	BL	Elec. Ball Valve	171C10210	B225B+LF24	BL	Elec. Ball Valve	171E10214
B222B+AF24-SR	BL	Elec. Ball Valve	171G10211	B225B+LF24-3	BL	Elec. Ball Valve	171F10214
B222B+LF24	BL	Elec. Ball Valve	171E10211	B225B+LF24-SR	BL	Elec. Ball Valve	171G10214
B222B+LF24-3	BL	Elec. Ball Valve	171F10211	B225B+LR24	BL	Elec. Ball Valve	171A10214
B222B+LF24-SR	BL	Elec. Ball Valve	171G10211	B225B+LR24-SR	BL	Elec. Ball Valve	171C10214
B222B+LR24	BL	Elec. Ball Valve	171A10211	B225B+NF24	BL	Elec. Ball Valve	171E10214
B222B+LR24-SR	BL	Elec. Ball Valve	171C10211	B225B+NF24-SR	BL	Elec. Ball Valve	171G10214
B222B+NF24-SR	BL	Elec. Ball Valve	171G10211	B225B+NM24	BL	Elec. Ball Valve	171A10214
B222B+NM24	BL	Elec. Ball Valve	171A10211	B225B+NM24-SR	BL	Elec. Ball Valve	171C10214
B222B+NM24-SR	BL	Elec. Ball Valve	171C10211	B229B+AF24-SR	BL	Elec. Ball Valve	171G10215
B223B+AF24-SR	BL	Elec. Ball Valve	171G10211	B229B+LF24	BL	Elec. Ball Valve	171E10215
B223B+LF24	BL	Elec. Ball Valve	171E10211	B229B+LF24-3	BL	Elec. Ball Valve	171F10215
B223B+LF24-3	BL	Elec. Ball Valve	171F10211	B229B+LF24-SR	BL	Elec. Ball Valve	171G10215
B223B+LF24-SR	BL	Elec. Ball Valve	171G10211	B229B+LR24	BL	Elec. Ball Valve	171A10215

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
B229B+LR24-SR	BL	Elec. Ball Valve	171C10215	B238B+AF24-3	BL	Elec. Ball Valve	171F10218
B229B+NF24-SR	BL	Elec. Ball Valve	171G10215	B238B+AF24-SR	BL	Elec. Ball Valve	171G10218
B229B+NM24	BL	Elec. Ball Valve	171A10215	B238B+AM24	BL	Elec. Ball Valve	171B10218
B229B+NM24-SR	BL	Elec. Ball Valve	171C10215	B238B+AM24-SR	BL	Elec. Ball Valve	171D10218
B230B+AF24-SR	BL	Elec. Ball Valve	171G10215	B238B+NF24-SR	BL	Elec. Ball Valve	171G10218
B230B+LF24	BL	Elec. Ball Valve	171E10215	B238B+NM24	BL	Elec. Ball Valve	171B10219
B230B+LF24-3	BL	Elec. Ball Valve	171F10215	B238B+NM24-SR	BL	Elec. Ball Valve	171D10218
B230B+LF24-SR	BL	Elec. Ball Valve	171G10215	B239B+AF24-3	BL	Elec. Ball Valve	171F10218
B230B+LR24	BL	Elec. Ball Valve	171A10215	B239B+AF24-SR	BL	Elec. Ball Valve	171G10218
B230B+LR24-SR	BL	Elec. Ball Valve	171C10215	B239B+AM24	BL	Elec. Ball Valve	171B10219
B230B+NF24	BL	Elec. Ball Valve	171E10215	B239B+NF24-SR	BL	Elec. Ball Valve	171G10218
B230B+NF24-SR	BL	Elec. Ball Valve	171G10215	B239B+NM24	BL	Elec. Ball Valve	171B10218
B230B+NM24	BL	Elec. Ball Valve	171A10215	B240B+AF24	BL	Elec. Ball Valve	171E10221
B230B+NM24-SR	BL	Elec. Ball Valve	171C10215	B240B+AF24-3	BL	Elec. Ball Valve	171F10221
B231B+AF24-3	BL	Elec. Ball Valve	171F10216	B240B+AF24-SR	BL	Elec. Ball Valve	171G10219
B231B+AF24-SR	BL	Elec. Ball Valve	171G10216	B240B+AM24	BL	Elec. Ball Valve	171B10220
B231B+AM24	BL	Elec. Ball Valve	171A10216	B240B+AM24-SR	BL	Elec. Ball Valve	171D10219
B231B+AM24-SR	BL	Elec. Ball Valve	171C10216	B240B+NF24	BL	Elec. Ball Valve	171E10221
B231B+NF24-SR	BL	Elec. Ball Valve	171G10216	B240B+NF24-SR	BL	Elec. Ball Valve	171G10219
B231B+NM24	BL	Elec. Ball Valve	171A10216	B240B+NM24	BL	Elec. Ball Valve	171B10220
B231B+NM24-SR	BL	Elec. Ball Valve	171C10216	B240B+NM24-SR	BL	Elec. Ball Valve	171D10219
B232B+AF24	BL	Elec. Ball Valve	171E10216	B248B+AF24-3	BL	Elec. Ball Valve	171F10222
B232B+AF24-3	BL	Elec. Ball Valve	171F10216	B248B+AF24-SR	BL	Elec. Ball Valve	171G10222
B232B+AF24-SR	BL	Elec. Ball Valve	171C10216	B248B+AM24	BL	Elec. Ball Valve	171B10222
B232B+AF24-SR	BL	Elec. Ball Valve	171G10216	B248B+AM24-SR	BL	Elec. Ball Valve	171D10222
B232B+AM24	BL	Elec. Ball Valve	171A10216	B248B+NM24	BL	Elec. Ball Valve	171B10222
B232B+NF24	BL	Elec. Ball Valve	171E10216	B248B+NM24-SR	BL	Elec. Ball Valve	171D10222
B232B+NF24-SR	BL	Elec. Ball Valve	171G10216	B249B+AF24-3	BL	Elec. Ball Valve	171F10222
B232B+NM24	BL	Elec. Ball Valve	171A10216	B249B+AF24-SR	BL	Elec. Ball Valve	171G10222
B232B+NM24-SR	BL	Elec. Ball Valve	171C10216	B249B+AM24	BL	Elec. Ball Valve	171B10222

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
B249B+NM24	BL	Elec. Ball Valve	171B10222	D-2346-2	JC	Pneu. Damper Actuator	331-2882
B250B+AF24-3	BL	Elec. Ball Valve	171F10223	D-2346-3	JC	Pneu. Damper Actuator	331-3070
B250B+AF24-SR	BL	Elec. Ball Valve	171G10223	D-3062-1	JC	Pneu. Damper Actuator	331-4310
B250B+AM24	BL	Elec. Ball Valve	171B10223	D-3062-2	JC	Pneu. Damper Actuator	331-4510
B250B+AM24	BL	Elec. Ball Valve	171E10223	D-3062-3	JC	Pneu. Damper Actuator	331-4810
B250B+AM24-SR	BL	Elec. Ball Valve	171D10223	D-3073-1	JC	Pneu. Damper Actuator	332-4811
B250B+NM24	BL	Elec. Ball Valve	171B10223	D-3073-2	JC	Pneu. Damper Actuator	331-4811
B250B+NM24-SR	BL	Elec. Ball Valve	171D10223	D-3073-3	JC	Pneu. Damper Actuator	331-4511
C-208-2	JC	Reverse-Acting Relay	243-0024	D-3153-1	JC	Pneu. Damper Actuator	332-3011
C-2220	JC	High/Low Signal Selector Relay	243-0019	D-3153-2	JC	Pneu. Damper Actuator	331-3011
C-5226	JC	Highest Pressure Relay	243-0018	D-3153-4	JC	Pneu. Damper Actuator	332-3011
C-522603	JC	Lowest Pressure Selector	243-0023	D-3153-41	JC	Pneu. Damper Actuator	331-3011
CBE118	V	Oil/gas heat cool	RDX42.22U	D-3153-5	JC	Pneu. Damper Actuator	331-3011
CC-8111-024	JC	Controller	RWD82U	D-3153-6	JC	Pneu. Damper Actuator	331-3013
CP-8102	INV	Controller	RWD68U	D-3153-7	JC	Pneu. Damper Actuator	331-3012
CP-8142-024	INV	Controller	RWD68U	D-3244-2	JC	Pneu. Damper Actuator	331-3070
CCC-1001	INV	Pneu. Receiver-Controller	195-0003	D-3244-3	JC	Pneu. Damper Actuator	331-2882
CCC-1002	INV	Pneu. Receiver-Controller	195-0003	D-3244-4	JC	Pneu. Damper Actuator	331-2882
CCE-1001	KR	Pressure Elec. Switch	251-0001	D-3703-4	JC	Pneu. Damper Actuator	332-4811
CCE-1003	KR	Pressure Elec. Switch	251-0001	D-3703-5	JC	Pneu. Damper Actuator	331-4811
CLEAFS405	HW	Diff. Static Pressure Air Flow Switch	141-0518	D-3703-6	JC	Pneu. Damper Actuator	331-4511
CLEAFS460	HW	Diff. Static Pressure Air Flow Switch	141-0575	D-3703-7	JC	Pneu. Damper Actuator	331-4314
CSE-1102	KR	Diff. Static Pressure Air Flow Switch	141-0518	DG05-2-03 SS/DS24-140	DT	Elec. Valve	29803002
CTC-1001	KR	Pneu. Room Thermostat	192-200	DG05-2-03 SS/DS24-140	DT	Elec. Valve	29903002
CTC-1002	KR	Pneu. Room Thermostat	192-201	DG05-2-03/DS24-140	DT	Elec. Valve	29803164
CTC-1502	KR	Pneu. Room Thermostat	192-202	DG05-3-03/DS24-140	DT	Elec. Valve	29903164
CTC-1502	KR	Pneu. Room Thermostat	192-203	DG05-3-03/DS24-140	DT	Elec. Valve	29803200
CTC-1503	KR	Pneu. Room Thermostat	192-229	DG05-3-03/DS24-140	DT	Elec. Valve	29903200
CTC-1504	KR	Pneu. Room Thermostat	192-207	DG1-2-10 SS/DS24-140	DT	Elec. Valve	29803005
CTC-1505	KR	Pneu. Room Thermostat	192-230	DG1-2-10 SS/DS24-140	DT	Elec. Valve	29903005
CTC-1506	KR	Pneu. Room Thermostat	192-208	DG1-2-10/DS24-140	DT	Elec. Valve	29803167
CTC-2001	KR	Pneu. Room Thermostat	192-200	DG1-2-10/DS24-140	DT	Elec. Valve	29903167
CTC-2002	KR	Pneu. Room Thermostat	192-201	DG125-2-16 SS/DMS24-140	DT	Elec. Valve	29803006
CTC-5001	KR	Pneu. Room Thermostat	192-200	DG125-2-16/SS/DS24-140	DT	Elec. Valve	29903006
CTC-5001	KR	Pneu. Room Thermostat	192-201	DG125-2-16/SS/DS24-140	DT	Elec. Valve	29903006
CTC-5011	KR	Pneu. Room Thermostat	192-200	DG125-2-16/SS/DS24-140	DT	Elec. Valve	29903006
CTC-5012	KR	Pneu. Room Thermostat	192-201	DG125-2-16/SS/DS24-140	DT	Elec. Valve	29903006
CTC-5501	KR	Pneu. Room Thermostat	192-202	DG125-2-16/SS/DS24-140	DT	Elec. Valve	29903006
CTC-5502	KR	Pneu. Room Thermostat	192-203	DG125-2-16/SS/DS24-140	DT	Elec. Valve	29903006
CTC-5511	KR	Pneu. Room Thermostat	192-202	DG125-2-16/SS/DS24-140	DT	Elec. Valve	29903006
CTC-5511	KR	Pneu. Room Thermostat	192-203	DG125-2-16/SS/DS24-140	DT	Elec. Valve	29903006
D-2346-1	JC	Pneu. Damper Actuator	331-2882	DMS24-140	DT	Elec. Valve	29803168

AC Accustat	INV Invensys (Robertshaw/Barber Colman/Siebe/Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
DG125-2-16/ DS24-140	DT	Elec. Valve	29903168	EDA-2040-24	JC	Damper Actuator 35 lb.-in. 3P w/ aux.	GDE166.1P
DG125-3-16/ DMS24-140	DT	Elec. Valve	29803204	EM402-102	ST	Elec. Damper Actuator	GDE131.1U
DG125-3-16/ DS24-140	DT	Elec. Valve	29903204	EMT402-102	ST	Elec. Damper Actuator	GDE131.1U
DG1-3-10/ DMS24-140	DT	Elec. Valve	29803203	EMT402-302	ST	Elec. Damper Actuator	GDE131.1U
DG1-3-10/ DS24-140	DT	Elec. Valve	29903203	EP-8000-2	JC	Elec.-Pneu. Transducer	545-208
DG150-2-25 SS/DMS24-140	DT	Elec. Valve	29803007	G-2010-300	JC	Pressure Gauge	142-0311
DG150-2-25 SS/DS24-140	DT	Elec. Valve	29903007	G-2010-302	JC	Pressure Gauge	142-0279
DG150-2-25/ DS24-140	DT	Elec. Valve	29903169	G-2010-403	JC	Pressure Gauge	142-0305
DG150-3-25/ DMS24-140	DT	Elec. Valve	29803169	G-2010-5	JC	Pressure Gauge	142-0373
DG150-3-25/ DMS24-140	DT	Elec. Valve	29803205	G240+AF24 US	BL	Elec. Valve	29903169
DG150-3-25/ DS24-140	DT	Elec. Valve	29903205	G240+ AF24-SR US	BL	Elec. Valve	29803169
DG2-2-40 SS/DMS24-140	DT	Elec. Valve	29803008	G250+ AF24 US	BL	Elec. Valve	29903170
DG2-2-40 SS/DS24-140	DT	Elec. Valve	29903008	G250+ AF24-SR US	BL	Elec. Valve	29803170
DG2-2-40/ DMS24-140	DT	Elec. Valve	29803170	G340+ AF24 US	BL	Elec. Valve	29903205
DG2-2-40/ DS24-140	DT	Elec. Valve	29903170	G340+ AF24-SR US	BL	Elec. Valve	29803205
DG2-3-40/ DMS24-140	DT	Elec. Valve	29803206	G350+ AF24 US	BL	Elec. Valve	29903206
DG2-3-40/ DS24-140	DT	Elec. Valve	29903206	G350+ AF24-SR US	BL	Elec. Valve	29803206
DG75-2-07 SS/ DMS24-140	DT	Elec. Valve	29803004	G-7185-1	JC	Pneu. Step Controller	256-1015
DG75-2-07 SS/ DS24-140	DT	Elec. Valve	29903004	G-7185-5	JC	Pneu. Step Controller	256-1015
DG75-2-07/ DMS24-140	DT	Elec. Valve	29803166	GM24 US	BL	Elec. Damper Actuator	GIB171.1U/P
DG75-2-07/ DS24-140	DT	Elec. Valve	29903166	GM24-SR US	BL	Elec. Damper Actuator 4-20 mA w/ fb	GIB151.1U/P
DG75-3-07/ DMS24-140	DT	Elec. Valve	29803202	GM24-SR US	BL	Elec. Damper Actuator 4-20 mA w/ fb & aux.	GIB156.1U/P
DG75-3-07/ DS24-140	DT	Elec. Valve	29903202	GM24-SR US	BL	Elec. Damper Actuator 2-10 V w/ fb	GIB161.1U/P
EDA-2040-11	JC	Damper Actuator 35 lb.-in. 3P	GDE131.1U/P	GM24-SR US	BL	Elec. Damper Actuator 2-10 V w/ fb & start/span adj.	GIB163.1U/P
EDA-2040-12	JC	Damper Actuator 35 lb.-in. 3P	GDE131.1U/P	GM24-SR US	BL	Elec. Damper Actuator w/ fb/aux. & start/span adj.	GIB164.1U/P
EDA-2040-21	JC	Damper Actuator 35 lb.-in. 3P	GDE131.1U/P	GM24-SR US	BL	Elec. Damper Actuator 2-10 V w/ fb & aux.	GIB166.1U/P
EDA-2040-22	JC	Damper Actuator 35 lb.-in. 3P	GDE131.1U/P	H18-301	INV	Room and Duct Hygrostat	186-0013
EDA-2040-23	JC	Damper Actuator 35 lb.-in. 3P w/ aux.	GDE166.1P	H18-301	INV	Room and Duct Hygrostat	186-0019
				H-4100-201	JC	Room and Duct Hygrostat	186-0013
				H-4100-203	JC	Room and Duct Hygrostat	186-0019
				H-5100-201	JC	Humidity Transmitter	196-0043
				H-5210-1001	JC	Humidity Transmitter	186-0089
				HAO-1001	KR	Pressure Reducing Valve	195-104
				HAO-1153	KR	Air Filter	908-051
				HK-18	INV	Room and Duct Hygrostat	186-0013
				HK-18	INV	Room and Duct Hygrostat	186-0019
				HKS-2033	INV	Humidity Transmitter	186-0089

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
HKS-5033	INV	Humidity Transmitter	196-0043	M573-5520	INV	Pneu. Damper Actuator	331-2973
HKS-5033	INV	Humidity Transmitter	196-0043	M573-8108	INV	Pneu. Damper Actuator	331-4313
HKS-8065	INV	Enthalpy Transmitter	184-0101	M573-8111	INV	Pneu. Damper Actuator	331-4313
HKS-8065	INV	Enthalpy Transmitter	184-0101	M573-8520	INV	Pneu. Damper Actuator	331-3000
HP-2001	AS	Low Voltage Room Thermostat	141-0597	M574-1520	INV	Pneu. Damper Actuator	332-2973
HP970A1009	HW	Room and Duct Hygrostat	186-0013	M574-1520	INV	Pneu. Damper Actuator	332-2973
HP970B1007	HW	Room and Duct Hygrostat	186-0019	M574-2520	INV	Pneu. Damper Actuator	331-3001
HP971A1008	HW	Humidity Transmitter	186-0043	M574-3208	INV	Pneu. Damper Actuator	331-2934
HP971A1008	HW	Humidity Transmitter	186-0089	M574-3211	INV	Pneu. Damper Actuator	331-2934
HP972B1005	HW	Room and Duct Hygrostat	186-0019	M574-3520	INV	Pneu. Damper Actuator	331-3002
HP972B1013	HW	Room and Duct Hygrostat	186-0020	M574-5208	INV	Pneu. Damper Actuator	331-2966
K-312	INV	Relief Valve	515-0190	M574-5211	INV	Pneu. Damper Actuator	331-2966
K-336	INV	Air Filter	908-051	M574-5520	INV	Pneu. Damper Actuator	331-2973
K-337	INV	Air Filter	908-051	M574-8208	INV	Pneu. Damper Actuator	331-2911
K-381	INV	Pressure Reducing Valve	201-1000	M574-8211	INV	Pneu. Damper Actuator	331-2911
K-381	INV	Pressure Reducing Valve	201-1000	M574-8520	INV	Pneu. Damper Actuator	331-3000
K-383	INV	Pressure Reducing Valve	201-1000	M693-3095	INV	Pneu. Damper Actuator	331-4514
L480B	HW	Low Temp. Detection Thermostat	134-1510	M693-3095-1	INV	Pneu. Damper Actuator	331-4514
L480G	HW	Low Temp. Detection Thermostat	134-1511	M693-3095-P-1	INV	Pneu. Damper Actuator	331-4514
LF120 US	BL	Elec. Damper Actuator	GMA221.1U	M693-5095	INV	Pneu. Damper Actuator	331-4814
LF120-S US	BL	Elec. Damper Actuator	GMA226.1U	M693-5095-1	INV	Pneu. Damper Actuator	331-4814
LF24	BL	Elec. Damper Actuator	GMA121.1P	M693-5095-P-2	INV	Pneu. Damper Actuator	331-4814
LF24-3	BL	Elec. Damper Actuator	GMA131.1P	M693-8095	INV	Pneu. Damper Actuator	331-4314
LF24-S US	BL	Elec. Damper Actuator	GMA126.1U	M693-8095-1	INV	Pneu. Damper Actuator	331-4314
LF24-SR US	BL	Elec. Damper Actuator	GMA161.1P	M693-8095-P-1	INV	Pneu. Damper Actuator	331-4314
LF24-SR-S US	BL	Elec. Damper Actuator	GMA166.1U	M9104-AGA-2	JC	Elec. Damper Actuator 35 lb.-in. 3P	GDE131.1U/P
LH1	AC	Elec. Damper Actuator	RAA20U	M9104-AGC-2	JC	Elec. Damper Actuator 35 lb.-in. 3P w/ dual aux.	GDE136.1U/P
LM24 US	BL	Elec. Damper Actuator 24V 3P 35 lb.-in.	GDE131.1U/P	M9104-GGA-2	JC	Elec. Damper Actuator 0-10 V	GDE161.1P
LM24-10P US	BL	Elec. Damper Actuator 3P w/ fb	GDE132.1P	M9104-GGC-2	JC	Elec. Damper Actuator 0-10 V w/ dual aux.	GDE166.1P
LM24-S US	BL	Elec. Damper Actuator 3P w/ aux.	GDE166.1P	M9108-AGA-2	JC	Elec. Damper Actuator 75 lb.-in.	GLB131.1P
LM24SR T.1 US	BL	Elec. Damper Actuator 0-10 V	GDE161.1P	M9108-AGC-2	JC	Elec. Damper Actuator 75 lb.-in.	GLB136.1P
LM24SR US	BL	Elec. Damper Actuator 0-10 V w/ fb	GDE161.1P	M9108-AGE-2	JC	Elec. Damper Actuator 75 lb.-in.	GLB132.1P
LM24SR US	BL	Elec. Damper Actuator 0-10 V w/ fb	GDE163.1P	M9108-GGA-2	JC	Elec. Damper Actuator 75 lb.-in..	GLB161.1P
LP914A1003	HW	Temp. Transmitter	184-0120	M9108-GGC-2	JC	Elec. Damper Actuator 75 lb.-in.	GLB166.1P
LP914A1052	HW	Temp. Transmitter	184-0121	M9108-HGA-2	JC	Elec. Damper Actuator 0-10 V	GLB163.1P
LP915A1077	HW	Temp. Transmitter	184-0004	M9108-HGC-2	JC	Elec. Damper Actuator 0-10 V w/ aux sw.	GLB164.1P
LP916A1019	HW	Unit Mount Thermostat	188-0031	M9116-AGA-2	JC	Elec. Damper Actuator 140 lb.-in. 3P	GEB131.1P
LP916B1017	HW	Unit Mount Thermostat	188-0033	M9116-AGC-2	JC	Elec. Damper Actuator 140 lb.-in. 3P w/ dual aux.	GBB175.1U/P
M556-14	INV	Pneu. Damper Actuator	331-2882	M9116-AGE-2	JC	Elec. Damper Actuator	GEB135.1U
M573-1520	INV	Pneu. Damper Actuator	332-2973	M9116-GGA-2	JC	Elec. Damper Actuator	GEB161.1P
M573-3108	INV	Pneu. Damper Actuator	331-4513	M9116-GGC-2	JC	Elec. Damper Actuator	GEB166.1U
M573-3111	INV	Pneu. Damper Actuator	331-4513	M9116-HGA-2	JC	Elec. Damper Actuator	GEB163.1P
M573-3520	INV	Pneu. Damper Actuator	331-3002	M9116-HGC-2	JC	Elec. Damper Actuator	GEB164.1U
M573-5108	INV	Pneu. Damper Actuator	331-4813	M9124-AGA-2	JC	Elec. Damper Actuator	GIB171.1U/P
M573-5111	INV	Pneu. Damper Actuator	331-4813				

AC Accustat	INV Invensys (Robertshaw/ Barber Colman/Siebe/ Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/ Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
M9124-AGE-2	JC	Elec. Damper Actuator	GIB175.1U/P	ML4465A1008	HW	Elec. Damper Actuator	GCA221.1U
M9124-GGA-2	JC	Elec. Damper Actuator 0-10 V, 210 lb.-in.,	GIB151.1U/P	ML6161A1001	HW	Elec. Damper Actuator 35 lb.-in. 3P w/ fb 90 sec.	GDE132.1P
M9124-GGA-2	JC	Elec. Damper Actuator 0-10 V, 210 lb.-in.,	GIB161.1U/P	ML6161A2009	HW	Elec. Damper Actuator 35 lb.-in. 3P w/ fb 90 sec.	GDE132.1P
M9124-GGC-2	JC	Elec. Damper Actuator 0-10 V, 210 lb.-in., w/ aux sw.	GIB156.1U/P	ML6161B2024	HW	Elec. Damper Actuator 35 lb.-in. 3P 90 sec.	GDE131.1U/P
M9124-GGC-2	JC	Elec. Damper Actuator 0-10 V, 210 lb.-in., w/ aux sw.	GIB166.1U/P	ML6161C2007	HW	Elec. Damper Actuator 35 lb.-in. 3P w/ fb 90 sec.	GDE132.1P
M9124-HGA-2	JC	Elec. Damper Actuator	GIB163.1U/P	ML6161D1008	HW	Elec. Damper Actuator 35 lb.-in. 3P w/ conduit 90 sec.	GDE131.1U/P
M9124-HGC-2	JC	Elec. Damper Actuator	GIB164.1U/P	ML6161D2006	HW	Elec. Damper Actuator 35 lb.-in. 3P w/ conduit 90 sec.	GDE131.1U/P
M9206-AGA-2	JC	Elec. Damper Actuator	GMA121.1P	ML6174A2002	HW	Elec. Damper Actuator 75 lb.-in.	GLB132.1P
M9206-AGC-2	JC	Elec. Damper Actuator	GMA126.1U	ML6174B2019	HW	Elec. Damper Actuator 75 lb.-in.	GLB131.1P
M9206-GGA-2	JC	Elec. Damper Actuator	GMA161.1P	ML6174C2000	HW	Elec. Damper Actuator 75 lb.-in.	GLB132.1P
M9206-GGC-2	JC	Elec. Damper Actuator	GMA166.1P	ML6174D2009	HW	Elec. Damper Actuator 75 lb.-in.	GLB131.1P
M9216-AGA-2	JC	Elec. Damper Actuator	GCA131.1U/P	ML6184A1003	HW	Elec. Damper Actuator	GEB131.1P
M9216-AGC-2	JC	Elec. Damper Actuator	GCA135.1U	ML6184D1000	HW	Elec. Damper Actuator 140 lb.-in. 3P	GBB171.1U/P
M9216-AGE-2	JC	Elec. Damper Actuator	GCA135.1U/P	ML6184F1008	HW	Elec. Damper Actuator	GBB175.1U/P
M9216-BGA-2	JC	Elec. Damper Actuator	GCA121.1U/P	ML6185A1000	HW	Elec. Damper Actuator	GMA131.1P
M9216-BGC-2	JC	Elec. Damper Actuator	GCA126.1U/P	ML6194A1002	HW	Elec. Damper Actuator	GIB171.1U/P
M9216-HGA-2	JC	Elec. Damper Actuator	GCA161.1U/P	ML6195A1009	HW	Elec. Damper Actuator	GCA131.1U
M9216-HGC-2	JC	Elec. Damper Actuator	GCA161.1U/P	ML6295C1005	HW	Elec. Damper Actuator	GCA135.1U
MA-6501	INV	Elec. Damper Actuator	GCA221.1U	ML6464A1008	HW	Elec. Damper Actuator	GBB171.1U/P
MA-6501-502	INV	Elec. Damper Actuator	GCA226.1U	ML6464A1008	HW	Elec. Damper Actuator	GBB175.1U/P
MA6503	INV	Elec. Damper Actuator	GCA121.1U/P	ML7161A1000	HW	Elec. Damper Actuator 35 lb.-in. 0-10 V	GDE131.1U/P
MA-6503-502	INV	Elec. Damper Actuator	GCA126.1U/P	ML7161A2008	HW	Elec. Damper Actuator 35 lb.-in. 0-10 V	GDE161.1P
MF1233	INV	Elec. Damper Actuator 35 lb.-in.	GDE131.1U/P	ML7174A2001	HW	Elec. Damper Actuator 75 lb.-in.	GLB161.1P
MF1233-002	INV	Elec. Damper Actuator 35 lb.-in.	GDE136.1U/P	ML7284A1018	HW	Elec. Damper Actuator	GEB161.1P
MF6233	INV	Elec. Damper Actuator 75 lb.-in.	GLB131.1P	ML7284D1007	HW	Elec. Damper Actuator	GBB151.1U/P
MF-6633	INV	Elec. Damper Actuator 140 lb.-in. 3P	GBB171.1U/P	ML7284D1015	HW	Elec. Damper Actuator	GBB161.1U/P
MF-6633	INV	Elec. Damper Actuator 140 lb.-in. 3P w/ dual aux.	GBB175.1U/P	ML7284F1005	HW	Elec. Damper Actuator	GBB156.1U/P
MK-4401	INV	Pneu. Damper Actuator	331-3000	ML7284F1013	HW	Elec. Damper Actuator	GEB166.1U
MK-4411	INV	Pneu. Damper Actuator	331-3001	ML7285A1007	HW	Elec. Damper Actuator	GMA161.1P
MK-4421	INV	Pneu. Damper Actuator	331-2793	ML7285C1005	HW	Elec. Damper Actuator	GMA166.1P
MK-573-31	INV	Pneu. Damper Actuator	331-4514	ML7294A1009	HW	Elec. Damper Actuator	GIB161.1U/P
MK-573-38	INV	Pneu. Damper Actuator	331-4514	ML7294C1007	HW	Elec. Damper Actuator	GIB166.1U/P
MK-573-51	INV	Pneu. Damper Actuator	331-4814	ML7295A1006	HW	Elec. Damper Actuator	GCA161.1U
MK-573-58	INV	Pneu. Damper Actuator	331-4814	ML7295A1014	HW	Elec. Damper Actuator	GCA151.1U
MK-574-31	INV	Pneu. Damper Actuator	331-2934	ML7295C1004	HW	Elec. Damper Actuator	GCA166.1U
MK-574-38	INV	Pneu. Damper Actuator	331-2934	ML7295C1012	HW	Elec. Damper Actuator	GCA156.1U
MK-574-51	INV	Pneu. Damper Actuator	331-2966	ML7295H1009	HW	Elec. Damper Actuator	GCA164.1U
MK-574-58	INV	Pneu. Damper Actuator	331-2966	ML7474A1007	HW	Elec. Damper Actuator	GBB161.1U/P
MK-693-35	INV	Pneu. Damper Actuator	331-4514	ML7474A1007	HW	Elec. Damper Actuator	GBB166.1U/P
MK-693-55	INV	Pneu. Damper Actuator	331-4814	ML7474A1015	HW	Elec. Damper Actuator	GBB163.1U/P
MK-693-85	INV	Pneu. Damper Actuator	331-4314	ML7474A1015	HW	Elec. Damper Actuator	GBB164.1U/P
ML4195A1001	HW	Elec. Damper Actuator	GCA221.1U				
ML4195C1009	HW	Elec. Damper Actuator	GCA226.1U				

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
Barber Colman/Siebe/
Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
(Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
ML7475A1004	HW	Elec. Damper Actuator	GCA161.1U/P	NF24 US	BL	Elec. Damper Actuator	GMA121.1P
ML7475A1012	HW	Elec. Damper Actuator	GCA163.1U/P	NF24-SR US	BL	Elec. Damper Actuator	GMA161.1P
ML8185A1008	HW	Elec. Damper Actuator	GMA121.1P	NM24 SR	BL	Elec. Damper Actuator 75 lb.-in.	GLB161.1P
ML8185C1006	HW	Elec. Damper Actuator	GMA126.1U	NM24 SR	BL	Elec. Damper Actuator 75 lb.-in.	GLB166.1P
ML8195A1007	HW	Elec. Damper Actuator	GCA121.1U	NM24 US	BL	Elec. Damper Actuator 75 lb.-in.	GLB131.1P
ML8195C1005	HW	Elec. Damper Actuator	GCA126.1U	NM24 US	BL	Elec. Damper Actuator 75 lb.-in.	GLB136.1P
ML8465A1008	HW	Elec. Damper Actuator	GCA121.1U/P	NM24-SR	BL	Elec. Damper Actuator	GLB161.1P
ML8465A1008	HW	Elec. Damper Actuator	GCA126.1U/P	NM24-SRS	BL	Elec. Damper Actuator 75 lb.-in.	GLB163.1P
ML9264A1000	HW	Elec. Damper Actuator	GIB175.1U/P	NM24-SRS	BL	Elec. Damper Actuator 75 lb.-in.	GLB164.1P
MP909D1201	HW	Pneu. Damper Actuator	331-4311	P10BC-7	JC	Pressure Elec. Switch	134-1460
MP909D1219	HW	Pneu. Damper Actuator	331-4811	P10FC-4	JC	Pressure Elec. Switch	251-0008
MP909D1227	HW	Pneu. Damper Actuator	331-4511	P10PA-11	JC	Pressure Elec. Switch	251-0011
MP909D1300	HW	Pneu. Damper Actuator	331-4314	P323-0025	INV	Low Diff. Pressure Transmitter	141-0590
MP909D1318	HW	Pneu. Damper Actuator	331-4814	P323-01	INV	Low Diff. Pressure Transmitter	141-0591
MP909D1334	HW	Pneu. Damper Actuator	331-4514	P323-03	INV	Low Diff. Pressure Transmitter	141-0592
MP909D1359	HW	Pneu. Damper Actuator	331-4314	P323-10	INV	Low Diff. Pressure Transmitter	141-0593
MP909D1441	HW	Pneu. Damper Actuator	331-4511	P341	INV	Pneu. Receiver-Controller	195-0011
MP909E1083	HW	Pneu. Damper Actuator	331-4314	P341	INV	Pneu. Receiver-Controller	195-1000
MP909E1158	HW	Pneu. Damper Actuator	331-4811	P352AB-1C	JC	Controller	RWD82U
MP909E1174	HW	Pneu. Damper Actuator	331-4814	P352PQ-1C	JC	Controller	RWD62U
MP909E1372	HW	Pneu. Damper Actuator	331-4311	P501-2000	INV	Air Velocity Transmitter	141-0582
MP909E1380	HW	Pneu. Damper Actuator	331-4811	P501-3000	INV	Air Velocity Transmitter	141-0583
MP909E1398	HW	Pneu. Damper Actuator	331-4811	P501-4000	INV	Air Velocity Transmitter	141-0584
MP918A1024	HW	Pneu. Damper Actuator	332-3011	P501-5500	INV	Air Velocity Transmitter	141-0585
MP918A1057	HW	Pneu. Damper Actuator	332-3011	P502-50	INV	Diff. Pressure Transmitter	378-2000
MP918A1081	HW	Pneu. Damper Actuator	332-3011	P-5210-1004	JC	Diff. Pressure Transmitter	378-2000
MP918B1006	HW	Pneu. Damper Actuator	331-3013	P-5215-10	JC	Low Diff. Pressure Transmitter	141-0593
MP918B1014	HW	Pneu. Damper Actuator	331-3013	P-5215-6	JC	Low Diff. Pressure Transmitter	141-0590
MP918B1022	HW	Pneu. Damper Actuator	331-3013	P-5215-7	JC	Low Diff. Pressure Transmitter	141-0591
MP918B1030	HW	Pneu. Damper Actuator	331-3013	P-5215-9	JC	Low Diff. Pressure Transmitter	141-0592
MP918B1063	HW	Pneu. Damper Actuator	331-3012	P-5219-1	JC	Air Velocity Transmitter	141-0582
MP918B1071	HW	Pneu. Damper Actuator	331-3012	P-5219-2	JC	Air Velocity Transmitter	141-0583
MP918B1089	HW	Pneu. Damper Actuator	331-3011	P-5219-3	JC	Air Velocity Transmitter	141-0583
MP918B1097	HW	Pneu. Damper Actuator	331-3011	P-5219-4	JC	Air Velocity Transmitter	141-0584
MP918B1105	HW	Pneu. Damper Actuator	331-3011	P-541	INV	Pneu. Receiver-Controller	195-0003
MP918B1113	HW	Pneu. Damper Actuator	331-3011	P-541	INV	Pneu. Receiver-Controller	195-2000
MP918B1196	HW	Pneu. Damper Actuator	331-3011	P541-RA	INV	Pneu. Receiver-Controller	195-0003
MP920B1002	HW	Pneu. Damper Actuator	331-2882	P643A1007	HW	Pressure Elec. Switch	251-0001
MS-6633	INV	Elec. Damper Actuator	GBB151.1U/P	P658A1005	HW	Pressure Elec. Switch	251-0001
MS-6633	INV	Elec. Damper Actuator	GBB156.1U/P	P658A1013	HW	Pressure Elec. Switch	251-0001
MS-6633	INV	Elec. Damper Actuator	GBB161.1U/P	P658A1021	HW	Pressure Elec. Switch	251-0001
MS-6633	INV	Elec. Damper Actuator	GBB166.1U/P	P658B1004	HW	Pressure Elec. Switch	251-0001
N100-4017	INV	Pressure Elec. Switch	251-0004	P658B1012	HW	Pressure Elec. Switch	251-0001
N4-14	INV	Relief Valve	515-0190	P658B1020	HW	Pressure Elec. Switch	251-0001
NF120 US	BL	Elec. Damper Actuator	GMA221.1U	P658C1003	HW	Pressure Elec. Switch	251-0002

AC Accustat	INV Invensys (Robertshaw/ Barber Colman/Siebe/ Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/ Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
PC-110	INV	Pressure Elec. Switch	251-0001	R-516	INV	Reverse-Acting Relay	243-0024
PC-151	INV	Pressure Elec. Switch	251-0011	R532-H	INV	Highest Pressure Relay	243-0018
PC-301	INV	Diff. Static Pressure Air Flow Switch	141-0574	R-532-L	INV	Lowest Pressure Selector	243-0025
PKS-323-01	INV	Low Diff. Pressure Transmitter	141-0591	R-532-L	INV	Lowest Pressure Selector	243-0027
PKS-323-03	INV	Low Diff. Pressure Transmitter	141-0592	R533	INV	High/Low Signal Selector Relay	243-0019
PKS-323-10	INV	Low Diff. Pressure Transmitter	141-0593	RCC-1001	KR	Reverse-Acting Relay	243-0024
PKS-323-25	INV	Low Diff. Pressure Transmitter	141-0590	RCC-1006	KR	Lowest Pressure Selector	243-0029
PKSR-9001	INV	Diff. Pressure Transmitter	378-2000	RCC-1008	KR	Highest Pressure Relay	243-0019
PKSR-9101	INV	Air Velocity Transmitter	141-0582	RCC-1012	KR	Reverse-Acting Relay	243-0024
PKSR-9102	INV	Air Velocity Transmitter	141-0583	RCC-1101	KR	Reverse-Acting Relay	243-0024
PKSR-9103	INV	Air Velocity Transmitter	141-0584	RCC-1106	KR	Lowest Pressure Selector	243-0030
PKSR-9104	INV	Air Velocity Transmitter	141-0585	RCC-1108	KR	Highest Pressure Relay	243-0020
PP901A1004	HW	Pressure Reducing Valves	201-1001	RCC-1112	KR	Reverse-Acting Relay	243-0024
PP901B1002	HW	Pressure Reducing Valves	201-1001	RK-503-2	INV	Switching Relay	243-0001
PP902C1017	HW	Pressure Reducing Valves	908-049	RK-504-1	INV	Switching Relay	243-0001
PP903A1010	HW	Differ. Pressure Transmitter	378-2000	RK-504-2	INV	Switching Relay	243-0001
PP904B1017	HW	Low Diff. Pressure Transmitter	141-0592	RK-516	INV	Reverse-Acting Relay	243-0024
PP905B1008	HW	Low Diff. Pressure Transmitter	141-0593	RK-532-H	INV	Highest Pressure Relay	243-0018
PT973A2209	HW	Pneu. Room Thermostat	192-200	RK-532-L	INV	Lowest Pressure Selector	243-0024
Q539A1014	HW	Low Voltage Room Thermostat	141-0599	RK-533	INV	High/Low Signal Selector Relay	243-0019
Q539A1121	HW	Low Voltage Room Thermostat	141-0599	RKS-1001	INV	Pneu. Receiver-Controller	195-0011
Q539A1469	HW	Low Voltage Room Thermostat	141-0599	RKS-1001	INV	Pneu. Receiver-Controller	195-0011
R-100	AS	Low Voltage Room Thermostat	141-0599	RKS-1001	INV	Pneu. Receiver-Controller	195-1000
R-2090-6	JC	Reverse-Acting Relay	243-0024	RKS-2001	INV	Pneu. Receiver-Controller	195-0011
R-3030-1	JC	Reverse-Acting Relay	243-0024	RKS-2001	INV	Pneu. Receiver-Controller	195-0011
R415	INV	Reverse-Acting Relay	243-0024	RKS-2001	INV	Pneu. Receiver-Controller	195-1000
R416	INV	Reverse-Acting Relay	243-0024	RKS-3002	INV	Pneu. Receiver-Controller	195-0003
R416-1	INV	Reverse-Acting Relay	243-0024	RKS-3002	INV	Pneu. Receiver-Controller	195-0003
R-416-2	INV	Reverse-Acting Relay	243-0024	RKS-3002	INV	Pneu. Receiver-Controller	195-2000
R-427-10	INV	EP Switch	265-1001	RKS-4002	INV	Pneu. Receiver-Controller	195-0003
R-427-20	INV	EP Switch	265-1002	RKS-4002	INV	Pneu. Receiver-Controller	195-0003
R-427-30	INV	EP Switch	265-1003	RKS-4002	INV	Pneu. Receiver-Controller	195-2000
R-427-40	INV	EP Switch	265-1004	RKS-5001	INV	Pneu. Receiver-Controller	195-0011
R-427-50	INV	EP Switch	265-1005	RKS-5001	INV	Pneu. Receiver-Controller	195-0011
R-427-60	INV	EP Switch	265-1006	RKS-5001	INV	Pneu. Receiver-Controller	195-1000
R-432-2	INV	Highest Pressure Relay	243-0018	RKSR-4000	INV	Pneu. Receiver-Controller	195-0003
R-436	INV	Diff. Static Pressure Air Flow Switch	141-0518	RKSR-4000	INV	Pneu. Receiver-Controller	195-0003
R-450-04	INV	Pneu. Step Controller	256-1015	RO49A2	HW	Switching Relay	243-0001
R-450-06	INV	Pneu. Step Controller	256-1015	RO95B	HW	Reverse-Acting Relay	243-0024
R-450-08	INV	Pneu. Step Controller	256-1015	RP2360-151	INV	Reverse-Acting Relay	243-0024
R-450-10	INV	Pneu. Step Controller	256-1015	RP418A1065	HW	EP Switch	265-1006
R471-1	INV	Pressure Elec. Switch	251-0001	RP418A1073	HW	EP Switch	265-1005
R-503-2	INV	Switching Relay	243-0001	RP418A1081	HW	EP Switch	265-1003
R-504-1	INV	Switching Relay	243-0001	RP418A1099	HW	EP Switch	265-1004
R-504-2	INV	Switching Relay	243-0001	RP418A1107	HW	EP Switch	265-1002

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
Barber Colman/Siebe/
Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
(Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
RP418B1063	HW	EP Switch	265-1004	RP920B1049	HW	Pneu. Receiver-Controller	195-2000
RP418B1071	HW	EP Switch	265-1008	RP920B1056	HW	Pneu. Receiver-Controller	195-2000
RP470A1003	HW	Highest Pressure Relay	243-0018	RP920B1056	HW	Pneu. Receiver-Controller	195-2000
RP470A1003	HW	Lowest Pressure Selector	243-0021	RP95B	HW	Reverse-Acting Relay	243-0024
RP470A1011	HW	Highest Pressure Relay	243-0018	RP972A1006	HW	Reverse-Acting Relay	243-0024
RP470A1011	HW	Lowest Pressure Selector	243-0022	RP972A1030	HW	Reverse-Acting Relay	243-0024
RP670A1001	HW	Switching Relay	243-0001	S-224-1	JC	Positioning/Gradual Switch	141-0600
RP670A1019	HW	Switching Relay	243-0001	S-224-1	JC	Positioning/Gradual Switch	151-142
RP670A1027	HW	Switching Relay	243-0001	S-2300-1	JC	Selector/Diverting Switch	786-0500
RP670A1035	HW	Switching Relay	243-0001	S-2300-1	JC	Selector/Diverting Switch	786-0610
RP7517B	HW	Elec. Pneu. Transducer	545-113	S-2300-2	JC	Selector/Diverting Switch	786-0500
RP7517B	HW	Elec. Pneu. Transducer	545-208	S-2300-2	JC	Selector/Diverting Switch	786-0610
RP818A1004	HW	EP Switch	265-1001	S-510	INV	Positioning/Gradual Switch	141-0600
RP818B1002	HW	EP Switch	265-1007	S-510	INV	Positioning/Gradual Switch	151-142
RP904B	HW	Reverse-Acting Relay	243-0024	S-520	INV	Selector/Diverting Switch	786-0600
RP908A1005	HW	Pneu. Receiver-Controller	195-1000	S-530	INV	Selector/Diverting Switch	786-0610
RP908A1005	HW	Pneu. Receiver-Controller	195-1000	SK-510	INV	Positioning/Gradual Switch	151-142
RP908A1013	HW	Pneu. Receiver-Controller	195-1000	SK-515	INV	Positioning/Gradual Switch	151-142
RP908A1013	HW	Pneu. Receiver-Controller	195-1000	SK-520	INV	Selector/Diverting Switch	786-0500
RP908A1021	HW	Pneu. Receiver-Controller	195-1000	SK-521	INV	Selector/Diverting Switch	786-0500
RP908A1021	HW	Pneu. Receiver-Controller	195-1000	SK-530	INV	Selector/Diverting Switch	786-0610
RP908A1039	HW	Pneu. Receiver-Controller	195-1000	SK-531	INV	Selector/Diverting Switch	786-0610
RP908A1039	HW	Pneu. Receiver-Controller	195-1000	SM24 US	BL	Elec. Damper Actuator 133 lb.-in. NSR 3P	GBB171.1U/P
RP908B1003	HW	Pneu. Receiver-Controller	195-2000	SM24 US	BL	Elec. Damper Actuator	GBB175.1U/P
RP908B1003	HW	Pneu. Receiver-Controller	195-2000	SM24-S US	BL	Elec. Damper Actuator	GBB175.1U/P
RP908B1029	HW	Pneu. Receiver-Controller	195-2000	SM24-SR US	BL	Elec. Damper Actuator	GBB151.1U/P
RP908B1029	HW	Pneu. Receiver-Controller	195-2000	SM24-SR US	BL	Elec. Damper Actuator	GBB156.1U/P
RP908B1037	HW	Pneu. Receiver-Controller	195-2000	SM24-SR US	BL	Elec. Damper Actuator	GBB161.1U/P
RP908B1037	HW	Pneu. Receiver-Controller	195-2000	SM24-SR US	BL	Elec. Damper Actuator	GBB163.1U/P
RP908B1037	HW	Pneu. Receiver-Controller	195-2000	SM24-SR US	BL	Elec. Damper Actuator	GBB164.1U/P
RP908B1037	HW	Pneu. Receiver-Controller	195-2000	SM24-SR US	BL	Elec. Damper Actuator	GBB166.1U/P
RP908B1037	HW	Pneu. Receiver-Controller	195-2000	SM24-SRS US	BL	Elec. Damper Actuator	GBB163.1U/P
RP913A1008	HW	High/Low Signal Selector Relay	243-0019	SM24-SRS US	BL	Elec. Damper Actuator	GBB164.1U/P
RP920A1025	HW	Pneu. Receiver-Controller	195-1000	SP-30600	INV	Pneu. Step Controller	256-1015
RP920A1025	HW	Pneu. Receiver-Controller	195-1000	SP-31000	INV	Pneu. Step Controller	256-1015
RP920A1033	HW	Pneu. Receiver-Controller	195-1000	SP470A1000	HW	Selector/Diverting Switch	786-0500
RP920A1033	HW	Pneu. Receiver-Controller	195-1000	SP470A1000	HW	Selector/Diverting Switch	786-0520
RP920A1041	HW	Pneu. Receiver-Controller	195-1000	SP470A1000	HW	Selector/Diverting Switch	786-0600
RP920A1041	HW	Pneu. Receiver-Controller	195-1000	SP470A1018	HW	Selector/Diverting Switch	786-0500
RP920A1058	HW	Pneu. Receiver-Controller	195-1000	SP470A1018	HW	Selector/Diverting Switch	786-0520
RP920A1058	HW	Pneu. Receiver-Controller	195-1000	SP470A1018	HW	Selector/Diverting Switch	786-0610
RP920B1023	HW	Pneu. Receiver-Controller	195-2000	SP470A1018	HW	Selector/Diverting Switch	786-0610
RP920B1023	HW	Pneu. Receiver-Controller	195-2000	SP470A1026	HW	Selector/Diverting Switch	786-0500
RP920B1031	HW	Pneu. Receiver-Controller	195-2000	SP470A1026	HW	Selector/Diverting Switch	786-0520
RP920B1031	HW	Pneu. Receiver-Controller	195-2000	SP470A1026	HW	Selector/Diverting Switch	786-0600
RP920B1049	HW	Pneu. Receiver-Controller	195-2000				

AC Accustat	INV Invensys (Robertshaw/ Barber Colman/Siebe/ Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/ Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
SP470A1034	HW	Selector/Diverting Switch	786-0500	T19-3011	INV	Pneu. Room Thermostat	192-203
SP470A1034	HW	Selector/Diverting Switch	786-0520	T201	INV	Elec. Room Thermostat	RAA40U
SP470A1034	HW	Selector/Diverting Switch	786-0610	T-205-MAH-2	JC	Low Voltage Room Thermostat	141-0599
SP470B1008	HW	Selector/Diverting Switch	786-0500	T-205MAH-3	JC	Low Voltage Room Thermostat	141-0599
SP470B1008	HW	Selector/Diverting Switch	786-0520	T-210-AH-22	JC	Low Voltage Room Thermostat	141-0596
SP470B1008	HW	Selector/Diverting Switch	786-0600	T22-ABC-3	JC	Line Voltage Room Thermostat	134-1083
SP470B1016	HW	Selector/Diverting Switch	786-0500	T22SDA-1	JC	Elec. Room Thermostat	RAA30U
SP470B1016	HW	Selector/Diverting Switch	786-0520	T22SEB-1	JC	Elec. Room Thermostat	RAA40U
SP470B1016	HW	Selector/Diverting Switch	786-0610	T22SFB-1	JC	Elec. Room Thermostat	RAA40U
SP955A1046	HW	Pneu. Step Controller	256-1015	T-23-301	INV	Pneu. Room Thermostat	192-204
SP970A	LS	Positioning/Gradual Switch	141-0600	T-23-3011	INV	Pneu. Room Thermostat	192-204
SQB12.1	LS	Elec. Damper Actuator	GCA221.1U	T23A-1	JC	Elec. Room Thermostat	RAB10U
SQB12.1	LS	Elec. Damper Actuator	GCA226.1U	T23A-1	JC	Two-pipe Heat-Off-Cool Lo-Med-High	RCC10U
SQB61.1	LS	Elec. Damper Actuator	GCA161.1U/P	T23B-1	JC	Elec. Room Thermostat	RAB20U
SQB72.1	LS	Elec. Damper Actuator	GCA121.1U/P	T23B-1	JC	Two-pipe Auto-Off Lo-Med-High	RCC10U
SQB72.1	LS	Elec. Damper Actuator	GCA126.1U/P	T-24-301	INV	Pneu. Room Thermostat	192-205
SQR65.1	LS	Elec. Damper Actuator	GBB161.1U/P	T-24-3011	INV	Pneu. Room Thermostat	192-205
SQR65.1	LS	Elec. Damper Actuator	GBB166.1U/P	T26S-18	JC	Line Voltage Room Thermostat	134-1084
SQR85.1	LS	Elec. Damper Actuator	GBB171.1U/P	T26S-18	JC	Elec. Room Thermostat	RAA20U
SQR85.1	LS	Elec. Damper Actuator	GBB175.1U/P	T26T-3	JC	Line Voltage Room Thermostat	134-1085
T12-2011	INV	Pneu. Room Thermostat	192-200	T26T-3	JC	Elec. Room Thermostat	RAA20U
T-12-301	INV	Pneu. Room Thermostat	192-200	T-27-301	INV	Pneu. Room Thermostat	192-206
T-12-3011	INV	Pneu. Room Thermostat	192-200	T-27-3011	INV	Pneu. Room Thermostat	192-206
T-12-3081	INV	Pneu. Room Thermostat	192-200	T28AA-1	JC	Elec. Room Thermostat	RAA20U
T-13-301	INV	Pneu. Room Thermostat	192-201	T28BA-1	JC	Elec. Room Thermostat	RAA20U
T-13-3011	INV	Pneu. Room Thermostat	192-201	T28BB-1	JC	Elec. Room Thermostat	RAA30U
T-13-3081	INV	Pneu. Room Thermostat	192-201	T28BD-1	JC	Elec. Room Thermostat	RAB10U
T150-1011	INV	Temp. Transmitter	184-0001	T28BD-1	JC	Two-pipe, cooling only Off-Hi-Med-Low	RCC10U
T150-1012	INV	Temp. Transmitter	184-0004	T28CD-1	JC	Elec. Room Thermostat	RAB20U
T150-1021	INV	Temp. Transmitter	184-0028	T28CD-1	JC	Two-pipe Off-Hi-Med-Low	RCC10U
T150-1023	INV	Temp. Transmitter	184-0048	T28DA-1	JC	Four-pipe Off-Hi-Med-Low Free Energy Band	RCC30U
T150-1054	INV	Temp. Transmitter	184-0005	T28DD-1	JC	Four-pipe Off-Hi-Med-Low Free Energy Band	RCC30U
T15-101	INV	Pneu. Room Thermostat	192-202	T28DG-1	JC	Four-pipe Off-Hi-Med-Low Free Energy Band	RCC30U
T16-101	INV	Pneu. Room Thermostat	192-203	T301	INV	High Temp. Limit Thermostat	141-0530
T18-101	INV	Pneu. Room Thermostat	192-202	T-3100-2	JC	Unit Mount Thermostat	188-0031
T18-201	INV	Pneu. Room Thermostat	192-202	T-3100-3	JC	Unit Mount Thermostat	188-0024
T-18-301	INV	Pneu. Room Thermostat	192-202	T-32-301	INV	Pneu. Room Thermostat	192-208
T-18-3011	INV	Pneu. Room Thermostat	192-202	T-32-3011	INV	Pneu. Room Thermostat	192-208
T-18-305	INV	Pneu. Room Thermostat	192-202	T-32-321	INV	Pneu. Room Thermostat	192-208
T-18-306	INV	Pneu. Room Thermostat	192-202	T-32-321	INV	Pneu. Room Thermostat	194-3082
T-18-3081	INV	Pneu. Room Thermostat	192-202	T-3300-2	JC	Unit Mount Thermostat	188-0034
T-18-3091	INV	Pneu. Room Thermostat	192-202	T-33-301	INV	Pneu. Room Thermostat	192-209
T19-101	INV	Pneu. Room Thermostat	192-203	T-34-3011	INV	Pneu. Room Thermostat	192-208
T19-201	INV	Pneu. Room Thermostat	192-203				
T19-301	INV	Pneu. Room Thermostat	192-203				

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
T-35-301	INV	Pneu. Room Thermostat	193-215	T-4506-6204	JC	Pneu. Room Thermostat	194-2043
T-4002-201	JC	Pneu. Room Thermostat	192-202	T-4506-6209	JC	Pneu. Room Thermostat	194-2053
T-4002-202	JC	Pneu. Room Thermostat	192-203	T-4506-6209	JC	Pneu. Room Thermostat	194-3053
T-4002-203	JC	Pneu. Room Thermostat	192-202	T-4506-6217	JC	Pneu. Room Thermostat	194-2053
T-4002-204	JC	Pneu. Room Thermostat	192-203	T-4506-6217	JC	Pneu. Room Thermostat	194-3053
T-4004.A.	JC	Pneu. Room Thermostat	192-200	T-4516-201	JC	Pneu. Room Thermostat	192-206
T-4004-207	JC	Pneu. Room Thermostat	192-201	T-4516-202	JC	Pneu. Room Thermostat	192-206
T4039A1000	HW	Elec. Room Thermostat	RAA30U	T-4516-6201	JC	Pneu. Room Thermostat	192-206
T4039A1008	HW	Two-pipe, cooling only On-Off Off-Hi-Med-Low	RCC10U	T-4516-6202	JC	Pneu. Room Thermostat	192-206
T4039B1008	HW	Elec. Room Thermostat	RAB20U	T-4552-201	JC	Pneu. Room Thermostat	192-209
T4039B1008	HW	Two-pipe cooling only On-Off Off-Hi-Med-Low	RCC10U	T-4576-217	JC	Pneu. Room Thermostat	192-208
T4039D1004	HW	Elec. Room Thermostat	RAA40U	T-4576-217	JC	Pneu. Room Thermostat	194-3083
T4039E1001	HW	Elec. Room Thermostat	RAB20U	T-4600-1	JC	Pneu. Room Thermostat	193-211
T4039F1009	HW	Two-pipe Off-Hi-Med-Low	RCC10U	T-4600-3	JC	Pneu. Room Thermostat	193-231
T-4054-1	JC	Pneu. Room Thermostat	193-215	T-4600-5	JC	Pneu. Room Thermostat	193-212
T-4054-2	JC	Pneu. Room Thermostat	193-218	T-4600-6	JC	Pneu. Room Thermostat	193-232
T-4100-1	JC	Pneu. Room Thermostat	192-200	T-4600-6001	JC	Pneu. Room Thermostat	193-211
T-4100-2	JC	Pneu. Room Thermostat	192-201	T-4600-6003	JC	Pneu. Room Thermostat	193-231
T-4100-3	JC	Pneu. Room Thermostat	192-220	T-4600-6005	JC	Pneu. Room Thermostat	193-212
T-4100-4	JC	Pneu. Room Thermostat	192-221	T-4600-6006	JC	Pneu. Room Thermostat	193-232
T-4100-6001	JC	Pneu. Room Thermostat	192-200	T46ADH-1	JC	Elec. Room Thermostat	RAA30U
T-4100-6002	JC	Pneu. Room Thermostat	192-201	T46SAA-1	JC	Elec. Room Thermostat	RAB30U
T-4100-6003	JC	Pneu. Room Thermostat	192-220	T46SAA-1	JC	Two-pipe Heat-Off-Cool Low-Med-Hi	RCC10U
T-4100-6004	JC	Pneu. Room Thermostat	192-221	T46SAH-1	JC	Elec. Room Thermostat	RAA40U
T-410PC-2000	JC	Low Voltage Room Thermostat	141-0597	T-4752-201	JC	Pneu. Room Thermostat	192-209
T-4502-217	JC	Pneu. Room Thermostat	194-3053	T-4752-202	JC	Pneu. Room Thermostat	192-209
T-4506-201	JC	Pneu. Room Thermostat	192-206	T-4752-205	JC	Pneu. Room Thermostat	192-208
T-4506-201	JC	Pneu. Room Thermostat	194-2043	T-4752-205	JC	Pneu. Room Thermostat	194-3083
T-4506-201	JC	Pneu. Room Thermostat	194-3043	T-4752-206	JC	Pneu. Room Thermostat	192-208
T-4506-202	JC	Pneu. Room Thermostat	192-206	T-4752-206	JC	Pneu. Room Thermostat	194-3083
T-4506-202	JC	Pneu. Room Thermostat	194-2043	T-4756-201	JC	Pneu. Room Thermostat	192-209
T-4506-202	JC	Pneu. Room Thermostat	194-3043	T-4756-205	JC	Pneu. Room Thermostat	192-208
T-4506-202	JC	Pneu. Room Thermostat	194-3043	T-4756-205	JC	Pneu. Room Thermostat	194-3083
T-4506-202	JC	Pneu. Room Thermostat	194-3043	T-4756-206	JC	Pneu. Room Thermostat	192-208
T-4506-203	JC	Pneu. Room Thermostat	194-2043	T-4756-206	JC	Pneu. Room Thermostat	194-3083
T-4506-203	JC	Pneu. Room Thermostat	194-3043	T500HCN-1	JC	Single stage heat/cool	RDX42.22U
T-4506-204	JC	Pneu. Room Thermostat	194-2043	T-5002-201	JC	Temp. Transmitter	184-0127
T-4506-204	JC	Pneu. Room Thermostat	194-3043	T-5002-202	JC	Temp. Transmitter	184-0340
T-4506-209	JC	Pneu. Room Thermostat	194-2053	T511	INV	Elec. Room Thermostat	RAB20U
T-4506-209	JC	Pneu. Room Thermostat	194-3053	T511	INV	Two-pipe On-Off Hi-Med-Lo	RCC10U
T-4506-217	JC	Pneu. Room Thermostat	194-2053	T511F	INV	Elec. Room Thermostat	RAB20U
T-4506-217	JC	Pneu. Room Thermostat	194-3053	T511F	INV	Two-pipe On-Off Hi-Med-Lo	RCC10U
T-4506-6201	JC	Pneu. Room Thermostat	194-2043	T513	INV	Elec. Room Thermostat	RAB30U
T-4506-6202	JC	Pneu. Room Thermostat	194-2043	T513	INV	Four-pipe Heat-Off-Cool Hi-Med-Lo Free Energy Band	RCC30U
T-4506-6203	JC	Pneu. Room Thermostat	194-2043				

AC Accustat	INV Invensys (Robertshaw/Barber Colman/Siebe/Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/ Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
T513F	INV	Elec. Room Thermostat	RAB30U	T694B2001	HW	Elec. Room Thermostat	RAB30U
T513F	INV	Four-pipe Heat-Off-Cool Hi-Med-Lo Free Energy Band	RCC30U	T694M2009	HW	Low Voltage Room Thermostat	141-0599
T51JC-1	JC	Elec. Room Thermostat	RAA20U	T694M2017	HW	Low Voltage Room Thermostat	141-0599
T51JF-1	JC	Elec. Room Thermostat	RAA20U	T7600A1000	V	One stage heat/cool	RDX42.22U
T-5210-1001	JC	Temp. Transmitter	184-0002	T775A1001	HW	Controller	RWD82U
T-5210-1002	JC	Temp. Transmitter	184-0123	T775A1019	HW	Controller	RWD82U
T-5210-1004	JC	Temp. Transmitter	184-0003	T775A1027	HW	Controller	RWD44U
T-5210-1004	JC	Temp. Transmitter	184-0122	T775A1035	HW	Controller	RWD44U
T-5210-1007	JC	Temp. Transmitter	184-0004	T775B1000	HW	Controller	RWD82U
T-5210-1007	JC	Temp. Transmitter	184-0129	T775B1018	HW	Controller	RWD44U
T-5210-1009	JC	Temp. Transmitter	184-0048	T775B1026	HW	Controller	RWD44U
T-5210-1009	JC	Temp. Transmitter	184-0125	T775J1001	HW	Controller	RWD82U
T-5210-1113	JC	Temp. Transmitter	184-0124	T775J1035	HW	Controller	RWD62U
T-5210-1114	JC	Temp. Transmitter	184-0036	T775J1068	HW	Controller	RWD45U
T-5210-1118	JC	Temp. Transmitter	184-0048	T775J1076	HW	Controller	RWD82U
T-5210-1151	JC	Temp. Transmitter	184-0005	T810B1039	HW	Elec. Room Thermostat	RAA20U
T-5210-2001	JC	Temp. Transmitter	184-0002	T810C1004	HW	Elec. Room Thermostat	RAA20U
T-5210-2003	JC	Temp. Transmitter	184-0028	T810D1003	HW	Elec. Room Thermostat	RAA20U
T-5210-2005	JC	Temp. Transmitter	184-0036	T810D1011	HW	Elec. Room Thermostat	RAA20U
T52JC-1	JC	Elec. Room Thermostat	RAB20U	T810D1136	HW	Elec. Room Thermostat	RAA20U
T52JF-1	JC	Elec. Room Thermostat	RAB20U	T822C1090	HW	Elec. Room Thermostat	RAA20U
T52KC-1	JC	Elec. Room Thermostat	RAB30U	T822D1024	HW	Elec. Room Thermostat	RAA20U
T52KF-1	JC	Elec. Room Thermostat	RAB30U	T822D1032	HW	Elec. Room Thermostat	RAA20U
T53-101	INV	Temp. Transmitter	184-0129	T822D1255	HW	Elec. Room Thermostat	RAA20U
T-5500-1051	JC	Receiver Gauge	142-0284	T822D1685	HW	Elec. Room Thermostat	RAA20U
T-5500-1053	JC	Receiver Gauge	142-0444	T822D1693	HW	Elec. Room Thermostat	RAA20U
T-5500-1054	JC	Receiver Gauge	142-0442	T822D1719	HW	Elec. Room Thermostat	RAA20U
T-5500-1055	JC	Receiver Gauge	142-0443	T822D2550	HW	Elec. Room Thermostat	RAA20U
T-5502-1001	JC	Receiver Gauge	142-0262	T822G1005	HW	Elec. Room Thermostat	RAA20U
T-5502-1002	JC	Receiver Gauge	142-0327	T827B1009	HW	Elec. Room Thermostat	RAA20U
T-5502-1003	JC	Receiver Gauge	142-0438	T834C1137	HW	Low Voltage Room Thermostat	141-0599
T-5502-1004	JC	Receiver Gauge	142-0436	T834C2309	HW	Low Voltage Room Thermostat	141-0599
T-5502-1005	JC	Receiver Gauge	142-0437	T8381A1005	HW	Elec. Room Thermostat	RAB20U
T5800-1	JC	Pneu. Receiver-Controller	195-0011	T8381B1003	HW	Elec. Room Thermostat	RAB30U
T5800-1	JC	Pneu. Receiver-Controller	195-1000	T8383B1001	HW	Elec. Room Thermostat	RAB30U
T5800-3	JC	Pneu. Receiver-Controller	195-0003	T8400C	HW	Single stage heat/cool	RDX42.22U
T5800-3	JC	Pneu. Receiver-Controller	195-2000	T8411R	HW	Heat Pump	RDX42.22U
T6051A1056	HW	Elec. Room Thermostat	RAA20U	T841A1316	HW	Low Voltage Room Thermostat	141-0596
T6381A1009	HW	Elec. Room Thermostat	RAB20U	T8501	HW	Single stage heat/cool	RDX42.22U
T6381B1007	HW	Elec. Room Thermostat	RAB30U	T8501D	HW	Heating and Cooling Systems	RDX42.22U
T6383B1005	HW	Elec. Room Thermostat	RAB30U	T8511G	HW	Heat Pump	RDX42.22U
T6387A1003	HW	Elec. Room Thermostat	RAB20U	T-8624D1006	HW	Low Voltage Room Thermostat	141-0597
T675A	HW	Elec. Line Voltage Bulb Thermostat	141-0520	T-8624D1030	HW	Low Voltage Room Thermostat	141-0597
T694A2002	HW	Elec. Room Thermostat	RAB10U	T874D1165	HW	Low Voltage Room Thermostat	141-0596
				T874D1223	HW	Low Voltage Room Thermostat	141-0596

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Sieba/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
T874E1016	HW	Low Voltage Room Thermostat	141-0596	TK-1001-116	INV	Pneu. Room Thermostat	192-222
T874F1015	HW	Low Voltage Room Thermostat	141-0596	TK-1001-116	INV	Pneu. Room Thermostat	192-222
T87F1826	HW	Low Voltage Room Thermostat	141-0599	TK-1001-600	INV	Pneu. Room Thermostat	192-202
T87F2816	HW	Elec. Room Thermostat	RAA20U	TK-1002	INV	Pneu. Room Thermostat	192-222
T87F2824	HW	Elec. Room Thermostat	RAA20U	TK-1101	INV	Pneu. Room Thermostat	192-203
TA-1101	INV	Elec. Room Thermostat	RAA20U	TK-1101	INV	Pneu. Room Thermostat	192-203
TA-1102	INV	Elec. Room Thermostat	RAA20U	TK-1101-116	INV	Pneu. Room Thermostat	192-203
TA-121	INV	Elec. Room Thermostat	RAA20U	TK-1101-116	INV	Pneu. Room Thermostat	192-223
TA155-010	INV	Elec. Room Thermostat	RAB30U	TK-1101-600	INV	Pneu. Room Thermostat	192-203
A155-010	INV	Four-pipe Heat-Off-Cool Hi-Med-Lo Free Energy Band	RCC30U	TK-1102	INV	Pneu. Room Thermostat	192-203
TA155-017	INV	Elec. Room Thermostat	RAB20U	TK12	INV	Pneu. Room Thermostat	192-200
TTA155-017	INV	Two-pipe On-Off Hi-Med-Lo	RCC10U	TK12-1	INV	Pneu. Room Thermostat	192-200
TA-3434	INV	High Temp. Limit Thermostat	141-0530	TK-13	INV	Pneu. Room Thermostat	192-201
TAYSTAT570	T	Heat Pump	RDX42.22U	TK-1301	INV	Pneu. Room Thermostat	194-2043
TAR-1101	INV	Elec. Room Thermostat	RAA20U	TK-1301	INV	Pneu. Room Thermostat	194-3043
TB155-010	INV	Four-pipe On-Off Hi-Med-Lo Free Energy Band	RCC30U	TK-1301-116	INV	Pneu. Room Thermostat	194-2043
TB158-002	INV	Four-pipe Off-Auto-Heat-Cool Off-Hi-Med-Low Free Energy Band	RCC30U	TK-1301-185	INV	Pneu. Room Thermostat	194-3043
TB158-017	INV	Four-pipe Fan Coil	RDX42.22U	TK-1301-185	INV	Pneu. Room Thermostat	194-2143
TC-1101	INV	Elec. Room Thermostat	RAA20U	TK-1381	INV	Pneu. Room Thermostat	194-3143
TC-114	INV	Low Voltage Room Thermostat	141-0599	TK-1381	INV	Pneu. Room Thermostat	194-2053
TC-114	INV	Elec. Room Thermostat	RAA20U	TK-1381-185	INV	Pneu. Room Thermostat	194-3053
TC-114	INV	Elec. Room Thermostat	RAA20U	TK-1381-185	INV	Pneu. Room Thermostat	194-2153
TC-114-770	INV	Elec. Room Thermostat	RAA20U	TK-1601	INV	Pneu. Room Thermostat	194-3153
TC-114-770	INV	Low Voltage Room Thermostat	141-0599	TK-1601-116	INV	Pneu. Room Thermostat	192-206
TC-186	INV	Elec. Room Thermostat	RAB10U	TK-1727	INV	Pneu. Room Thermostat	192-206
TC-187	INV	Elec. Room Thermostat	RAB10U	TK-1727	INV	Pneu. Room Thermostat	192-226
TC-195	INV	Elec. Room Thermostat	RAA20U	TK-1727-116	INV	Pneu. Room Thermostat	192-210
TC-195-770	INV	Elec. Room Thermostat	RAA20U	TK-1736	INV	Pneu. Room Thermostat	192-210
TC-202	INV	Controller	RWD82U	TK-1736	INV	Pneu. Room Thermostat	192-230
TC-252	INV	Controller	RWD82U	TK-1741	INV	Pneu. Room Thermostat	192-208
TC-282	INV	Controller	RWD44U	TK-1741	INV	Pneu. Room Thermostat	194-3083
TC-282-20	INV	Controller	RWD44U	TK-1741	INV	Pneu. Room Thermostat	192-208
TC-288	INV	Controller	RWD44U	TK-1741	INV	Pneu. Room Thermostat	192-209
TC-2974	INV	High Temp. Limit Thermostat	141-0519	TK-1741	INV	Pneu. Room Thermostat	193-216
TC-4111	INV	Elec. Line Voltage Bulb Thermostat	141-0520	TK-1741	INV	Pneu. Room Thermostat	194-3083
TC-4416	INV	Controller	RWD82U	TK-1741-116	INV	Pneu. Room Thermostat	194-3083
TC-5131	INV	Low Temp. Detection Thermostat	134-1510	TK-1741-116	INV	Pneu. Room Thermostat	192-228
TC-5131	INV	Low Temp. Detection Thermostat	134-1510	TK-1741-600	INV	Pneu. Room Thermostat	192-229
TC5141	INV	Low Temp. Detection Thermostat	134-1511	TK-18	INV	Pneu. Room Thermostat	193-236
TC5141	INV	Low Temp. Detection Thermostat	134-1511	TK-1801	INV	Pneu. Room Thermostat	192-208
TDIAP502730	HW	Diff. Static Pressure Air Flow Switch	141-0518	TK-1801-116	INV	Pneu. Room Thermostat	192-202
TK-1001	INV	Pneu. Room Thermostat	192-202	TK-1811	INV	Pneu. Room Thermostat	193-215
TK-1001	INV	Pneu. Room Thermostat	192-202	TK-1811	INV	Pneu. Room Thermostat	193-235
							193-218
							193-218

AC Accustat	INV Invensys (Robertshaw/Barber Colman/Siebe/Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/ Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
TK-1811-116	INV	Pneu. Room Thermostat	193-238	TKR-5001-116	INV	Pneu. Room Thermostat	192-220
TK-1811-116	INV	Pneu. Room Thermostat	193-238	TKR-5101	INV	Pneu. Room Thermostat	192-201
TK-19	INV	Pneu. Room Thermostat	192-203	TKR-5101-116	INV	Pneu. Room Thermostat	192-221
TK-19-1	INV	Pneu. Room Thermostat	192-203	TKS-4014	INV	Temp. Transmitter	184-0048
TK-23	INV	Pneu. Room Thermostat	192-204	TKS-4017	INV	Temp. Transmitter	184-0004
TK-23-1	INV	Pneu. Room Thermostat	192-204	TKS-5001	INV	Temp. Transmitter	184-0340
TK-24	INV	Pneu. Room Thermostat	192-205	TKS-8014	INV	Temp. Transmitter	184-0028
TK-24-1	INV	Pneu. Room Thermostat	192-205	TKS-8033	INV	Temp. Transmitter	184-0003
TK-27	INV	Pneu. Room Thermostat	192-206	TO900A	HW	Pneu. Room Thermostat	192-202
TK-27-1	INV	Pneu. Room Thermostat	192-206	TO901A	HW	Pneu. Room Thermostat	192-202
TK-3001	INV	Unit Mount Thermostat	188-0031	TO901B	HW	Pneu. Room Thermostat	192-201
TK-3001	INV	Room and Duct Hygrostat	188-0031	TO901B	HW	Pneu. Room Thermostat	192-203
TK-32	INV	Pneu. Room Thermostat	192-208	TO91A	HW	Pneu. Room Thermostat	192-202
TK-3201	INV	Room and Duct Hygrostat	188-0034	TO931B	HW	Pneu. Room Thermostat	192-202
TK-32-1	INV	Pneu. Room Thermostat	192-208	TO93A	HW	Pneu. Room Thermostat	192-202
TK-32-321	INV	Pneu. Room Thermostat	192-208	TO93C	HW	Pneu. Room Thermostat	192-203
TK-32-321	INV	Pneu. Room Thermostat	194-3082	TP900A	HW	Pneu. Room Thermostat	192-202
TK-33	INV	Pneu. Room Thermostat	192-209	TP901B	HW	Pneu. Room Thermostat	192-201
TK-35	INV	Pneu. Room Thermostat	193-215	TP901C	HW	Pneu. Room Thermostat	192-200
TK-36	INV	Pneu. Room Thermostat	193-218	TP910A	HW	Pneu. Room Thermostat	192-202
TK-5001	INV	Pneu. Room Thermostat	192-200	TP910B	HW	Pneu. Room Thermostat	192-203
TK-5001-116	INV	Pneu. Room Thermostat	192-220	TP923A	HW	Pneu. Room Thermostat	192-200
TK-5002	INV	Pneu. Room Thermostat	192-200	TP923B	HW	Pneu. Room Thermostat	192-201
TK-50501	INV	Pneu. Room Thermostat	193-211	TP931B	HW	Pneu. Room Thermostat	192-202
TK-50511	INV	Pneu. Room Thermostat	193-212	TP932B	HW	Pneu. Room Thermostat	192-201
TK-5101	INV	Pneu. Room Thermostat	192-201	TP93A	HW	Pneu. Room Thermostat	192-202
TK-5101-116	INV	Pneu. Room Thermostat	192-221	TP9702008	HW	Pneu. Room Thermostat	192-203
TK-5102	INV	Pneu. Room Thermostat	192-201	TP970A1002	HW	Pneu. Room Thermostat	192-202
TK-51501	INV	Pneu. Room Thermostat	193-213	TP970A1004	HW	Pneu. Room Thermostat	192-202
TK-51511	INV	Pneu. Room Thermostat	193-214	TP970A1012	HW	Pneu. Room Thermostat	192-202
TK-6024	INV	Unit Mount Thermostat	188-0032	TP970A1038	HW	Pneu. Room Thermostat	192-202
TK-6124	INV	Unit Mount Thermostat	188-0024	TP970A1053	HW	Pneu. Room Thermostat	192-202
TKR-1001	INV	Pneu. Room Thermostat	192-202	TP970A1061	HW	Pneu. Room Thermostat	192-202
TKR-1001-116	INV	Pneu. Room Thermostat	192-202	TP970A2004	HW	Pneu. Room Thermostat	192-202
TKR-1101	INV	Pneu. Room Thermostat	192-203	TP970A2012	HW	Pneu. Room Thermostat	192-202
TKR-1101-116	INV	Pneu. Room Thermostat	192-223	TP970A2020	HW	Pneu. Room Thermostat	192-222
TKR-12	INV	Pneu. Room Thermostat	192-200	TP970A2038	HW	Pneu. Room Thermostat	192-202
TKR-13	INV	Pneu. Room Thermostat	192-201	TP970A2053	HW	Pneu. Room Thermostat	192-202
TKR-13-1	INV	Pneu. Room Thermostat	192-201	TP970A2087	HW	Pneu. Room Thermostat	192-202
TKR-1601	INV	Pneu. Room Thermostat	192-206	TP970A2095	HW	Pneu. Room Thermostat	192-202
TKR-18	INV	Pneu. Room Thermostat	192-202	TP970A2129	HW	Pneu. Room Thermostat	192-202
TKR-18-91	INV	Pneu. Room Thermostat	192-202	TP970A2145	HW	Pneu. Room Thermostat	192-202
TKR-19	INV	Pneu. Room Thermostat	192-203	TP970A2190	HW	Pneu. Room Thermostat	192-203
TKR-19-91	INV	Pneu. Room Thermostat	192-203	TP970A2242	HW	Pneu. Room Thermostat	192-202
TKR-5001	INV	Pneu. Room Thermostat	192-200	TP970A2267	HW	Pneu. Room Thermostat	192-202

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
Barber Colman/Sieba/
Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
(Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
TP970A2275	HW	Pneu. Room Thermostat	192-202	TP971B2001	HW	Pneu. Room Thermostat	192-205
TP970B1002	HW	Pneu. Room Thermostat	192-203	TP971B2001	HW	Pneu. Room Thermostat	194-3052
TP970B1028	HW	Pneu. Room Thermostat	192-203	TP971B2019	HW	Pneu. Room Thermostat	192-205
TP970B1036	HW	Pneu. Room Thermostat	192-203	TP971B2019	HW	Pneu. Room Thermostat	194-3052
TP970B1044	HW	Pneu. Room Thermostat	192-203	TP971B2043	HW	Pneu. Room Thermostat	192-205
TP970B2002	HW	Pneu. Room Thermostat	192-203	TP971B2043	HW	Pneu. Room Thermostat	194-3052
TP970B2010	HW	Pneu. Room Thermostat	192-223	TP971B2068	HW	Pneu. Room Thermostat	194-2052
TP970B2028	HW	Pneu. Room Thermostat	192-203	TP971B2068	HW	Pneu. Room Thermostat	194-3052
TP970B2036	HW	Pneu. Room Thermostat	192-203	TP971B2074	HW	Pneu. Room Thermostat	194-2052
TP970B2069	HW	Pneu. Room Thermostat	192-203	TP971B2074	HW	Pneu. Room Thermostat	194-3052
TP970B2077	HW	Pneu. Room Thermostat	192-203	TP971C1009	HW	Pneu. Room Thermostat	192-206
TP970B2166	HW	Pneu. Room Thermostat	192-203	TP971C1025	HW	Pneu. Room Thermostat	192-206
TP970B2182	HW	Pneu. Room Thermostat	192-203	TP971C2009	HW	Pneu. Room Thermostat	192-206
TP970B2208	HW	Pneu. Room Thermostat	192-203	TP971C2025	HW	Pneu. Room Thermostat	192-206
TP970C1000	HW	Pneu. Room Thermostat	193-213	TP971C2058	HW	Pneu. Room Thermostat	192-206
TP970C2000	HW	Pneu. Room Thermostat	192-202	TP972A2036	HW	Pneu. Room Thermostat	192-208
TP971A1003	HW	Pneu. Room Thermostat	194-2042	TP972A2036	HW	Pneu. Room Thermostat	194-3082
TP971A1003	HW	Pneu. Room Thermostat	194-3042	TP972A2168	HW	Pneu. Room Thermostat	192-207
TP971A1029	HW	Pneu. Room Thermostat	194-2042	TP972A2176	HW	Pneu. Room Thermostat	192-208
TP971A1029	HW	Pneu. Room Thermostat	194-3042	TP972A2218	HW	Pneu. Room Thermostat	192-208
TP971A1037	HW	Pneu. Room Thermostat	194-2042	TP972A2219	HW	Pneu. Room Thermostat	194-3082
TP971A1037	HW	Pneu. Room Thermostat	194-3042	TP973A1068	HW	Pneu. Room Thermostat	192-200
TP971A1045	HW	Pneu. Room Thermostat	192-200	TP973A1076	HW	Pneu. Room Thermostat	192-200
TP971A1045	HW	Pneu. Room Thermostat	194-2042	TP973A1092	HW	Pneu. Room Thermostat	192-200
TP971A1045	HW	Pneu. Room Thermostat	194-3042	TP973A2068	HW	Pneu. Room Thermostat	192-200
TP971A1086	HW	Pneu. Room Thermostat	194-2042	TP973A2076	HW	Pneu. Room Thermostat	192-200
TP971A1086	HW	Pneu. Room Thermostat	194-3042	TP973A2092	HW	Pneu. Room Thermostat	192-200
TP971A2003	HW	Pneu. Room Thermostat	194-2042	TP973A2215	HW	Pneu. Room Thermostat	192-200
TP971A2003	HW	Pneu. Room Thermostat	194-3042	TP973B1006	HW	Pneu. Room Thermostat	192-201
TP971A2029	HW	Pneu. Room Thermostat	192-204	TP973B1066	HW	Pneu. Room Thermostat	192-201
TP971A2037	HW	Pneu. Room Thermostat	194-2042	TP973B2066	HW	Pneu. Room Thermostat	192-201
TP971A2037	HW	Pneu. Room Thermostat	194-3042	TP973B2171	HW	Pneu. Room Thermostat	192-201
TP971A2045	HW	Pneu. Room Thermostat	192-204	TP973B2189	HW	Pneu. Room Thermostat	192-201
TP971A2086	HW	Pneu. Room Thermostat	192-204	TP974A1000	HW	Temp. Transmitter	184-0126
TP971A2102	HW	Pneu. Room Thermostat	194-2042	TP974A2000	HW	Temp. Transmitter	184-0126
TP971A2102	HW	Pneu. Room Thermostat	194-3042	TP978A1006	HW	Pneu. Room Thermostat	193-213
TP971A2183	HW	Pneu. Room Thermostat	194-2042	TP979A2005	HW	Pneu. Room Thermostat	193-215
TP971A2183	HW	Pneu. Room Thermostat	194-3042	TP979A2013	HW	Pneu. Room Thermostat	193-215
TP971A2191	HW	Pneu. Room Thermostat	194-2052	TP979B2003	HW	Pneu. Room Thermostat	193-218
TP971A2191	HW	Pneu. Room Thermostat	194-3052	TP979C2001	HW	Pneu. Room Thermostat	193-216
TP971A2209	HW	Pneu. Room Thermostat	194-2042	TP979C2019	HW	Pneu. Room Thermostat	193-216
TP971A2217	HW	Pneu. Room Thermostat	194-2052	TPC-1002	KR	Differ. Pressure Transmitter	378-2000
TP971A2217	HW	Pneu. Room Thermostat	194-3052	TSC-1001	KR	Air Velocity Transmitter	141-0582
TP971B1001	HW	Pneu. Room Thermostat	192-205	TSC-1002	KR	Air Velocity Transmitter	141-0583
TP971B1001	HW	Pneu. Room Thermostat	194-3052	TSC-1003	KR	Air Velocity Transmitter	141-0584

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
TSC-1004	KR	Air Velocity Transmitter	141-0585	V5011A1163			
TSC-2001	KR	Low Diff. Pressure Transmitter	141-0591	MP953C1026	HW	Pneu. Valve	277-03166
TSC-2002	KR	Low Diff. Pressure Transmitter	141-0592	V5011A1163			
TSC-2003	KR	Low Diff. Pressure Transmitter	141-0592	MP953D1107	HW	Pneu. Valve	277-03184
TSC-2004	KR	Low Diff. Pressure Transmitter	141-0593	V5011A1163			
TTC-1003	KR	Temp. Transmitter	184-0028	MP953D1131	HW	Pneu. Valve	277-03184
TTC-1005	KR	Temp. Transmitter	184-0002	V5011A1163			
TTC-1006	KR	Temp. Transmitter	184-0003	MP953E1301	HW	Pneu. Valve	283-03166
TTC-1507	KR	Temp. Transmitter	184-0001	V5011A1163			
TTC-2001	KR	Temp. Transmitter	184-0004	MP953E1319	HW	Pneu. Valve	283-03166
TTC-2003	KR	Temp. Transmitter	184-0048	V5011A1163			
TTC-3001	KR	Temp. Transmitter	184-0340	MP953E1327	HW	Pneu. Valve	283-03166
V11HAA-100	JC	EP Switch	265-1002	V5011A1164			
V11HBA-100	JC	EP Switch	265-1004	MP953F1093	HW	Pneu. Valve	283-03184
V11HCA-100	JC	EP Switch	265-1003	V5011A1164			
V11HDA-100	JC	EP Switch	265-1006	MP953F1101	HW	Pneu. Valve	283-03184
V11HFA-100	JC	EP Switch	265-1005	V5011A1164			
V11HGA-100	JC	EP Switch	265-1001	MP953F1119	HW	Pneu. Valve	283-03184
V2410-1	JC	EP Switch	265-1001	V5011A1221			
V2410-2	JC	EP Switch	265-1002	MP953C1000	HW	Pneu. Valve	277-03167
V2410-3	JC	EP Switch	265-1003	V5011A1221			
V2410-4	JC	EP Switch	265-1004	MP953C1018	HW	Pneu. Valve	277-03167
V2410-5	JC	EP Switch	265-1005	V5011A1221			
V2410-6	JC	EP Switch	265-1006	MP953C1026	HW	Pneu. Valve	277-03167
V2410-8	JC	EP Switch	265-1007	V5011A1221			
V-3754-1008	JC	Pneu. Valve	658-0066	MP953D1131	HW	Pneu. Valve	277-03185
V-3754-1010	JC	Pneu. Valve	658-0068	V5011A1221			
V-3754-1022	JC	Pneu. Valve	268-03166	MP953E1301	HW	Pneu. Valve	283-03167
V-3754-1023	JC	Pneu. Valve	268-03167	V5011A1221			
V-3974-1004	JC	Pneu. Valve	270-03182	MP953E1319	HW	Pneu. Valve	283-03167
V-3974-1005	JC	Pneu. Valve	270-03185	MP953E1327	HW	Pneu. Valve	283-03167
V-4324-1005	JC	Pneu. Valve	268-03202	V5011A1221			
V-4324-1006	JC	Pneu. Valve	270-03202	MP953F1093	HW	Pneu. Valve	283-03185
V-4324-1007	JC	Pneu. Valve	268-03203	MP953F1101	HW	Pneu. Valve	283-03185
V-4324-1008	JC	Pneu. Valve	270-03203	V5011A1221			
V-4440-1001	HW	Pneu. Valve	658-0050	MP953F1119	HW	Pneu. Valve	283-03185
V-4440-1002	HW	Pneu. Valve	658-0051	V5011A1288			
V-4440-1004	HW	Pneu. Valve	658-0050	MP953C1000	HW	Pneu. Valve	277-03168
V-4440-1005	HW	Pneu. Valve	658-0051	V5011A1288			
V-4440-1008	HW	Pneu. Valve	658-0052	MP953C1018	HW	Pneu. Valve	277-03168
V-4440-1011	HW	Pneu. Valve	658-0052	V5011A1288			
V5011A1163				MP953C1026	HW	Pneu. Valve	277-03168
MP953C1000	HW	Pneu. Valve	277-03166	V5011A1288			
V5011A1163				MP953D1107	HW	Pneu. Valve	277-03186
MP953C1018	HW	Pneu. Valve	277-03166	V5011A1288			
				MP953D1131	HW	Pneu. Valve	277-03186
				V5011A1288			
				MP953E1301	HW	Pneu. Valve	283-03168

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V5011A1288 MP953E1319	HW	Pneu. Valve	283-03168	V5011A1460 MP953C1075	HW	Pneu. Valve	277-05980
V5011A1288 MP953E1327	HW	Pneu. Valve	283-03168	V5011A1460 MP953C1083	HW	Pneu. Valve	277-05980
V5011A1288 MP953F1093	HW	Pneu. Valve	283-03186	V5011A1460 MP953D1107	HW	Pneu. Valve	277-05990
V5011A1288 MP953F1101	HW	Pneu. Valve	283-03186	V5011A1460 MP953D1131	HW	Pneu. Valve	277-05990
V5011A1288 MP953F1119	HW	Pneu. Valve	283-03186	V5011A1460 MP953E1277	HW	Pneu. Valve	283-05980
V5011A1395 MP953C1000	HW	Pneu. Valve	277-03170	V5011A1460 MP953E1285	HW	Pneu. Valve	283-05980
V5011A1395 MP953C1018	HW	Pneu. Valve	277-03170	V5011A1460 MP953E1293	HW	Pneu. Valve	283-05980
V5011A1395 MP953C1026	HW	Pneu. Valve	277-03170	V5011A1460 MP953E1368	HW	Pneu. Valve	283-05980
V5011A1395 MP953C1067	HW	Pneu. Valve	277-03170	V5011A1460 MP953E1376	HW	Pneu. Valve	283-05980
V5011A1395 MP953C1075	HW	Pneu. Valve	277-03170	V5011A1460 MP953E1384	HW	Pneu. Valve	283-05980
V5011A1395 MP953C1083	HW	Pneu. Valve	277-03170	V5011A1460 MP953F1093	HW	Pneu. Valve	283-05990
V5011A1395 MP953D1107	HW	Pneu. Valve	277-03188	V5011A1460 MP953F1101	HW	Pneu. Valve	283-05990
V5011A1395 MP953D1131	HW	Pneu. Valve	277-03188	V5011A1460 MP953F1119	HW	Pneu. Valve	283-05990
V5011A1395 MP953E1277	HW	Pneu. Valve	283-03170	V5011A1528 MP953C1067	HW	Pneu. Valve	277-05981
V5011A1395 MP953E1285	HW	Pneu. Valve	283-03170	V5011A1528 MP953C1075	HW	Pneu. Valve	277-05981
V5011A1395 MP953E1293	HW	Pneu. Valve	283-03170	V5011A1528 MP953C1083	HW	Pneu. Valve	277-05981
V5011A1395 MP953E1301	HW	Pneu. Valve	283-03170	V5011A1528 MP953D1107	HW	Pneu. Valve	279-05991
V5011A1395 MP953E1319	HW	Pneu. Valve	283-03170	V5011A1528 MP953D1131	HW	Pneu. Valve	279-05991
V5011A1395 MP953E1327	HW	Pneu. Valve	283-03170	V5011A1528 MP953E1277	HW	Pneu. Valve	283-05981
V5011A1395 MP953E1368	HW	Pneu. Valve	283-03170	V5011A1528 MP953E1285	HW	Pneu. Valve	283-05981
V5011A1395 MP953E1376	HW	Pneu. Valve	283-03170	V5011A1528 MP953E1293	HW	Pneu. Valve	283-05981
V5011A1395 MP953E1384	HW	Pneu. Valve	283-03170	V5011A1528 MP953E1368	HW	Pneu. Valve	283-05981
V5011A1395 MP953F1093	HW	Pneu. Valve	283-03188	V5011A1528 MP953E1376	HW	Pneu. Valve	283-05981
V5011A1395 MP953F1101	HW	Pneu. Valve	283-03188	V5011A1528 MP953E1384	HW	Pneu. Valve	283-05981
V5011A1395 MP953F1119	HW	Pneu. Valve	283-03188	V5011A1528 MP953F1093	HW	Pneu. Valve	285-05991
V5011A1460 MP953C1067	HW	Pneu. Valve	277-05980	V5011A1528 MP953F1101	HW	Pneu. Valve	285-05991

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V5011A1528 MP953F1119	HW	Pneu. Valve	285-05991	V5011A1916 MP953C1489	HW	Pneu. Valve	281-05984
V5011A1767 MP953C1067	HW	Pneu. Valve	277-05981	V5011A1916 MP953E1392	HW	Pneu. Valve	287-05984
V5011A1767 MP953C1075	HW	Pneu. Valve	277-05981	V5011A1916 MP953E1400	HW	Pneu. Valve	287-05984
V5011A1767 MP953C1083	HW	Pneu. Valve	277-05981	V5011A1916 MP953E1418	HW	Pneu. Valve	287-05984
V5011A1767 MP953D1107	HW	Pneu. Valve	279-05991	V5011A346 MP953C1000	HW	Pneu. Valve	277-03169
V5011A1767 MP953D1131	HW	Pneu. Valve	279-05991	V5011A346 MP953C1018	HW	Pneu. Valve	277-03169
V5011A1767 MP953E1277	HW	Pneu. Valve	283-05981	V5011A346 MP953C1026	HW	Pneu. Valve	277-03169
V5011A1767 MP953E1285	HW	Pneu. Valve	283-05981	V5011A346 MP953C1067	HW	Pneu. Valve	277-03169
V5011A1767 MP953E1293	HW	Pneu. Valve	283-05981	V5011A346 MP953C1075	HW	Pneu. Valve	277-03169
V5011A1767 MP953E1368	HW	Pneu. Valve	283-05981	V5011A346 MP953C1083	HW	Pneu. Valve	277-03169
V5011A1767 MP953E1376	HW	Pneu. Valve	283-05981	V5011A346 MP953D1107	HW	Pneu. Valve	277-03187
V5011A1767 MP953E1384	HW	Pneu. Valve	283-05981	V5011A346 MP953D1131	HW	Pneu. Valve	277-03187
V5011A1767 MP953F1093	HW	Pneu. Valve	283-05991	V5011A346 MP953E1277	HW	Pneu. Valve	283-03169
V5011A1767 MP953F1101	HW	Pneu. Valve	283-05991	V5011A346 MP953E1285	HW	Pneu. Valve	283-03169
V5011A1767 MP953F1119	HW	Pneu. Valve	283-05991	V5011A346 MP953E1293	HW	Pneu. Valve	283-03169
V5011A1858 MP953C1471	HW	Pneu. Valve	281-05982	V5011A346 MP953E1301	HW	Pneu. Valve	283-03169
V5011A1858 MP953C1489	HW	Pneu. Valve	281-05982	V5011A346 MP953E1319	HW	Pneu. Valve	283-03169
V5011A1858 MP953E1392	HW	Pneu. Valve	287-05982	V5011A346 MP953E1327	HW	Pneu. Valve	283-03169
V5011A1858 MP953E1400	HW	Pneu. Valve	287-05982	V5011A346 MP953E1368	HW	Pneu. Valve	283-03169
V5011A1858 MP953E1418	HW	Pneu. Valve	287-05982	V5011A346 MP953E1376	HW	Pneu. Valve	283-03169
V5011A1882 MP953C1471	HW	Pneu. Valve	281-05983	V5011A346 MP953E1384	HW	Pneu. Valve	283-03169
V5011A1882 MP953C1489	HW	Pneu. Valve	281-05983	V5011A346 MP953F1093	HW	Pneu. Valve	283-03187
V5011A1882 MP953E1392	HW	Pneu. Valve	287-05983	V5011A346 MP953F1101	HW	Pneu. Valve	283-03187
V5011A1882 MP953E1400	HW	Pneu. Valve	287-05983	V5011A346 MP953F1119	HW	Pneu. Valve	283-03187
V5011A1882 MP953E1418	HW	Pneu. Valve	287-05983	V5011B1013 MP953C1471	HW	Pneu. Valve	281-05992
V5011A1916 MP953C1471	HW	Pneu. Valve	281-05984	V5011B1013 MP953C1489	HW	Pneu. Valve	281-05992

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V5011B1013 MP953E1392	HW	Pneu. Valve	287-05992	V5013A1005 MP953D1131	HW	Pneu. Valve	277-03200
V5011B1013 MP953E1400	HW	Pneu. Valve	287-05992	V5013A1005 MP953E1277	HW	Pneu. Valve	283-03200
V5011B1013 MP953E1418	HW	Pneu. Valve	287-05992	V5013A1005 MP953E1285	HW	Pneu. Valve	283-03200
V5011B1047 MP953C1471	HW	Pneu. Valve	287-05993	V5013A1005 MP953E1293	HW	Pneu. Valve	283-03200
V5011B1047 MP953C1489	HW	Pneu. Valve	287-05993	V5013A1005 MP953E1301	HW	Pneu. Valve	283-03200
V5011B1047 MP953E1392	HW	Pneu. Valve	287-05993	V5013A1005 MP953E1319	HW	Pneu. Valve	283-03200
V5011B1047 MP953E1400	HW	Pneu. Valve	287-05993	V5013A1005 MP953E1327	HW	Pneu. Valve	283-03200
V5011B1047 MP953E1418	HW	Pneu. Valve	287-05993	V5013A1005 MP953E1368	HW	Pneu. Valve	283-03200
V5011B1070 MP953C1471	HW	Pneu. Valve	287-05994	V5013A1005 MP953E1376	HW	Pneu. Valve	283-03200
V5011B1070 MP953C1489	HW	Pneu. Valve	287-05994	V5013A1005 MP953E1384	HW	Pneu. Valve	283-03200
V5011B1070 MP953E1392	HW	Pneu. Valve	287-05994	V5013A1005 MP953F1093	HW	Pneu. Valve	283-03200
V5011B1070 MP953E1400	HW	Pneu. Valve	287-05994	V5013A1005 MP953F1101	HW	Pneu. Valve	283-03200
V5011B1070 MP953E1418	HW	Pneu. Valve	287-05994	V5013A1005 MP953F1119	HW	Pneu. Valve	283-03200
V5011N1032/ ML6425A3022	HW	Elec. Valve	29803164	V5013A1021 MP953C1000	HW	Pneu. Valve	268-03202
V5011N1057/ ML6425A3022	HW	Elec. Valve	29803166	V5013A1021 MP953C1018	HW	Pneu. Valve	270-03202
V5011N1065/ ML6425A3022	HW	Elec. Valve	29803167	V5013A1021 MP953C1026	HW	Pneu. Valve	269-03202
V5011N1073/ ML6425A3022	HW	Elec. Valve	29803168	V5013A1021 MP953C1067	HW	Pneu. Valve	277-03202
V5011N1081/ ML6425A3022	HW	Elec. Valve	29803169	V5013A1021 MP953C1075	HW	Pneu. Valve	277-03202
V5011N1099/ ML6425A3022	HW	Elec. Valve	29803170	V5013A1021 MP953C1083	HW	Pneu. Valve	277-03202
V5013A1005 MP953C1000	HW	Pneu. Valve	268-03200	V5013A1021 MP953D1107	HW	Pneu. Valve	277-03202
V5013A1005 MP953C1018	HW	Pneu. Valve	270-03200	V5013A1021 MP953D1131	HW	Pneu. Valve	277-03202
V5013A1005 MP953C1026	HW	Pneu. Valve	269-03200	V5013A1021 MP953E1277	HW	Pneu. Valve	283-03202
V5013A1005 MP953C1067	HW	Pneu. Valve	277-03200	V5013A1021 MP953E1285	HW	Pneu. Valve	283-03202
V5013A1005 MP953C1075	HW	Pneu. Valve	277-03200	V5013A1021 MP953E1293	HW	Pneu. Valve	283-03202
V5013A1005 MP953C1083	HW	Pneu. Valve	277-03200	V5013A1021 MP953E1301	HW	Pneu. Valve	283-03202
V5013A1005 MP953D1107	HW	Pneu. Valve	277-03200	V5013A1021 MP953E1319	HW	Pneu. Valve	283-03202

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V5013A1021 MP953E1327	HW	Pneu. Valve	283-03202	V5013A1039 MP953F1119	HW	Pneu. Valve	283-03203
V5013A1021 MP953E1368	HW	Pneu. Valve	283-03202	V5013A1047 MP953C1000	HW	Pneu. Valve	268-03204
V5013A1021 MP953E1376	HW	Pneu. Valve	283-03202	V5013A1047 MP953C1018	HW	Pneu. Valve	270-03204
V5013A1021 MP953E1384	HW	Pneu. Valve	283-03202	V5013A1047 MP953C1026	HW	Pneu. Valve	269-03204
V5013A1021 MP953F1093	HW	Pneu. Valve	283-03202	V5013A1047 MP953C1067	HW	Pneu. Valve	277-03204
V5013A1021 MP953F1101	HW	Pneu. Valve	283-03202	V5013A1047 MP953C1075	HW	Pneu. Valve	277-03204
V5013A1021 MP953F1119	HW	Pneu. Valve	283-03202	V5013A1047 MP953C1083	HW	Pneu. Valve	277-03204
V5013A1039 MP953C1000	HW	Pneu. Valve	268-03203	V5013A1047 MP953D1107	HW	Pneu. Valve	277-03204
V5013A1039 MP953C1018	HW	Pneu. Valve	270-03203	V5013A1047 MP953D1131	HW	Pneu. Valve	277-03204
V5013A1039 MP953C1026	HW	Pneu. Valve	269-03203	V5013A1047 MP953E1277	HW	Pneu. Valve	283-03204
V5013A1039 MP953C1067	HW	Pneu. Valve	277-03203	V5013A1047 MP953E1285	HW	Pneu. Valve	283-03204
V5013A1039 MP953C1075	HW	Pneu. Valve	277-03203	V5013A1047 MP953E1293	HW	Pneu. Valve	283-03204
V5013A1039 MP953C1083	HW	Pneu. Valve	277-03203	V5013A1047 MP953E1301	HW	Pneu. Valve	283-03204
V5013A1039 MP953D1107	HW	Pneu. Valve	277-03203	V5013A1047 MP953E1319	HW	Pneu. Valve	283-03204
V5013A1039 MP953D1131	HW	Pneu. Valve	277-03203	V5013A1047 MP953E1327	HW	Pneu. Valve	283-03204
V5013A1039 MP953E1277	HW	Pneu. Valve	283-03203	V5013A1047 MP953E1368	HW	Pneu. Valve	283-03204
V5013A1039 MP953E1285	HW	Pneu. Valve	283-03203	V5013A1047 MP953E1376	HW	Pneu. Valve	283-03204
V5013A1039 MP953E1293	HW	Pneu. Valve	283-03203	V5013A1047 MP953E1384	HW	Pneu. Valve	283-03204
V5013A1039 MP953E1301	HW	Pneu. Valve	283-03203	V5013A1047 MP953F1093	HW	Pneu. Valve	283-03204
V5013A1039 MP953E1319	HW	Pneu. Valve	283-03203	V5013A1047 MP953F1101	HW	Pneu. Valve	283-03204
V5013A1039 MP953E1327	HW	Pneu. Valve	283-03203	V5013A1047 MP953F1119	HW	Pneu. Valve	283-03204
V5013A1039 MP953E1368	HW	Pneu. Valve	283-03203	V5013A1054 MP953C1000	HW	Pneu. Valve	268-03205
V5013A1039 MP953E1376	HW	Pneu. Valve	283-03203	V5013A1054 MP953C1018	HW	Pneu. Valve	270-03205
V5013A1039 MP953E1384	HW	Pneu. Valve	283-03203	V5013A1054 MP953C1026	HW	Pneu. Valve	269-03205
V5013A1039 MP953F1093	HW	Pneu. Valve	283-03203	V5013A1054 MP953C1067	HW	Pneu. Valve	277-03205
V5013A1039 MP953F1101	HW	Pneu. Valve	283-03203	V5013A1054 MP953C1075	HW	Pneu. Valve	277-03205

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V5013A1054 MP953C1083	HW	Pneu. Valve	277-03205	V5013A1062 MP953E1301	HW	Pneu. Valve	283-03206
V5013A1054 MP953D1107	HW	Pneu. Valve	277-03205	V5013A1062 MP953E1319	HW	Pneu. Valve	283-03206
V5013A1054 MP953D1131	HW	Pneu. Valve	277-03205	V5013A1062 MP953E1327	HW	Pneu. Valve	283-03206
V5013A1054 MP953E1277	HW	Pneu. Valve	283-03205	V5013A1062 MP953E1368	HW	Pneu. Valve	283-03206
V5013A1054 MP953E1285	HW	Pneu. Valve	283-03205	V5013A1062 MP953E1376	HW	Pneu. Valve	283-03206
V5013A1054 MP953E1293	HW	Pneu. Valve	283-03205	V5013A1062 MP953E1384	HW	Pneu. Valve	283-03206
V5013A1054 MP953E1301	HW	Pneu. Valve	283-03205	V5013A1062 MP953F1093	HW	Pneu. Valve	283-03206
V5013A1054 MP953E1319	HW	Pneu. Valve	283-03205	V5013A1062 MP953F1101	HW	Pneu. Valve	283-03206
V5013A1054 MP953E1327	HW	Pneu. Valve	283-03205	V5013A1062 MP953F1119	HW	Pneu. Valve	283-03206
V5013A1054 MP953E1368	HW	Pneu. Valve	283-03205	V5013B1003 MP953C1067	HW	Pneu. Valve	277-06160
V5013A1054 MP953E1376	HW	Pneu. Valve	283-03205	V5013B1003 MP953C1075	HW	Pneu. Valve	277-06160
V5013A1054 MP953E1384	HW	Pneu. Valve	283-03205	V5013B1003 MP953C1083	HW	Pneu. Valve	277-06160
V5013A1054 MP953F1093	HW	Pneu. Valve	283-03205	V5013B1003 MP953D1107	HW	Pneu. Valve	277-06160
V5013A1054 MP953F1101	HW	Pneu. Valve	283-03205	V5013B1003 MP953D1131	HW	Pneu. Valve	277-06160
V5013A1054 MP953F1119	HW	Pneu. Valve	283-03205	V5013B1003 MP953E1277	HW	Pneu. Valve	283-06160
V5013A1062 MP953C1000	HW	Pneu. Valve	268-03206	V5013B1003 MP953E1285	HW	Pneu. Valve	283-06160
V5013A1062 MP953C1018	HW	Pneu. Valve	270-03206	V5013B1003 MP953E1293	HW	Pneu. Valve	283-06160
V5013A1062 MP953C1026	HW	Pneu. Valve	269-03206	V5013B1003 MP953E1301	HW	Pneu. Valve	283-06160
V5013A1062 MP953C1067	HW	Pneu. Valve	277-03206	V5013B1003 MP953E1319	HW	Pneu. Valve	283-06160
V5013A1062 MP953C1075	HW	Pneu. Valve	277-03206	V5013B1003 MP953E1327	HW	Pneu. Valve	283-06160
V5013A1062 MP953C1083	HW	Pneu. Valve	277-03206	V5013B1003 MP953E1368	HW	Pneu. Valve	283-06160
V5013A1062 MP953D1107	HW	Pneu. Valve	277-03206	V5013B1003 MP953E1376	HW	Pneu. Valve	283-06160
V5013A1062 MP953D1131	HW	Pneu. Valve	277-03206	V5013B1003 MP953E1384	HW	Pneu. Valve	283-06160
V5013A1062 MP953E1277	HW	Pneu. Valve	283-03206	V5013B1003 MP953F1093	HW	Pneu. Valve	283-06160
V5013A1062 MP953E1285	HW	Pneu. Valve	283-03206	V5013B1003 MP953F1101	HW	Pneu. Valve	283-06160
V5013A1062 MP953E1293	HW	Pneu. Valve	283-03206	V5013B1003 MP953F1119	HW	Pneu. Valve	283-06160

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V5013B1011 MP953C1067	HW	Pneu. Valve	277-06161	V5013B1045 MP953E1418	HW	Pneu. Valve	287-06163
V5013B1011 MP953C1075	HW	Pneu. Valve	277-06161	V5013F1079 MP953C1000	HW	Pneu. Valve	268-03200
V5013B1011 MP953C1083	HW	Pneu. Valve	277-06161	V5013F1079 MP953C1018	HW	Pneu. Valve	270-03200
V5013B1011 MP953D1107	HW	Pneu. Valve	277-06161	V5013F1079 MP953C1026	HW	Pneu. Valve	269-03200
V5013B1011 MP953D1131	HW	Pneu. Valve	277-06161	V5013F1079 MP953C1067	HW	Pneu. Valve	277-03200
V5013B1011 MP953E1277	HW	Pneu. Valve	283-06161	V5013F1079 MP953C1075	HW	Pneu. Valve	277-03200
V5013B1011 MP953E1285	HW	Pneu. Valve	283-06161	V5013F1079 MP953C1083	HW	Pneu. Valve	277-03200
V5013B1011 MP953E1293	HW	Pneu. Valve	283-06161	V5013F1079 MP953D1107	HW	Pneu. Valve	277-03200
V5013B1011 MP953E1301	HW	Pneu. Valve	283-06161	V5013F1079 MP953D1131	HW	Pneu. Valve	277-03200
V5013B1011 MP953E1319	HW	Pneu. Valve	283-06161	V5013F1079 MP953E1277	HW	Pneu. Valve	283-03200
V5013B1011 MP953E1327	HW	Pneu. Valve	283-06161	V5013F1079 MP953E1285	HW	Pneu. Valve	283-03200
V5013B1011 MP953E1368	HW	Pneu. Valve	283-06161	V5013F1079 MP953E1293	HW	Pneu. Valve	283-03200
V5013B1011 MP953E1376	HW	Pneu. Valve	283-06161	V5013F1079 MP953E1301	HW	Pneu. Valve	283-03200
V5013B1011 MP953E1384	HW	Pneu. Valve	283-06161	V5013F1079 MP953E1319	HW	Pneu. Valve	283-03200
V5013B1011 MP953F1093	HW	Pneu. Valve	283-06161	V5013F1079 MP953E1327	HW	Pneu. Valve	283-03200
V5013B1011 MP953F1101	HW	Pneu. Valve	283-06161	V5013F1079 MP953E1368	HW	Pneu. Valve	283-03200
V5013B1011 MP953F1119	HW	Pneu. Valve	283-06161	V5013F1079 MP953E1376	HW	Pneu. Valve	283-03200
V5013B1029 MP953C1471	HW	Pneu. Valve	281-06162	V5013F1079 MP953E1384	HW	Pneu. Valve	283-03200
V5013B1029 MP953C1489	HW	Pneu. Valve	281-06162	V5013F1079 MP953F1093	HW	Pneu. Valve	283-03200
V5013B1029 MP953E1392	HW	Pneu. Valve	287-06162	V5013F1079 MP953F1101	HW	Pneu. Valve	283-03200
V5013B1029 MP953E1400	HW	Pneu. Valve	287-06162	V5013F1079 MP953F1119	HW	Pneu. Valve	283-03200
V5013B1029 MP953E1418	HW	Pneu. Valve	287-06162	V5013F1087 MP953C1000	HW	Pneu. Valve	268-03202
V5013B1045 MP953C1471	HW	Pneu. Valve	281-06163	V5013F1087 MP953C1018	HW	Pneu. Valve	270-03202
V5013B1045 MP953C1489	HW	Pneu. Valve	281-06163	V5013F1087 MP953C1026	HW	Pneu. Valve	269-03202
V5013B1045 MP953E1392	HW	Pneu. Valve	287-06163	V5013F1087 MP953C1067	HW	Pneu. Valve	277-03202
V5013B1045 MP953E1400	HW	Pneu. Valve	287-06163	V5013F1087 MP953C1075	HW	Pneu. Valve	277-03202

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V5013F1087 MP953C1083	HW	Pneu. Valve	277-03202	V5013F1095 MP953E1301	HW	Pneu. Valve	283-03203
V5013F1087 MP953D1107	HW	Pneu. Valve	277-03202	V5013F1095 MP953E1319	HW	Pneu. Valve	283-03203
V5013F1087 MP953D1131	HW	Pneu. Valve	277-03202	V5013F1095 MP953E1327	HW	Pneu. Valve	283-03203
V5013F1087 MP953E1277	HW	Pneu. Valve	283-03202	V5013F1095 MP953E1368	HW	Pneu. Valve	283-03203
V5013F1087 MP953E1285	HW	Pneu. Valve	283-03202	V5013F1095 MP953E1376	HW	Pneu. Valve	283-03203
V5013F1087 MP953E1293	HW	Pneu. Valve	283-03202	V5013F1095 MP953E1384	HW	Pneu. Valve	283-03203
V5013F1087 MP953E1301	HW	Pneu. Valve	283-03202	V5013F1095 MP953F1093	HW	Pneu. Valve	283-03203
V5013F1087 MP953E1319	HW	Pneu. Valve	283-03202	V5013F1095 MP953F1101	HW	Pneu. Valve	283-03203
V5013F1087 MP953E1327	HW	Pneu. Valve	283-03202	V5013F1095 MP953F1119	HW	Pneu. Valve	283-03203
V5013F1087 MP953E1368	HW	Pneu. Valve	283-03202	V5013F1103 MP953C1000	HW	Pneu. Valve	268-03204
V5013F1087 MP953E1376	HW	Pneu. Valve	283-03202	V5013F1111 MP953C1000	HW	Pneu. Valve	268-03205
V5013F1087 MP953E1384	HW	Pneu. Valve	283-03202	V5013F1111 MP953C1018	HW	Pneu. Valve	270-03205
V5013F1087 MP953F1093	HW	Pneu. Valve	283-03202	V5013F1111 MP953C1026	HW	Pneu. Valve	269-03205
V5013F1087 MP953F1101	HW	Pneu. Valve	283-03202	V5013F1111 MP953C1067	HW	Pneu. Valve	277-03205
V5013F1087 MP953F1119	HW	Pneu. Valve	283-03202	V5013F1111 MP953C1075	HW	Pneu. Valve	277-03205
V5013F1095 MP953C1000	HW	Pneu. Valve	268-03203	V5013F1111 MP953C1083	HW	Pneu. Valve	277-03205
V5013F1095 MP953C1018	HW	Pneu. Valve	270-03203	V5013F1111 MP953D1107	HW	Pneu. Valve	277-03205
V5013F1095 MP953C1026	HW	Pneu. Valve	269-03203	V5013F1111 MP953D1131	HW	Pneu. Valve	277-03205
V5013F1095 MP953C1067	HW	Pneu. Valve	277-03203	V5013F1111 MP953E1277	HW	Pneu. Valve	283-03205
V5013F1095 MP953C1075	HW	Pneu. Valve	277-03203	V5013F1111 MP953E1285	HW	Pneu. Valve	283-03205
V5013F1095 MP953C1083	HW	Pneu. Valve	277-03203	V5013F1111 MP953E1293	HW	Pneu. Valve	283-03205
V5013F1095 MP953D1107	HW	Pneu. Valve	277-03203	V5013F1111 MP953E1301	HW	Pneu. Valve	283-03205
V5013F1095 MP953D1131	HW	Pneu. Valve	277-03203	V5013F1111 MP953E1319	HW	Pneu. Valve	283-03205
V5013F1095 MP953E1277	HW	Pneu. Valve	283-03203	V5013F1111 MP953E1327	HW	Pneu. Valve	283-03205
V5013F1095 MP953E1285	HW	Pneu. Valve	283-03203	V5013F1111 MP953E1368	HW	Pneu. Valve	283-03205
V5013F1095 MP953E1293	HW	Pneu. Valve	283-03203	V5013F1111 MP953E1376	HW	Pneu. Valve	283-03205

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V5013F1111 MP953E1384	HW	Pneu. Valve	283-03205	V5013N1063/ ML6425A3022	HW	Elec. Valve	29803203
V5013F1111 MP953F1093	HW	Pneu. Valve	283-03205	V5013N1071/ ML6425A3022	HW	Elec. Valve	29803204
V5013F1111 MP953F1101	HW	Pneu. Valve	283-03205	V5013N1089/ ML6425A3022	HW	Elec. Valve	29803205
V5013F1111 MP953F1119	HW	Pneu. Valve	283-03205	V5013N1097/ ML6425A3022	HW	Elec. Valve	29803206
V5013F1129 MP953C1000	HW	Pneu. Valve	268-03206	V-5252-10	JC	Pneu. Valve	283-05981
V5013F1129 MP953C1018	HW	Pneu. Valve	270-03206	V-5252-11	JC	Pneu. Valve	277-05981
V5013F1129 MP953C1026	HW	Pneu. Valve	269-03206	V-5252-12	JC	Pneu. Valve	279-05981
V5013F1129 MP953C1067	HW	Pneu. Valve	277-03206	V-5252-13	JC	Pneu. Valve	285-05981
V5013F1129 MP953C1075	HW	Pneu. Valve	277-03206	V-5252-14	JC	Pneu. Valve	283-05980
V5013F1129 MP953C1083	HW	Pneu. Valve	277-03206	V-5252-15	JC	Pneu. Valve	281-05982
V5013F1129 MP953D1107	HW	Pneu. Valve	277-03206	V-5252-16	JC	Pneu. Valve	287-05982
V5013F1129 MP953D1131	HW	Pneu. Valve	277-03206	V-5252-17	JC	Pneu. Valve	281-05983
V5013F1129 MP953E1277	HW	Pneu. Valve	283-03206	V-5252-18	JC	Pneu. Valve	287-05983
V5013F1129 MP953E1285	HW	Pneu. Valve	283-03206	V-5252-19	JC	Pneu. Valve	281-05984
V5013F1129 MP953E1293	HW	Pneu. Valve	283-03206	V-5252-20	JC	Pneu. Valve	287-05984
V5013F1129 MP953E1301	HW	Pneu. Valve	283-03206	V-5252-4	JC	Pneu. Valve	277-05980
V5013F1129 MP953E1319	HW	Pneu. Valve	283-03206	V-5252-5	JC	Pneu. Valve	283-05980
V5013F1129 MP953E1327	HW	Pneu. Valve	283-03206	V-5252-6	JC	Pneu. Valve	277-05980
V5013F1129 MP953E1368	HW	Pneu. Valve	283-03206	V-5252-7	JC	Pneu. Valve	279-05980
V5013F1129 MP953E1376	HW	Pneu. Valve	283-03206	V-5252-8	JC	Pneu. Valve	285-05980
V5013F1129 MP953E1384	HW	Pneu. Valve	283-03206	V-5252-9	JC	Pneu. Valve	277-05981
V5013F1129 MP953F1093	HW	Pneu. Valve	283-03206	V-5254-1	JC	Pneu. Valve	277-03169
V5013F1129 MP953F1101	HW	Pneu. Valve	283-03206	V-5254-2	JC	Pneu. Valve	277-03169
V5013F1129 MP953F1119	HW	Pneu. Valve	283-03206	V-5254-3	JC	Pneu. Valve	277-03169
V5013N1030/ ML6425A3022	HW	Elec. Valve	29803200	V-5254-4	JC	Pneu. Valve	277-03170
V5013N1055/ ML6425A3022	HW	Elec. Valve	29803202	V-5254-6	JC	Pneu. Valve	277-03170
				V-5354-5	JC	Pneu. Valve	283-03170
				V-5462-11	JC	Pneu. Valve	281-05992
				V-5462-12	JC	Pneu. Valve	287-05992
				V-5462-15	JC	Pneu. Valve	287-05993
				V-5462-16	JC	Pneu. Valve	287-05993
				V-5462-17	JC	Pneu. Valve	287-05994
				V-5462-18	JC	Pneu. Valve	287-05994
				V-5462-6	JC	Pneu. Valve	277-05990
				V-5462-7	JC	Pneu. Valve	283-05990
				V-5462-8	JC	Pneu. Valve	279-05991
				V-5462-9	JC	Pneu. Valve	285-05991
				V-5464-1	JC	Pneu. Valve	277-03187
				V5464-2	JC	Pneu. Valve	283-03187
				V-5464-3	JC	Pneu. Valve	277-03188
				V-5464-4	JC	Pneu. Valve	283-03188
				V-5842-10	JC	Pneu. Valve	279-06161

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
V-5842-11	JC	Pneu. Valve	277-06162	V-7416-4523	JC	Pneu. Valve	278-03080
V-5842-12	JC	Pneu. Valve	277-06162	V-7416-4555	JC	Pneu. Valve	284-03074
V-5842-13	JC	Pneu. Valve	287-06162	V-7416-4557	JC	Pneu. Valve	278-03074
V-5842-14	JC	Pneu. Valve	281-06163	V-7416-4563	JC	Pneu. Valve	284-03074
V-5842-15	JC	Pneu. Valve	287-06163	V-7416-4566	JC	Pneu. Valve	284-03076
V-5842-16	JC	Pneu. Valve	281-06163	V-7416-4571	JC	Pneu. Valve	284-03078
V-5842-17	JC	Pneu. Valve	279-06161	V-7416-4572	JC	Pneu. Valve	284-03079
V-5842-18	JC	Pneu. Valve	277-06161	V-7416-4573	JC	Pneu. Valve	284-03080
V-5842-7	JC	Pneu. Valve	277-06160	VC-1010-120 V	KR	EP Switch	265-1008
V-5842-8	JC	Pneu. Valve	283-06160	VC-1010-24V	KR	EP Switch	265-1007
V-5842-9	JC	Pneu. Valve	277-06161	VC-1020-120 V	KR	EP Switch	265-1002
V-5844-1	JC	Pneu. Valve	277-03205	VC-1020-208 V	KR	EP Switch	265-1003
V-5844-2	JC	Pneu. Valve	277-03205	VC-1020-240 V	KR	EP Switch	265-1004
V-5844-3	JC	Pneu. Valve	283-03205	VC-1020-24V	KR	EP Switch	265-1001
V-5844-4	JC	Pneu. Valve	277-03206	VC-1020-480 V	KR	EP Switch	265-1006
V-5844-5	JC	Pneu. Valve	277-03206	VF-7213-251-4-2	INV	Elec. Valve	261-02063
V-5844-6	JC	Pneu. Valve	283-03206	VF-7213-251-4-6	INV	Elec. Valve	261-02044
v592-6650	LS	Pneu. Valve	283-03206	VK-1114-201-3-3	INV	Pneu. Valve	656-0017
V-7216-4503	JC	Pneu. Valve	268-03162	VK-1114-201-3-5	INV	Pneu. Valve	656-0018
V-7216-4505	JC	Pneu. Valve	268-03164	VK-1114-202-3-3	INV	Pneu. Valve	656-0019
V-7216-4505	JC	Pneu. Valve	278-03056	VK-1114-202-3-5	INV	Pneu. Valve	656-0021
V-7216-4507	JC	Pneu. Valve	268-03166	VK-1115-401-3-2	INV	Pneu. Valve	658-0007
V-7216-4516	JC	Pneu. Valve	278-03058	VK-1115-401-3-3	INV	Pneu. Valve	658-0008
V-7216-4517	JC	Pneu. Valve	278-03059	VK-1115-401-3-7	INV	Pneu. Valve	658-0012
V-7216-4518	JC	Pneu. Valve	278-03060	VK-1115-401-3-9	INV	Pneu. Valve	658-0014
V-7216-4519	JC	Pneu. Valve	278-03061	VK-1115-421-3-2	INV	Pneu. Valve	658-0064
V-7216-4521	JC	Pneu. Valve	278-03060	VK-1115-421-3-3	INV	Pneu. Valve	658-0065
V-7216-4522	JC	Pneu. Valve	278-03061	VK-1115-421-3-5	INV	Pneu. Valve	658-0067
V-7216-4523	JC	Pneu. Valve	278-03062	VK-1115-421-3-8	INV	Pneu. Valve	658-0069
V-7216-4555	JC	Pneu. Valve	284-03056	VK-1115-421-3-9	INV	Pneu. Valve	658-0071
V-7216-4564	JC	Pneu. Valve	284-03056	VK4-9213-301-4-6	INV	Pneu. Valve	283-03166
V-7216-4567	JC	Pneu. Valve	284-03059	VK4-9213-301-4-8	INV	Pneu. Valve	283-03167
V-7216-4571	JC	Pneu. Valve	283-03168	VK4-9213-301-4-9	INV	Pneu. Valve	283-03168
V-7216-4572	JC	Pneu. Valve	284-03061	VK4-9213-371-4-10	INV	Pneu. Valve	283-03187
V-7216-4573	JC	Pneu. Valve	284-03062	VK4-9213-371-4-11	INV	Pneu. Valve	283-03170
V-7416-4503	JC	Pneu. Valve	270-03180	VK4-9213-372-4-10	INV	Pneu. Valve	283-03205
V-7416-4505	JC	Pneu. Valve	270-03182	VK4-9213-372-4-11	INV	Pneu. Valve	283-03206
V-7416-4505	JC	Pneu. Valve	278-03074	VK4-9213-373-4-10	INV	Pneu. Valve	283-03169
V-7416-4507	JC	Pneu. Valve	270-03184	VK4-9213-373-4-10	INV	Pneu. Valve	283-03169
V-7416-4507	JC	Pneu. Valve	278-03074	VK4-9213-373-4-10	INV	Pneu. Valve	283-03205
V-7416-4516	JC	Pneu. Valve	278-03074	VK4-9213-373-4-11	INV	Pneu. Valve	283-03206
V-7416-4518	JC	Pneu. Valve	278-03078	VK4-9213-601-4-10	INV	Pneu. Valve	283-03169
V-7416-4519	JC	Pneu. Valve	278-03079	VK4-9213-601-4-10	INV	Pneu. Valve	283-03169
V-7416-4521	JC	Pneu. Valve	278-03078	VK4-9213-601-4-11	INV	Pneu. Valve	283-03170
V-7416-4522	JC	Pneu. Valve	278-03079	VK4-9213-601-5-12	INV	Pneu. Valve	283-05980

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
VK4-9213-601-5-13	INV	Pneu. Valve	283-05981	VK4-9313-602-5-12	INV	Pneu. Valve	283-06160
VK4-9213-801-5-12	INV	Pneu. Valve	285-05980	VK4-9313-602-5-13	INV	Pneu. Valve	283-06161
VK4-9213-801-5-13	INV	Pneu. Valve	285-05981	VK4-9313-603-4-11	INV	Pneu. Valve	283-03206
VK4-9213-811-5-16	INV	Pneu. Valve	287-05984	VK4-9313-603-4-11	INV	Pneu. Valve	283-03206
VK4-9223-301-4-6	INV	Pneu. Valve	283-03166	VK4-9313-603-5-12	INV	Pneu. Valve	283-06160
VK4-9223-301-4-8	INV	Pneu. Valve	283-03167	VK4-9313-603-5-13	INV	Pneu. Valve	283-06161
VK4-9223-301-4-9	INV	Pneu. Valve	283-03168	VK4-9313-801-5-14	INV	Pneu. Valve	287-05982
VK4-9223-373-4-10	INV	Pneu. Valve	283-03187	VK4-9313-802-5-12	INV	Pneu. Valve	283-06160
VK4-9223-373-4-11	INV	Pneu. Valve	283-03170	VK4-9313-802-5-13	INV	Pneu. Valve	283-06161
VK4-9223-603-4-10	INV	Pneu. Valve	283-03187	VK4-9313-802-5-14	INV	Pneu. Valve	283-06162
VK4-9223-603-5-12	INV	Pneu. Valve	285-05990	VK4-9313-802-5-14	INV	Pneu. Valve	283-06162
VK4-9223-603-5-13	INV	Pneu. Valve	283-05981	VK4-9313-812-5-15	INV	Pneu. Valve	287-06163
VK4-9223-801-5-13	INV	Pneu. Valve	285-05991	VK4-9313-812-5-16	INV	Pneu. Valve	287-06164
VK4-9223-803-5-12	INV	Pneu. Valve	285-05990	VK4-9323-601-5-14	INV	Pneu. Valve	287-05982
VK4-9223-813-5-15	INV	Pneu. Valve	287-05993	VK4-9323-603-5-14	INV	Pneu. Valve	287-05982
VK4-9223-813-5-16	INV	Pneu. Valve	287-05994	VK4-9323-801-5-14	INV	Pneu. Valve	287-05982
VK4-9253-301-4-3	INV	Pneu. Valve	284-03056	VK-7323-201-4-6	INV	Pneu. Valve	258-02070
VK4-9263-303-4-3	INV	Pneu. Valve	284-03074	VK-7323-203-4-4	INV	Pneu. Valve	258-02069
VK4-9273-301-4-3	INV	Pneu. Valve	283-03110	VK-9211-201-4-2	INV	Pneu. Valve	257-02037
VK4-9273-301-4-8	INV	Pneu. Valve	283-03113	VK-9211-201-4-3	INV	Pneu. Valve	257-02039
VK4-9273-301-4-9	INV	Pneu. Valve	283-03114	VK-9211-201-4-5	INV	Pneu. Valve	257-02042
VK4-9273-371-4-10	INV	Pneu. Valve	283-03115	VK-9211-202-4-5	INV	Pneu. Valve	257-02042
VK4-9273-371-4-11	INV	Pneu. Valve	283-03116	VK-9211-301-4-2	INV	Pneu. Valve	268-03271
VK4-9273-601-4-10	INV	Pneu. Valve	283-03115	VK-9211-301-4-3	INV	Pneu. Valve	268-03272
VK4-9273-601-4-11	INV	Pneu. Valve	283-03116	VK-9211-301-4-6	INV	Pneu. Valve	268-03274
VK4-9283-303-4-3	INV	Pneu. Valve	283-03128	VK-9211-301-4-8	INV	Pneu. Valve	268-03275
VK4-9283-303-4-6	INV	Pneu. Valve	283-03130	VK-9211-301-4-9	INV	Pneu. Valve	268-03276
VK4-9283-303-4-8	INV	Pneu. Valve	283-03131	VK-9212-201-4-2	INV	Pneu. Valve	656-0004
VK4-9283-303-4-9	INV	Pneu. Valve	283-03132	VK-9212-201-4-3	INV	Pneu. Valve	656-0002
VK4-9283-304-4-3	INV	Pneu. Valve	283-03128	VK-9212-202-4-2	INV	Pneu. Valve	257-02039
VK4-9283-371-4-10	INV	Pneu. Valve	283-03115	VK-9213-301-4-2	INV	Pneu. Valve	268-03163
VK4-9283-373-4-11	INV	Pneu. Valve	283-03134	VK-9213-301-4-3	INV	Pneu. Valve	268-03164
VK4-9283-603-4-10	INV	Pneu. Valve	283-03115	VK-9213-301-4-6	INV	Pneu. Valve	268-03166
VK4-9283-603-4-11	INV	Pneu. Valve	283-03134	VK-9213-301-4-8	INV	Pneu. Valve	268-03167
VK4-9313-302-4-2	INV	Pneu. Valve	283-03200	VK-9213-301-4-9	INV	Pneu. Valve	268-03168
VK4-9313-302-4-6	INV	Pneu. Valve	283-03202	VK-9213-302-4-6	INV	Pneu. Valve	269-03166
VK4-9313-302-4-8	INV	Pneu. Valve	283-03203	VK-9213-302-4-8	INV	Pneu. Valve	269-03167
VK4-9313-302-4-9	INV	Pneu. Valve	283-03204	VK-9213-302-4-9	INV	Pneu. Valve	269-03168
VK4-9313-303-4-2	INV	Pneu. Valve	283-03200	VK-9213-303-4-6	INV	Pneu. Valve	270-03166
VK4-9313-303-4-6	INV	Pneu. Valve	283-03202	VK-9213-303-4-8	INV	Pneu. Valve	270-03167
VK4-9313-303-4-8	INV	Pneu. Valve	283-03203	VK-9213-303-4-9	INV	Pneu. Valve	270-03168
VK4-9313-303-4-9	INV	Pneu. Valve	283-03204	VK-9213-371-4-10	INV	Pneu. Valve	270-03169
VK4-9313-601-5-14	INV	Pneu. Valve	287-05982	VK-9213-371-4-11	INV	Pneu. Valve	268-03170
VK4-9313-602-4-10	INV	Pneu. Valve	283-03205	VK-9213-372-4-10	INV	Pneu. Valve	269-03169
VK4-9313-602-4-11	INV	Pneu. Valve	283-03206	VK-9213-372-4-11	INV	Pneu. Valve	269-03170

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Sieba/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
VK-9213-372-4-11	INV	Pneu. Valve	270-03206	VK-9223-371-4-11	INV	Pneu. Valve	268-03188
VK-9213-373-4-10	INV	Pneu. Valve	270-03169	VK-9223-372-4-10	INV	Pneu. Valve	269-03187
VK-9213-373-4-10	INV	Pneu. Valve	270-03169	VK-9223-372-4-11	INV	Pneu. Valve	269-03170
VK-9213-373-4-10	INV	Pneu. Valve	270-03187	VK-9223-373-4-10	INV	Pneu. Valve	270-03187
VK-9213-373-4-10	INV	Pneu. Valve	270-03205	VK-9223-373-4-11	INV	Pneu. Valve	270-03170
VK-9213-373-4-11	INV	Pneu. Valve	270-03170	VK-9223-601-4-10	INV	Pneu. Valve	277-03187
VK-9213-373-4-11	INV	Pneu. Valve	270-03206	VK-9223-601-5-12	INV	Pneu. Valve	279-05990
VK-9213-601-4-10	INV	Pneu. Valve	277-03169	VK-9223-601-5-13	INV	Pneu. Valve	277-05981
VK-9213-601-4-11	INV	Pneu. Valve	277-03170	VK-9223-602-4-10	INV	Pneu. Valve	277-03187
VK-9213-601-5-12	INV	Pneu. Valve	277-05980	VK-9223-602-5-12	INV	Pneu. Valve	279-05990
VK-9213-601-5-12	INV	Pneu. Valve	277-05980	VK-9223-602-5-13	INV	Pneu. Valve	277-05981
VK-9213-601-5-12	INV	Pneu. Valve	277-05980	VK-9223-603-4-10	INV	Pneu. Valve	277-03187
VK-9213-601-5-12	INV	Pneu. Valve	283-06160	VK-9223-603-5-12	INV	Pneu. Valve	279-05990
VK-9213-601-5-12	INV	Pneu. Valve	283-06160	VK-9223-603-5-13	INV	Pneu. Valve	277-05981
VK-9213-601-5-13	INV	Pneu. Valve	277-05981	VK-9223-801-5-13	INV	Pneu. Valve	279-05991
VK-9213-601-5-13	INV	Pneu. Valve	279-06161	VK-9223-803-5-12	INV	Pneu. Valve	279-05990
VK-9213-602-4-10	INV	Pneu. Valve	277-03169	VK-9223-813-5-15	INV	Pneu. Valve	287-05993
VK-9213-602-4-11	INV	Pneu. Valve	277-03170	VK-9223-813-5-16	INV	Pneu. Valve	287-05994
VK-9213-602-5-12	INV	Pneu. Valve	277-05980	VK-9253-301-4-3	INV	Pneu. Valve	268-03056
VK-9213-602-5-13	INV	Pneu. Valve	277-05981	VK-9263-303-4-3	INV	Pneu. Valve	270-03074
VK-9213-603-4-10	INV	Pneu. Valve	279-03169	VK-9273-301-4-3	INV	Pneu. Valve	268-03110
VK-9213-603-4-11	INV	Pneu. Valve	277-03170	VK-9273-301-4-6	INV	Pneu. Valve	268-03112
VK-9213-603-5-12	INV	Pneu. Valve	277-05980	VK-9273-301-4-8	INV	Pneu. Valve	268-03113
VK-9213-603-5-13	INV	Pneu. Valve	277-05981	VK-9273-301-4-9	INV	Pneu. Valve	268-03114
VK-9213-603-5-13	INV	Pneu. Valve	277-06161	VK-9273-302-4-3	INV	Pneu. Valve	269-03110
VK-9213-603-5-13	INV	Pneu. Valve	285-06161	VK-9273-302-4-6	INV	Pneu. Valve	269-03112
VK-9213-801-5-12	INV	Pneu. Valve	279-05980	VK-9273-302-4-8	INV	Pneu. Valve	269-03113
VK-9213-801-5-13	INV	Pneu. Valve	279-05981	VK-9273-302-4-9	INV	Pneu. Valve	269-03114
VK-9213-811-5-15	INV	Pneu. Valve	281-05983	VK-9273-303-4-3	INV	Pneu. Valve	270-03110
VK-9213-811-5-16	INV	Pneu. Valve	281-05984	VK-9273-303-4-6	INV	Pneu. Valve	270-03112
VK-9222-203-4-3	INV	Pneu. Valve	656-0012	VK-9273-303-4-8	INV	Pneu. Valve	270-03113
VK-9223-203-4-4	INV	Pneu. Valve	256-02010	VK-9273-303-4-9	INV	Pneu. Valve	270-03114
VK-9223-301-4-6	INV	Pneu. Valve	268-03166	VK-9273-371-4-10	INV	Pneu. Valve	268-03115
VK-9223-301-4-8	INV	Pneu. Valve	268-03167	VK-9273-371-4-11	INV	Pneu. Valve	268-03116
VK-9223-301-4-9	INV	Pneu. Valve	268-03168	VK-9273-372-4-10	INV	Pneu. Valve	269-03115
VK-9223-302-4-6	INV	Pneu. Valve	269-03166	VK-9273-372-4-11	INV	Pneu. Valve	269-03116
VK-9223-302-4-8	INV	Pneu. Valve	269-03167	VK-9273-373-4-10	INV	Pneu. Valve	270-03115
VK-9223-302-4-9	INV	Pneu. Valve	269-03168	VK-9273-373-4-11	INV	Pneu. Valve	270-03116
VK-9223-303-4-2	INV	Pneu. Valve	270-03180	VK-9273-601-4-10	INV	Pneu. Valve	277-03115
VK-9223-303-4-3	INV	Pneu. Valve	270-03182	VK-9273-601-4-11	INV	Pneu. Valve	277-03116
VK-9223-303-4-6	INV	Pneu. Valve	270-03166	VK-9273-602-4-10	INV	Pneu. Valve	277-03115
VK-9223-303-4-6	INV	Pneu. Valve	270-03184	VK-9273-602-4-11	INV	Pneu. Valve	277-03116
VK-9223-303-4-8	INV	Pneu. Valve	270-03167	VK-9273-603-4-10	INV	Pneu. Valve	277-03115
VK-9223-303-4-8	INV	Pneu. Valve	270-03185	VK-9273-603-4-11	INV	Pneu. Valve	277-03116
VK-9223-303-4-9	INV	Pneu. Valve	270-03168	VK-9283-301-4-3	INV	Pneu. Valve	268-03128

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Competitive Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
VK-9283-301-4-6	INV	Pneu. Valve	268-03130	VK-9313-602-4-11	INV	Pneu. Valve	277-03206
VK-9283-301-4-8	INV	Pneu. Valve	268-03131	VK-9313-602-5-14	INV	Pneu. Valve	281-05982
VK-9283-301-4-9	INV	Pneu. Valve	268-03132	VK-9313-603-4-10	INV	Pneu. Valve	277-03205
VK-9283-302-4-3	INV	Pneu. Valve	269-03128	VK-9313-603-4-11	INV	Pneu. Valve	277-03206
VK-9283-302-4-6	INV	Pneu. Valve	269-03130	VK-9313-603-5-14	INV	Pneu. Valve	281-05982
VK-9283-302-4-8	INV	Pneu. Valve	269-03131	VK-9313-801-5-14	INV	Pneu. Valve	281-05982
VK-9283-302-4-9	INV	Pneu. Valve	269-03132	VK-9313-812-5-16	INV	Pneu. Valve	281-06164
VK-9283-303-4-3	INV	Pneu. Valve	270-03128	VK-9323-601-5-14	INV	Pneu. Valve	281-05982
VK-9283-303-4-6	INV	Pneu. Valve	270-03130	VK-9323-602-5-14	INV	Pneu. Valve	281-05982
VK-9283-303-4-8	INV	Pneu. Valve	270-03131	VK-9323-603-5-14	INV	Pneu. Valve	281-05982
VK-9283-303-4-9	INV	Pneu. Valve	270-03132	VK-9323-801-5-14	INV	Pneu. Valve	281-05982
VK-9283-371-4-10	INV	Pneu. Valve	268-03115	VMP42.10(2)	LS	1/2", 2W, BR, Cv 0.4	599-02000
VK-9283-371-4-11	INV	Pneu. Valve	268-03134	VMP42.10(2)	LS	1/2", 2W, SS, Cv 0.4	599-02015
VK-9283-372-4-10	INV	Pneu. Valve	269-03115	VMP42.10(2)	LS	1/2", 3W, BR, Cv 0.4	599-02064
VK-9283-372-4-11	INV	Pneu. Valve	269-03134	VMP42.10(2)	LS	1/2", 3W, SS, Cv 0.4	599-02072
VK-9283-373-4-10	INV	Pneu. Valve	270-03115	VMP42.11(2)	LS	1/2", 2W, BR, Cv 0.63	599-02002
VK-9283-373-4-11	INV	Pneu. Valve	270-03134	VMP42.11(2)	LS	1/2", 2W, SS, Cv 0.63	599-02017
VK-9283-601-4-10	INV	Pneu. Valve	277-03115	VMP42.11(2)	LS	1/2", 3W, BR, Cv 0.63	599-02065
VK-9283-601-4-11	INV	Pneu. Valve	277-03134	VMP42.11(2)	LS	1/2", 3W, SS, Cv 0.63	599-02073
VK-9283-602-4-10	INV	Pneu. Valve	277-03115	VMP42.12(2)	LS	1/2", 2W, BR, Cv 1	599-02004
VK-9283-602-4-11	INV	Pneu. Valve	277-03134	VMP42.12(2)	LS	1/2", 2W, SS, Cv 1	599-02019
VK-9283-603-4-10	INV	Pneu. Valve	277-03115	VMP42.12(2)	LS	1/2", 3W, BR, Cv 1	599-02066
VK-9283-603-4-11	INV	Pneu. Valve	277-03134	VMP42.12(2)	LS	1/2", 3W, SS, Cv 1	599-02074
VK-9312-201-4-2	INV	Pneu. Valve	656-0010	VMP42.13(2)	LS	3/4", 2W, BR, Cv 1.6	599-02006
VK-9312-201-4-2	INV	Pneu. Valve	656-0011	VMP42.13(2)	LS	3/4", 2W, SS, Cv 1.6	599-02021
VK-9312-203-4-2	INV	Pneu. Valve	656-0009	VMP42.13(2)	LS	3/4", 3W, BR, Cv 1.6	599-02067
VK-9312-203-4-2	INV	Pneu. Valve	658-0051	VMP42.13(2)	LS	3/4", 3W, SS, Cv 1.6	599-02075
VK-9313-201-4-4	INV	Pneu. Valve	258-02069	VMP42.14(2)	LS	3/4", 2W, BR, Cv 2.5	599-02008
VK-9313-203-4-4	INV	Pneu. Valve	656-0015	VMP42.14(2)	LS	3/4", 2W, SS, Cv 2.5	599-02023
VK-9313-301-4-2	INV	Pneu. Valve	268-03200	VMP42.14(2)	LS	3/4", 3W, BR, Cv 2.5	599-02068
VK-9313-301-4-6	INV	Pneu. Valve	268-03202	VMP42.14(2)	LS	3/4", 3W, SS, Cv 2.5	599-02076
VK-9313-301-4-8	INV	Pneu. Valve	268-03203	VP512A1205	HW	Pneu. valve	257-02033
VK-9313-301-4-9	INV	Pneu. Valve	268-03204	VP512A1213	HW	Pneu. Valve	257-02035
VK-9313-302-4-2	INV	Pneu. Valve	269-03200	VP512A1221	HW	Pneu. valve	257-02037
VK-9313-302-4-6	INV	Pneu. Valve	269-03202	VP512A1643	HW	Pneu. Valve	257-02039
VK-9313-302-4-8	INV	Pneu. Valve	269-03203	VP512A1684	HW	Pneu. Valve	257-02045
VK-9313-302-4-9	INV	Pneu. Valve	269-03204	VP512A1726	HW	Pneu. Valve	268-03275
VK-9313-303-4-2	INV	Pneu. Valve	270-03200	VP512A1742	HW	Pneu. Valve	658-0012
VK-9313-303-4-6	INV	Pneu. Valve	270-03202	VP512A1776	HW	Pneu. Valve	268-03177
VK-9313-303-4-8	INV	Pneu. Valve	270-03203	VP512A1783	HW	Pneu. Valve	658-0014
VK-9313-303-4-9	INV	Pneu. Valve	270-03204	VP522A1039	HW	Pneu. Valve	658-0051
VK-9313-601-4-10	INV	Pneu. Valve	268-03205	VP522B1011	HW	Pneu. Valve	658-0052
VK-9313-601-4-11	INV	Pneu. Valve	268-03206	VP525A1077	HW	Pneu. Valve	257-02038
VK-9313-601-5-14	INV	Pneu. Valve	281-05982	VP525A1077	HW	Pneu. Valve	257-02039
VK-9313-602-4-10	INV	Pneu. Valve	277-03205	VP525A1085	HW	Pneu. Valve	257-02040

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
Barber Colman/Siebe/
Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
(Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
VP525A1101	HW	Pneu. valve	257-02041	VTM-TM019-324	HW	Pneu. Valve	270-03200
VP525A1192	HW	Pneu. Valve	257-02044	VTM-TM019-393	HW	Pneu. Valve	258-02069
VP525A1200	HW	Pneu. Valve	257-02044	VTM-TM019-394	HW	Pneu. Valve	656-0015
VP525A1218	HW	Pneu. Valve	656-0021	VTM-TM019-413	HW	Pneu. Valve	258-02069
VP525A1226	HW	Pneu. Valve	656-0018	VTM-TM019-414	HW	Pneu. Valve	656-0015
VP525A1408	HW	Pneu. Valve	257-02032	VTM-TN007-312	JC	Pneu. Valve	268-03162
VP525A1416	HW	Pneu. Valve	257-02039	VTM-TN007-314	JC	Pneu. Valve	270-03162
VP526A1068	HW	Pneu. Valve	656-0004	VTM-TN007-322	JC	Pneu. Valve	268-03162
VP526A1076	HW	Pneu. Valve	656-0011	VTM-TN007-324	JC	Pneu. Valve	270-03162
VP526A1084	HW	Pneu. Valve	656-0004	VTM-TN019-312	JC	Pneu. Valve	268-03164
VP531A1012	HW	Pneu. valve	257-02036	VTM-TN019-314	JC	Pneu. Valve	270-03164
VP531A1038	HW	Pneu. valve	257-02038	VTM-TN019-322	JC	Pneu. Valve	268-03164
VP-9213-201-4-2	INV	Elec. Valve	260-02034	VTM-TN019-324	JC	Pneu. Valve	270-03164
VP-9213-201-4-6	INV	Elec. Valve	260-02044	VVG41.11U	LS	Elec. Valve	599-03135
VP-9223-201-4-2	INV	Elec. Valve	260-02004	VVG41.12U	LS	Elec. Valve	599-03135
VP-9223-201-4-6	INV	Elec. Valve	260-02012	VVG41.13U	LS	Elec. Valve	599-03136
VS-7213-201-4-2	INV	Elec. Valve	260-02008	VVG41.14U	LS	Elec. Valve	599-03137
VS-7213-256-4-2	INV	Elec. Valve	259-02004	VVG41.15U	LS	Elec. Valve	599-03138
VS-7223-201-4-2	INV	Elec. Valve	260-02004	VVG41.20U	LS	Elec. Valve	599-03139
VS-7223-256-4-6	INV	Elec. Valve	259-02012	VVG41.25U	LS	Elec. Valve	599-03140
VTM-AA019-393	JC	Pneu. Valve	656-0017	VVG41.32U	LS	Elec. Valve	599-03141
VTM-AA019-413	JC	Pneu. Valve	656-0017	VVG41.40U	LS	Elec. Valve	599-03142
VTM-AN007-312	JC	Pneu. Valve	658-0007	VVG41.50U	LS	Elec. Valve	599-03143
VTM-AN007-322	JC	Pneu. Valve	658-0007	VXG41.1301U	LS	Elec. Valve	599-03154
VTM-AN019-312	JC	Pneu. Valve	658-0008	VXG41.1401U	LS	Elec. Valve	599-03155
VTM-AN019-314	JC	Pneu. Valve	658-0065	VXG41.1501U	LS	Elec. Valve	599-03156
VTM-AN019-322	JC	Pneu. Valve	658-0008	VXG41.15U	LS	Elec. Valve	599-03156
VTM-AN019-324	JC	Pneu. Valve	658-0065	VXG41.2001U	LS	Elec. Valve	599-03157
VTM-GN007-393	JC	Pneu. Valve	257-02035	VXG41.20U	LS	Elec. Valve	599-03157
VTM-GN007-413	JC	Pneu. Valve	257-02035	VXG41.2501U	LS	Elec. Valve	599-03158
VTM-GN019-312	JC	Pneu. Valve	268-03272	VXG41.25U	LS	Elec. Valve	599-03158
VTM-GN019-314	JC	Pneu. Valve	270-03164	VXG41.3201U	LS	Elec. Valve	599-03159
VTM-GN019-322	JC	Pneu. Valve	268-03272	VXG41.32U	LS	Elec. Valve	599-03159
VTM-GN019-324	JC	Pneu. Valve	270-03164	VXG41.4001U	LS	Elec. Valve	599-03160
VTM-GN019-393	JC	Pneu. Valve	257-02039	VXG41.40U	LS	Elec. Valve	599-03160
VTM-GN019-413	JC	Pneu. Valve	257-02039	VXG41.5001U	LS	Elec. Valve	599-03161
VTM-TC007-314	JC	Pneu. Valve	270-03180	VXG41.50U	LS	Elec. Valve	599-03161
VTM-TC007-324	JC	Pneu. Valve	270-03180	W351AA-1C	JC	Controller	RWD82U
VTM-TC019-314	JC	Pneu. Valve	270-03182	W351AA-2C	JC	Controller	RWD82U
VTM-TC019-324	JC	Pneu. Valve	270-03182	W351AB-2C	JC	Controller	RWD82U
VTM-TC019-394	JC	Pneu. Valve	256-02008	WLIMA1	AC	Elec. Room Thermostat	RAA20U
VTM-TC019-414	JC	Pneu. Valve	256-02008	YMC-1001	KR	Positioning/Gradual Switch	151-142
VTM-TM019-313	HW	Pneu. Valve	268-03200	YMC-2001	KR	Selector/Diverting Switch	786-0600
VTM-TM019-314	HW	Pneu. Valve	270-03200	YMC-3001	KR	Selector/Diverting Switch	786-0610
VTM-TM019-323	HW	Pneu. Valve	268-03200	033-202	LS	Pressure Elec. Switch	134-1460

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
033-203	LS	Pressure Elec. Switch	134-1460	134-1408	LS	EP Switch	265-1005
033-204	LS	Pressure Elec. Switch	251-0004	134-1452	LS	Pressure Elec. Switch	251-0001
033-205	LS	Pressure Elec. Switch	251-0002	134-1453	LS	Pressure Elec. Switch	251-0009
033-206	LS	Pressure Elec. Switch	251-0002	134-1454	LS	Pressure Elec. Switch	251-0008
033-207	LS	Pressure Elec. Switch	251-0002	134-1455	LS	Pressure Elec. Switch	251-0004
033-208	LS	Pressure Elec. Switch	251-0008	134-1456	LS	Pressure Elec. Switch	251-0002
033-209	LS	Pressure Elec. Switch	251-0008	134-1457	LS	Pressure Elec. Switch	251-0010
033-210	LS	Pressure Elec. Switch	251-0008	134-1458	LS	Pressure Elec. Switch	251-0005
033-211	LS	Pressure Elec. Switch	251-0004	134-1459	LS	Pressure Elec. Switch	251-0008
033-212	LS	Pressure Elec. Switch	134-1460	134-1514	LS	Low Temp. Detection Thermostat	134-1510
033-213	LS	Pressure Elec. Switch	134-1460	141-0522	LS	Line Voltage Room Thermostat	134-1085
033-214	LS	Pressure Elec. Switch	251-0004	141-0523	LS	Line Voltage Room Thermostat	134-1085
033-215	LS	Pressure Elec. Switch	251-0009	141-0524	LS	Line Voltage Room Thermostat	134-1083
033-216	LS	Pressure Elec. Switch	251-0010	141-0525	LS	Line Voltage Room Thermostat	134-1084
033-217	LS	Pressure Elec. Switch	251-0011	141-0526	LS	Line Voltage Room Thermostat	134-1084
033-218	LS	Pressure Elec. Switch	251-0011	141-0529	LS	Low Voltage Room Thermostat	141-0599
0672T0281EA00	INV	Elec. Valve	261-02030	141-0531	LS	High Temp. Limit Thermostat	141-0530
0672T0284EA00	INV	Elec. Valve	261-02041	141-0532	LS	Diff. Static Pressure Air Flow Switch	141-0574
0672T0293EA00	INV	Elec. Valve	261-02068	141-0564	LS	Low Temp. Detection Thermostat	134-1510
0691T0281EA00	INV	Elec. Valve	261-02030	141-0565	LS	Low Temp. Detection Thermostat	134-1511
0691T0282EA00	INV	Elec. Valve	261-02031	141-0595	LS	Low Voltage Room Thermostat	141-0599
1A11-2	WR	Two-pipe Heat-Off-Cool Hi-Med-Low	RCC10U	180-400	LS	Pneu. Room Thermostat	192-202
1F79-111	WR	Heat Pump	RDX42.22U	180-401	LS	Pneu. Room Thermostat	192-202
1F89-211	WR	Heat Pump	RDX42.22U	180-402	LS	Pneu. Room Thermostat	192-202
134-1001	LS	Low Voltage Room Thermostat	141-0599	180-403	LS	Pneu. Room Thermostat	192-202
134-1024	LS	Low Voltage Room Thermostat	141-0599	180-410	LS	Pneu. Room Thermostat	192-204
134-1026	LS	Line Voltage Room Thermostat	134-1085	180-411	LS	Pneu. Room Thermostat	192-204
134-1028	LS	Line Voltage Room Thermostat	134-1085	180-412	LS	Pneu. Room Thermostat	192-204
134-1035	LS	Line Voltage Room Thermostat	134-1083	180-413	LS	Pneu. Room Thermostat	192-204
134-1036	LS	Line Voltage Room Thermostat	134-1084	180-414	LS	Pneu. Room Thermostat	192-206
134-1038	LS	Line Voltage Room Thermostat	134-1084	180-416	LS	Pneu. Room Thermostat	192-206
134-1080	LS	Elec. Line Volt. Bulb Thermostat	141-0520	180-417	LS	Pneu. Room Thermostat	192-206
134-1081	LS	Elec. Line Volt. Bulb Thermostat	141-0520	180-420	LS	Pneu. Room Thermostat	192-208
134-1082	LS	Elec. Line Volt. Bulb Thermostat	141-0521	180-420	LS	Pneu. Room Thermostat	194-3084
134-1101	LS	High Temp. Limit Thermostat	141-0519	180-422	LS	Pneu. Room Thermostat	192-208
134-1102	LS	High Temp. Limit Thermostat	141-0519	180-422	LS	Pneu. Room Thermostat	194-3084
134-1106	LS	High Temp. Limit Thermostat	141-0530	180-423	LS	Pneu. Room Thermostat	192-208
134-1400	LS	EP Switch	265-1002	180-423	LS	Pneu. Room Thermostat	194-3084
134-1402	LS	EP Switch	265-1006	180-430	LS	Pneu. Room Thermostat	192-203
134-1403	LS	EP Switch	265-1005	180-431	LS	Pneu. Room Thermostat	192-203
134-1404	LS	EP Switch	265-1002	180-432	LS	Pneu. Room Thermostat	192-203
134-1405	LS	EP Switch	265-1004	180-433	LS	Pneu. Room Thermostat	192-203
134-1406	LS	EP Switch	265-1003	180-884	LS	Pneu. Room Thermostat	192-202
134-1407	LS	EP Switch	265-1006	180-885	LS	Pneu. Room Thermostat	192-203
				180-887	LS	Pneu. Room Thermostat	192-204

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
180-900	LS	Pneu. Room Thermostat	192-202	182-627	LS	Pneu. Room Thermostat	192-204
180-901	LS	Pneu. Room Thermostat	192-202	182-628	LS	Pneu. Room Thermostat	192-205
180-902	LS	Pneu. Room Thermostat	192-202	182-630	LS	Pneu. Room Thermostat	192-204
180-903	LS	Pneu. Room Thermostat	192-202	182-633	LS	Pneu. Room Thermostat	192-208
180-910	LS	Pneu. Room Thermostat	192-204	182-633	LS	Pneu. Room Thermostat	194-3084
180-911	LS	Pneu. Room Thermostat	192-204	182-634	LS	Pneu. Room Thermostat	192-208
180-912	LS	Pneu. Room Thermostat	192-204	182-634	LS	Pneu. Room Thermostat	194-3084
180-913	LS	Pneu. Room Thermostat	192-204	182-635	LS	Pneu. Room Thermostat	192-207
180-914	LS	Pneu. Room Thermostat	192-206	182-635	LS	Pneu. Room Thermostat	192-227
180-915	LS	Pneu. Room Thermostat	192-206	182-636	LS	Pneu. Room Thermostat	192-210
180-916	LS	Pneu. Room Thermostat	192-206	182-638	LS	Pneu. Room Thermostat	192-210
180-917	LS	Pneu. Room Thermostat	192-206	182-673	LS	Pneu. Room Thermostat	193-211
180-918	LS	Pneu. Room Thermostat	192-206	182-674	LS	Pneu. Room Thermostat	193-214
180-920	LS	Pneu. Room Thermostat	192-208	182-675	LS	Pneu. Room Thermostat	193-212
180-920	LS	Pneu. Room Thermostat	194-3084	182-676	LS	Pneu. Room Thermostat	193-213
180-921	LS	Pneu. Room Thermostat	192-208	182-677	LS	Pneu. Room Thermostat	193-231
180-921	LS	Pneu. Room Thermostat	194-3084	182-678	LS	Pneu. Room Thermostat	193-234
180-922	LS	Pneu. Room Thermostat	192-208	182-679	LS	Pneu. Room Thermostat	193-232
180-922	LS	Pneu. Room Thermostat	194-3084	182-680	LS	Pneu. Room Thermostat	193-233
180-923	LS	Pneu. Room Thermostat	192-208	182-694	LS	Pneu. Room Thermostat	192-209
180-923	LS	Pneu. Room Thermostat	194-3084	185-0001	LS	Pneu. Receiver-Controller	195-0011
180-924	LS	Pneu. Room Thermostat	192-200	185-0002	LS	Pneu. Receiver-Controller	195-0011
180-925	LS	Pneu. Room Thermostat	192-200	185-0003	LS	Pneu. Receiver-Controller	195-0011
180-926	LS	Pneu. Room Thermostat	192-200	185-0004	LS	Pneu. Receiver-Controller	195-0011
180-927	LS	Pneu. Room Thermostat	192-200	185-0005	LS	Pneu. Receiver-Controller	195-0011
180-932	LS	Pneu. Room Thermostat	192-203	185-0006	LS	Pneu. Receiver-Controller	195-0011
180-933	LS	Pneu. Room Thermostat	192-203	185-0007	LS	Pneu. Receiver-Controller	195-0011
180-937	LS	Pneu. Room Thermostat	192-205	185-0008	LS	Pneu. Receiver-Controller	195-0011
180-942	LS	Pneu. Room Thermostat	192-201	185-0009	LS	Pneu. Receiver-Controller	195-0011
182-421	LS	Pneu. Room Thermostat	192-208	185-0010	LS	Pneu. Receiver-Controller	195-0011
182-421	LS	Pneu. Room Thermostat	194-3084	185-0011	LS	Pneu. Receiver-Controller	195-0011
182-500	LS	Pneu. Room Thermostat	192-204	185-0012	LS	Pneu. Receiver-Controller	195-0011
182-501	LS	Pneu. Room Thermostat	192-204	185-0013	LS	Pneu. Receiver-Controller	195-0011
182-502	LS	Pneu. Room Thermostat	192-204	185-0014	LS	Pneu. Receiver-Controller	195-0011
182-503	LS	Pneu. Room Thermostat	192-205	185-0015	LS	Pneu. Receiver-Controller	195-0003
182-504	LS	Pneu. Room Thermostat	192-206	185-0016	LS	Pneu. Receiver-Controller	195-0003
182-505	LS	Pneu. Room Thermostat	192-206	185-0017	LS	Pneu. Receiver-Controller	195-0003
182-506	LS	Pneu. Room Thermostat	192-208	185-0018	LS	Pneu. Receiver-Controller	195-0003
182-506	LS	Pneu. Room Thermostat	194-3084	185-0023	LS	Pneu. Receiver-Controller	195-0003
182-507	LS	Pneu. Room Thermostat	192-208	185-0024	LS	Pneu. Receiver-Controller	195-0003
182-507	LS	Pneu. Room Thermostat	194-3084	185-0025	LS	Pneu. Receiver-Controller	195-0003
182-508	LS	Pneu. Room Thermostat	192-207	185-0031	LS	Pneu. Receiver-Controller	195-0003
182-509	LS	Pneu. Room Thermostat	192-207	185-0032	LS	Pneu. Receiver-Controller	195-0003
182-625	LS	Pneu. Room Thermostat	192-210	185-0033	LS	Pneu. Receiver-Controller	195-0003
182-626	LS	Pneu. Room Thermostat	192-210	185-0034	LS	Pneu. Receiver-Controller	195-0003

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
185-0035	LS	Pneu. Receiver-Controller	195-0003	188-0020	LS	Unit Mount Thermostat	188-0030
185-0036	LS	Pneu. Receiver-Controller	195-0003	188-0021	LS	Unit Mount Thermostat	184-0024
185-0037	LS	Pneu. Receiver-Controller	195-0011	188-0022	LS	Room and Duct Hygrostat	188-0031
185-0038	LS	Pneu. Receiver-Controller	195-0011	188-0023	LS	Room and Duct Hygrostat	188-0030
185-0067	LS	Pneu. Receiver-Controller	195-0011	188-0025	LS	Room and Duct Hygrostat	188-0031
185-0068	LS	Pneu. Receiver-Controller	195-0011	188-0026	LS	Room and Duct Hygrostat	188-0030
185-0069	LS	Pneu. Receiver-Controller	195-0011	188-0027	LS	Room and Duct Hygrostat	188-0031
185-0070	LS	Pneu. Receiver-Controller	195-0011	190-1100	LS	Room and Duct Hygrostat	186-0013
185-0071	LS	Pneu. Receiver-Controller	195-0011	190-1110	LS	Room and Duct Hygrostat	186-0013
185-0072	LS	Pneu. Receiver-Controller	195-0011	190-1120	LS	Room and Duct Hygrostat	186-0019
185-0073	LS	Pneu. Receiver-Controller	195-0011	190-1130	LS	Room and Duct Hygrostat	186-0019
185-0074	LS	Pneu. Receiver-Controller	195-0011	190-1240	LS	Room and Duct Hygrostat	186-0019
185-0075	LS	Pneu. Receiver-Controller	195-0011	191-0250	LS	Room and Duct Hygrostat	186-0087
185-0076	LS	Pneu. Receiver-Controller	195-0011	191-0260	LS	Room and Duct Hygrostat	186-0088
185-0093	LS	Pneu. Receiver-Controller	195-0011	1A10-651	WR	Elec. Room Thermostat	RAA20U
185-0123	LS	Pneu. Receiver-Controller	195-0011	1A11-2	WR	Elec. Room Thermostat	RAB30U
185-0124	LS	Pneu. Receiver-Controller	195-0011	1A16-51	WR	Elec. Room Thermostat	RAA20U
185-0125	LS	Pneu. Receiver-Controller	195-0003	1A65-641	WR	Elec. Room Thermostat	RAA20U
185-0126	LS	Pneu. Receiver-Controller	195-0003	1A66-641	WR	Elec. Room Thermostat	RAA20U
186-0001	LS	Room and Duct Hygrostat	186-0013	1C70-1	WR	Low Voltage Room Thermostat	141-0596
186-0006	LS	Room and Duct Hygrostat	186-0013	1C70-51	WR	Low Voltage Room Thermostat	141-0596
186-0007	LS	Room and Duct Hygrostat	186-0019	1C72-101	WR	Low Voltage Room Thermostat	141-0596
186-0012	LS	Room and Duct Hygrostat	186-0019	1C72-251	WR	Low Voltage Room Thermostat	141-0596
186-0018	LS	Room and Duct Hygrostat	186-0013	1C76-151	WR	Low Voltage Room Thermostat	141-0596
186-0024	LS	Room and Duct Hygrostat	186-0019	1E30-910	WR	Elec. Room Thermostat	RAA20U
186-0025	LS	Humidity Transmitter	186-0043	1E35-608	WR	Low Voltage Room Thermostat	141-0599
186-0030	LS	Humidity Transmitter	186-0043	1E35-910	WR	Low Voltage Room Thermostat	141-0599
186-0031	LS	Humidity Transmitter	186-0043	1E56-301	WR	Low Voltage Room Thermostat	141-0599
186-0036	LS	Humidity Transmitter	186-0043	1F35-910	WR	Low Voltage Room Thermostat	141-0599
186-0037	LS	Humidity Transmitter	186-0043	1F36-335	WR	Low Voltage Room Thermostat	141-0599
186-0042	LS	Humidity Transmitter	186-0043	1F56-301	WR	Low Voltage Room Thermostat	141-0599
186-0048	LS	Humidity Transmitter	186-0043	1F57-306	WR	Low Voltage Room Thermostat	141-0596
186-0049	LS	Room and Duct Hygrostat	186-0087	1F92-1	WR	Low Voltage Room Thermostat	141-0597
186-0050	LS	Room and Duct Hygrostat	186-0088	20-880	INV	Pressure Reducing Valves	201-1001
186-0051	LS	Humidity Transmitter	186-0089	20-907	INV	Relief Valve	515-0190
186-0053	LS	Room and Duct Hygrostat	186-0092	21-196	INV	Air Filter	908-033
186-0054	LS	Room and Duct Hygrostat	186-0091	21-501	INV	Air Filter	908-051
186-0075	LS	Room and Duct Hygrostat	186-0090	2211-012	INV	Pneu. Room Thermostat	192-200
186-0076	LS	Room and Duct Hygrostat	186-0091	2211-013	INV	Pneu. Room Thermostat	192-201
188-0001	LS	Unit Mount Thermostat	188-0030	2211-113	INV	Pneu. Room Thermostat	192-201
188-0002	LS	Unit Mount Thermostat	188-0031	2211-411	INV	Pneu. Room Thermostat	192-200
188-0003	LS	Unit Mount Thermostat	188-0024	2211-412	INV	Pneu. Room Thermostat	192-201
188-0004	LS	Unit Mount Thermostat	188-0030	2211-512	INV	Pneu. Room Thermostat	192-200
188-0005	LS	Unit Mount Thermostat	188-0031	2211-513	INV	Pneu. Room Thermostat	192-201
188-0006	LS	Unit Mount Thermostat	184-0024	2212-012	INV	Pneu. Room Thermostat	192-202

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
2212-118	INV	Pneu. Room Thermostat	192-202	2341-502	INV	Pneu. Receiver-Controller	195-0003
2212-119	INV	Pneu. Room Thermostat	192-203	2353-502	INV	Switching Relay	243-0001
2212-128	INV	Pneu. Room Thermostat	192-202	2354-501	INV	Switching Relay	243-0001
2212-129	INV	Pneu. Room Thermostat	192-203	2354-502	INV	Switching Relay	243-0001
2212-301	INV	Pneu. Room Thermostat	192-202	2360-501	INV	Reverse-Acting Relay	243-0024
2212-302	INV	Pneu. Room Thermostat	192-202	2364-202	INV	Pressure Elec. Switch	251-0004
2212-318	INV	Pneu. Room Thermostat	193-215	2364-211	INV	Pressure Elec. Switch	251-0001
2212-418	INV	Pneu. Room Thermostat	192-202	2364-211	INV	Pressure Elec. Switch	251-0001
2212-518	INV	Pneu. Room Thermostat	192-202	2368-301	INV	EP Switch	265-1001
2214-112	INV	Pneu. Room Thermostat	192-200	2368-302	INV	EP Switch	265-1002
2214-121	INV	Pneu. Room Thermostat	192-204	2368-303	INV	EP Switch	265-1003
2214-122	INV	Pneu. Room Thermostat	192-205	2368-304	INV	EP Switch	265-1004
2214-131	INV	Pneu. Room Thermostat	192-204	2368-305	INV	EP Switch	265-1005
2214-132	INV	Pneu. Room Thermostat	192-205	2368-306	INV	EP Switch	265-1006
2214-521	INV	Pneu. Room Thermostat	192-204	2368-401	INV	EP Switch	265-1001
2214-522	INV	Pneu. Room Thermostat	192-205	2368-402	INV	EP Switch	265-1002
2216-136	INV	Pneu. Room Thermostat	192-206	2368-403	INV	EP Switch	265-1003
2216-526	INV	Pneu. Room Thermostat	192-206	2368-404	INV	EP Switch	265-1004
2218-132	INV	Pneu. Room Thermostat	192-208	2368-406	INV	EP Switch	265-1006
2218-133	INV	Pneu. Room Thermostat	192-209	2372-352	INV	Highest Pressure Relay	243-0018
2218-134	INV	Pneu. Room Thermostat	192-208	2372-501	INV	Lowest Pressure Selector	243-0026
2218-134	INV	Pneu. Room Thermostat	194-3082	2372-501	INV	Lowest Pressure Selector	243-0028
2218-142	INV	Pneu. Room Thermostat	192-208	2372-502	INV	Highest Pressure Relay	243-0018
2218-301	INV	Pneu. Room Thermostat	192-208	2373-501	INV	High/Low Signal Selector Relay	243-0019
2218-532	INV	Pneu. Room Thermostat	192-208	2374-410	INV	Diff. Static Pressure Air Flow Switch	141-0518
2218-532	INV	Pneu. Room Thermostat	192-208	2380-504	INV	Pneu. Step Controller	256-1015
2220-053	INV	Temp. Transmitter	184-0129	2380-506	INV	Pneu. Step Controller	256-1015
2230-018	INV	Room and Duct Hygrostat	186-0007	2380-508	INV	Pneu. Step Controller	256-1015
2230-118	INV	Room and Duct Hygrostat	186-0001	2380-510	INV	Pneu. Step Controller	256-1015
2252-151	INV	Temp. Transmitter	184-0006	2390-501	INV	Positioning/Gradual Switch	141-0600
2252-250	INV	Temp. Transmitter	184-0028	2390-501	INV	Positioning/Gradual Switch	151-142
2252-501	INV	Temp. Transmitter	184-0004	2390-515	INV	Positioning/Gradual Switch	151-142
2252-510	INV	Temp. Transmitter	184-0001	2392-504	INV	Selector/Diverting Switch	786-0600
2282-410	INV	High Temp. Limit Thermostat	141-0530	2393-504	INV	Selector/Diverting Switch	786-0610
2302-051	INV	Diff. Pressure Transmitter	378-2000	2420-001	INV	Pressure Gauge	142-0373
2323-500	INV	Low Diff. Pressure Transmitter	141-0592	243-0014	LS	Highest Pressure Relay	243-0018
2323-503	INV	Low Diff. Pressure Transmitter	141-0591	243-0014	LS	Lowest Pressure Selector	243-0020
2323-504	INV	Low Diff. Pressure Transmitter	141-0593	243-0015	LS	High/Low Signal Selector Relay	243-0019
2323-505	INV	Low Diff. Pressure Transmitter	141-0590	2466-011	INV	Pneu. Damper Actuator	331-2882
2327-020	INV	Air Velocity Transmitter	141-0582	2473-020	INV	Pneu. Damper Actuator	331-4313
2327-020	INV	Air Velocity Transmitter	141-0583	2473-030	INV	Pneu. Damper Actuator	331-4513
2327-040	INV	Air Velocity Transmitter	141-0584	2473-040	INV	Pneu. Damper Actuator	331-4813
2327-055	INV	Air Velocity Transmitter	141-0585	2473-120	INV	Pneu. Damper Actuator	331-4313
2341-001	INV	Pneu. Receiver-Controller	195-0003	2473-130	INV	Pneu. Damper Actuator	331-4513
2341-501	INV	Pneu. Receiver-Controller	195-0003	2473-140	INV	Pneu. Damper Actuator	331-4813

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
2473-220	INV	Pneu. Damper Actuator	331-4311	2545-332	INV	Pneu. Valve	283-03167
2473-230	INV	Pneu. Damper Actuator	331-4511	2545-333	INV	Pneu. Valve	277-03168
2473-240	INV	Pneu. Damper Actuator	331-4811	2545-334	INV	Pneu. Valve	277-03168
2473-260	INV	Pneu. Damper Actuator	332-4811	2545-335	INV	Pneu. Valve	277-03168
2473-260	INV	Pneu. Damper Actuator	332-4811	2545-336	INV	Pneu. Valve	283-03168
2474-020	INV	Pneu. Damper Actuator	331-2911	2545-337	INV	Pneu. Valve	277-03169
2474-030	INV	Pneu. Damper Actuator	331-2934	2545-338	INV	Pneu. Valve	277-03169
2474-040	INV	Pneu. Damper Actuator	331-2966	2545-339	INV	Pneu. Valve	277-03169
2474-120	INV	Pneu. Damper Actuator	331-2911	2545-340	INV	Pneu. Valve	283-03169
2474-130	INV	Pneu. Damper Actuator	331-2934	2545-341	INV	Pneu. Valve	277-03170
2474-140	INV	Pneu. Damper Actuator	331-2966	2545-342	INV	Pneu. Valve	277-03170
2474-210	INV	Pneu. Damper Actuator	331-3001	2545-343	INV	Pneu. Valve	277-03170
2474-220	INV	Pneu. Damper Actuator	331-3000	2545-344	INV	Pneu. Valve	283-03170
2474-230	INV	Pneu. Damper Actuator	331-3002	2545-613	INV	Pneu. Valve	277-03169
2474-240	INV	Pneu. Damper Actuator	331-2973	2545-614	INV	Pneu. Valve	277-03169
2474-260	INV	Pneu. Damper Actuator	332-2973	2545-615	INV	Pneu. Valve	277-03169
2492-020	INV	Pneu. Damper Actuator	331-4314	2545-616	INV	Pneu. Valve	283-03169
2492-030	INV	Pneu. Damper Actuator	331-4514	2545-617	INV	Pneu. Valve	277-03170
2492-040	INV	Pneu. Damper Actuator	331-4814	2545-618	INV	Pneu. Valve	277-03170
2492-120	INV	Pneu. Damper Actuator	331-4314	2545-619	INV	Pneu. Valve	277-03170
2492-130	INV	Pneu. Damper Actuator	331-4514	2545-620	INV	Pneu. Valve	283-03170
2492-140	INV	Pneu. Damper Actuator	331-4814	2545-629	INV	Pneu. Valve	277-05980
251-0003	LS	Pressure Elec. Switch	251-0002	2545-630	INV	Pneu. Valve	277-05980
251-0012	LS	Pressure Elec. Switch	251-0011	2545-631	INV	Pneu. Valve	277-05980
2541-304	INV	Pneu. Valve	658-0007	2545-632	INV	Pneu. Valve	283-05980
2541-306	INV	Pneu. Valve	658-0064	2545-633	INV	Pneu. Valve	277-05981
2541-307	INV	Pneu. Valve	658-0008	2545-634	INV	Pneu. Valve	277-05981
2541-309	INV	Pneu. Valve	658-0065	2545-635	INV	Pneu. Valve	277-05981
2541-315	INV	Pneu. Valve	658-0067	2545-636	INV	Pneu. Valve	283-05981
2541-319	INV	Pneu. Valve	658-0012	2545-637	INV	Pneu. Valve	281-05982
2541-324	INV	Pneu. Valve	658-0069	2545-638	INV	Pneu. Valve	281-05982
2541-325	INV	Pneu. Valve	658-0014	2545-639	INV	Pneu. Valve	281-05982
2542-304	INV	Pneu. Valve	268-03270	2545-640	INV	Pneu. Valve	287-05982
2542-307	INV	Pneu. Valve	268-03272	2546-321	INV	Pneu. Valve	277-03166
2542-316	INV	Pneu. Valve	268-03274	2546-322	INV	Pneu. Valve	277-03166
2542-322	INV	Pneu. Valve	268-03275	2546-323	INV	Pneu. Valve	277-03166
2542-325	INV	Pneu. Valve	658-0022	2546-324	INV	Pneu. Valve	283-03166
2542-327	INV	Pneu. Valve	658-0071	2546-329	INV	Pneu. Valve	277-03167
2545-321	INV	Pneu. Valve	277-03166	2546-330	INV	Pneu. Valve	277-03167
2545-322	INV	Pneu. Valve	277-03166	2546-331	INV	Pneu. Valve	277-03167
2545-323	INV	Pneu. Valve	277-03166	2546-332	INV	Pneu. Valve	283-03167
2545-324	INV	Pneu. Valve	283-03166	2546-333	INV	Pneu. Valve	277-03168
2545-329	INV	Pneu. Valve	277-03167	2546-334	INV	Pneu. Valve	277-03168
2545-330	INV	Pneu. Valve	277-03167	2546-335	INV	Pneu. Valve	277-03168
2545-331	INV	Pneu. Valve	277-03167	2546-336	INV	Pneu. Valve	283-03168

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
2546-338	INV	Pneu. Valve	277-03187	2547-340	INV	Pneu. Valve	283-03115
2546-339	INV	Pneu. Valve	277-03187	2547-341	INV	Pneu. Valve	277-03116
2546-340	INV	Pneu. Valve	283-03187	2547-342	INV	Pneu. Valve	277-03116
2546-341	INV	Pneu. Valve	277-03170	2547-343	INV	Pneu. Valve	277-03116
2546-342	INV	Pneu. Valve	277-03170	2547-344	INV	Pneu. Valve	283-03116
2546-343	INV	Pneu. Valve	283-03170	2547-637	INV	Pneu. Valve	277-03115
2546-613	INV	Pneu. Valve	277-03187	2547-638	INV	Pneu. Valve	277-03115
2546-614	INV	Pneu. Valve	277-03187	2547-639	INV	Pneu. Valve	277-03115
2546-615	INV	Pneu. Valve	277-03187	2547-640	INV	Pneu. Valve	283-03115
2546-616	INV	Pneu. Valve	283-03187	2547-641	INV	Pneu. Valve	277-03116
2546-617	INV	Pneu. Valve	277-03188	2547-642	INV	Pneu. Valve	277-03116
2546-618	INV	Pneu. Valve	591-7880	2547-643	INV	Pneu. Valve	277-03116
2546-619	INV	Pneu. Valve	591-7881	2547-644	INV	Pneu. Valve	283-03116
2546-620	INV	Pneu. Valve	591-7882	2548-309	INV	Pneu. Valve	277-03128
2546-629	INV	Pneu. Valve	277-05980	2548-310	INV	Pneu. Valve	277-03128
2546-630	INV	Pneu. Valve	277-05980	2548-311	INV	Pneu. Valve	277-03128
2546-631	INV	Pneu. Valve	277-05980	2548-312	INV	Pneu. Valve	283-03128
2546-632	INV	Pneu. Valve	283-05980	2548-321	INV	Pneu. Valve	277-03130
2546-633	INV	Pneu. Valve	277-05981	2548-322	INV	Pneu. Valve	277-03130
2546-634	INV	Pneu. Valve	277-05981	2548-323	INV	Pneu. Valve	277-03130
2546-635	INV	Pneu. Valve	277-05981	2548-324	INV	Pneu. Valve	283-03130
2546-636	INV	Pneu. Valve	283-05981	2548-329	INV	Pneu. Valve	277-03131
2546-637	INV	Pneu. Valve	281-05982	2548-330	INV	Pneu. Valve	277-03131
2546-638	INV	Pneu. Valve	281-05982	2548-331	INV	Pneu. Valve	277-03131
2546-639	INV	Pneu. Valve	281-05982	2548-332	INV	Pneu. Valve	283-03131
2546-640	INV	Pneu. Valve	287-05982	2548-333	INV	Pneu. Valve	277-03132
2547-309	INV	Pneu. Valve	277-03110	2548-334	INV	Pneu. Valve	277-03132
2547-310	INV	Pneu. Valve	277-03110	2548-335	INV	Pneu. Valve	277-03132
2547-311	INV	Pneu. Valve	277-03110	2548-336	INV	Pneu. Valve	283-03132
2547-312	INV	Pneu. Valve	283-03110	2548-337	INV	Pneu. Valve	277-03115
2547-321	INV	Pneu. Valve	277-03112	2548-338	INV	Pneu. Valve	277-03115
2547-322	INV	Pneu. Valve	277-03112	2548-339	INV	Pneu. Valve	277-03115
2547-323	INV	Pneu. Valve	277-03112	2548-340	INV	Pneu. Valve	283-03115
2547-324	INV	Pneu. Valve	283-03112	2548-341	INV	Pneu. Valve	277-03134
2547-329	INV	Pneu. Valve	277-03113	2548-342	INV	Pneu. Valve	277-03134
2547-330	INV	Pneu. Valve	277-03113	2548-343	INV	Pneu. Valve	277-03134
2547-331	INV	Pneu. Valve	277-03113	2548-344	INV	Pneu. Valve	283-03134
2547-332	INV	Pneu. Valve	283-03113	2548-637	INV	Pneu. Valve	277-03115
2547-333	INV	Pneu. Valve	277-03114	2548-638	INV	Pneu. Valve	277-03115
2547-334	INV	Pneu. Valve	277-03114	2548-639	INV	Pneu. Valve	277-03115
2547-335	INV	Pneu. Valve	277-03114	2548-640	INV	Pneu. Valve	283-03115
2547-336	INV	Pneu. Valve	283-03114	2548-641	INV	Pneu. Valve	277-03134
2547-337	INV	Pneu. Valve	277-03115	2548-642	INV	Pneu. Valve	277-03134
2547-338	INV	Pneu. Valve	277-03115	2548-643	INV	Pneu. Valve	277-03134
2547-339	INV	Pneu. Valve	277-03115	2548-644	INV	Pneu. Valve	283-03134

AC Accustat	INV Invensys (Robertshaw/ Barber Colman/Siebe/ Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/ Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
255-0450	LS	EP Switch	265-1002	2552-622	INV	Pneu. Valve	283-06160
255-0460	LS	EP Switch	265-1004	2552-623	INV	Pneu. Valve	277-06160
255-0470	LS	EP Switch	265-1006	2552-624	INV	Pneu. Valve	277-06160
255-0480	LS	EP Switch	265-1003	2552-625	INV	Pneu. Valve	277-06160
2552-301	INV	Pneu. Valve	277-03200	2552-626	INV	Pneu. Valve	283-06161
2552-302	INV	Pneu. Valve	277-03200	2552-627	INV	Pneu. Valve	283-06161
2552-303	INV	Pneu. Valve	270-03200	2552-628	INV	Pneu. Valve	285-06161
2552-303	INV	Pneu. Valve	277-03200	2552-629	INV	Pneu. Valve	277-06161
2552-304	INV	Pneu. Valve	283-03200	2552-630	INV	Pneu. Valve	277-06161
2552-305	INV	Pneu. Valve	283-03200	256-1008	LS	Pneu. Step Controller	256-1015
2552-311	INV	Pneu. Valve	268-03202	256-1010	LS	Pneu. Step Controller	256-1015
2552-311	INV	Pneu. Valve	277-03202	265-0001	LS	EP Switch	265-1001
2552-312	INV	Pneu. Valve	277-03202	265-0002	LS	EP Switch	265-1002
2552-313	INV	Pneu. Valve	270-03202	265-0003	LS	EP Switch	265-1003
2552-313	INV	Pneu. Valve	277-03202	265-0004	LS	EP Switch	265-1004
2552-314	INV	Pneu. Valve	283-03202	265-0005	LS	EP Switch	265-1005
2552-315	INV	Pneu. Valve	283-03202	265-0006	LS	EP Switch	265-1006
2552-316	INV	Pneu. Valve	268-03203	265-0007	LS	EP Switch	265-1001
2552-319	INV	Pneu. Valve	283-03203	265-0008	LS	EP Switch	265-1002
2552-320	INV	Pneu. Valve	283-03203	265-0009	LS	EP Switch	265-1007
2552-321	INV	Pneu. Valve	268-03204	265-1013	LS	EP Switch	265-1001
2552-321	INV	Pneu. Valve	277-03204	265-1014	LS	EP Switch	265-1002
2552-322	INV	Pneu. Valve	277-03204	265-1015	LS	EP Switch	265-1003
2552-323	INV	Pneu. Valve	270-03204	265-1016	LS	EP Switch	265-1004
2552-323	INV	Pneu. Valve	277-03204	265-1017	LS	EP Switch	265-1005
2552-324	INV	Pneu. Valve	283-03204	265-1018	LS	EP Switch	265-1006
2552-325	INV	Pneu. Valve	283-03204	265-1019	LS	EP Switch	265-1007
2552-326	INV	Pneu. Valve	277-03205	265-1020	LS	EP Switch	265-1008
2552-327	INV	Pneu. Valve	277-03205	305929	HW	Receiver Gauge	142-0430
2552-328	INV	Pneu. Valve	283-03205	305931	HW	Receiver Gauge	142-0431
2552-329	INV	Pneu. Valve	283-03205	305965	HW	Pressure Gauge	142-0373
2552-330	INV	Pneu. Valve	277-03206	305972	HW	Receiver Gauge	142-0242
2552-331	INV	Pneu. Valve	277-03206	31-102	INV	Elec. Room Thermostat	RAA20U
2552-332	INV	Pneu. Valve	283-03206	331-0200	LS	Pneu. Damper Actuator	331-4312
2552-333	INV	Pneu. Valve	283-03206	331-0220	LS	Pneu. Damper Actuator	331-2904
2552-601	INV	Pneu. Valve	277-03205	331-0230	LS	Pneu. Damper Actuator	331-2900
2552-602	INV	Pneu. Valve	277-03205	331-0240	LS	Pneu. Damper Actuator	331-2905
2552-603	INV	Pneu. Valve	277-03205	331-0520	LS	Pneu. Damper Actuator	331-4311
2552-604	INV	Pneu. Valve	283-03205	331-0540	LS	Pneu. Damper Actuator	331-4311
2552-606	INV	Pneu. Valve	277-03206	331-1000	LS	Pneu. Damper Actuator	331-2794
2552-607	INV	Pneu. Valve	277-03206	331-1040	LS	Pneu. Damper Actuator	331-2961
2552-608	INV	Pneu. Valve	277-03206	331-1050	LS	Pneu. Damper Actuator	331-2909
2552-609	INV	Pneu. Valve	283-03206	331-1080	LS	Pneu. Damper Actuator	331-2882
2552-610	INV	Pneu. Valve	283-03206	331-2490	LS	Pneu. Damper Actuator	331-2795
2552-621	INV	Pneu. Valve	283-06160	331-2570	LS	Pneu. Damper Actuator	331-4312

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
331-2580	LS	Pneu. Damper Actuator	331-2900	331-2706	LS	Pneu. Damper Actuator	331-4811
331-2604	LS	Pneu. Damper Actuator	331-2963	331-2707	LS	Pneu. Damper Actuator	331-3011
331-2605	LS	Pneu. Damper Actuator	331-2906	331-2716	LS	Pneu. Damper Actuator	331-2913
331-2609	LS	Pneu. Damper Actuator	331-2793	331-2726	LS	Pneu. Damper Actuator	331-2927
331-2628	LS	Pneu. Damper Actuator	331-2905	331-2728	LS	Pneu. Damper Actuator	331-2965
331-2629	LS	Pneu. Damper Actuator	331-2964	331-2729	LS	Pneu. Damper Actuator	331-2962
331-2630	LS	Pneu. Damper Actuator	331-3411	331-2731	LS	Pneu. Damper Actuator	331-2914
331-2631	LS	Pneu. Damper Actuator	331-2904	331-2740	LS	Pneu. Damper Actuator	331-2793
331-2632	LS	Pneu. Damper Actuator	331-2961	331-2741	LS	Pneu. Damper Actuator	331-3012
331-2633	LS	Pneu. Damper Actuator	331-2912	331-2742	LS	Pneu. Damper Actuator	331-2795
331-2634	LS	Pneu. Damper Actuator	331-2964	331-2743	LS	Pneu. Damper Actuator	331-3011
331-2637	LS	Pneu. Damper Actuator	331-2966	331-2747	LS	Pneu. Damper Actuator	331-4512
331-2640	LS	Pneu. Damper Actuator	331-2905	331-2749	LS	Pneu. Damper Actuator	331-2917
331-2642	LS	Pneu. Damper Actuator	331-4312	331-2754	LS	Pneu. Damper Actuator	331-2792
331-2643	LS	Pneu. Damper Actuator	331-2961	331-2756	LS	Pneu. Damper Actuator	331-2961
331-2647	LS	Pneu. Damper Actuator	331-2793	331-2758	LS	Pneu. Damper Actuator	331-4312
331-2648	LS	Pneu. Damper Actuator	331-2796	331-2762	LS	Pneu. Damper Actuator	331-2918
331-2650	LS	Pneu. Damper Actuator	331-2912	331-2767	LS	Pneu. Damper Actuator	331-4814
331-2651	LS	Pneu. Damper Actuator	331-2964	331-2774	LS	Pneu. Damper Actuator	331-2904
331-2652	LS	Pneu. Damper Actuator	331-2912	331-2775	LS	Pneu. Damper Actuator	331-3000
331-2653	LS	Pneu. Damper Actuator	331-4312	331-2776	LS	Pneu. Damper Actuator	331-2905
331-2657	LS	Pneu. Damper Actuator	331-2936	331-2777	LS	Pneu. Damper Actuator	331-3001
331-2662	LS	Pneu. Damper Actuator	331-4311	331-2778	LS	Pneu. Damper Actuator	331-2906
331-2668	LS	Pneu. Damper Actuator	331-4812	331-2779	LS	Pneu. Damper Actuator	331-3002
331-2669	LS	Pneu. Damper Actuator	331-4811	331-2780	LS	Pneu. Damper Actuator	331-2961
331-2672	LS	Pneu. Damper Actuator	331-2793	331-2781	LS	Pneu. Damper Actuator	331-2973
331-2674	LS	Pneu. Damper Actuator	331-4812	331-2782	LS	Pneu. Damper Actuator	331-2929
331-2681	LS	Pneu. Damper Actuator	331-3001	331-2783	LS	Pneu. Damper Actuator	331-2930
331-2682	LS	Pneu. Damper Actuator	331-2973	331-2784	LS	Pneu. Damper Actuator	331-2931
331-2683	LS	Pneu. Damper Actuator	331-3002	331-2785	LS	Pneu. Damper Actuator	331-2968
331-2684	LS	Pneu. Damper Actuator	331-3000	331-2786	LS	Pneu. Damper Actuator	331-4810
331-2685	LS	Pneu. Damper Actuator	331-3001	331-2788	LS	Pneu. Damper Actuator	331-4312
331-2686	LS	Pneu. Damper Actuator	331-3004	331-2789	LS	Pneu. Damper Actuator	331-4510
331-2687	LS	Pneu. Damper Actuator	331-3000	331-2790	LS	Pneu. Damper Actuator	331-2966
331-2688	LS	Pneu. Damper Actuator	331-2793	331-2797	LS	Pneu. Damper Actuator	331-3012
331-2689	LS	Pneu. Damper Actuator	331-3001	331-2798	LS	Pneu. Damper Actuator	331-3013
331-2691	LS	Pneu. Damper Actuator	331-2973	331-2799	LS	Pneu. Damper Actuator	331-3011
331-2692	LS	Pneu. Damper Actuator	331-3002	331-2801	LS	Pneu. Damper Actuator	331-2792
331-2693	LS	Pneu. Damper Actuator	331-3000	331-2802	LS	Pneu. Damper Actuator	331-2793
331-2694	LS	Pneu. Damper Actuator	331-3001	331-2812	LS	Pneu. Damper Actuator	331-4811
331-2695	LS	Pneu. Damper Actuator	331-3004	331-2814	LS	Pneu. Damper Actuator	331-3011
331-2696	LS	Pneu. Damper Actuator	331-3012	331-2823	LS	Pneu. Damper Actuator	331-2884
331-2697	LS	Pneu. Damper Actuator	331-3013	331-2827	LS	Pneu. Damper Actuator	331-4810
331-2699	LS	Pneu. Damper Actuator	331-3010	331-2830	LS	Pneu. Damper Actuator	331-4811
331-2703	LS	Pneu. Damper Actuator	331-4812	331-2833	LS	Pneu. Damper Actuator	331-3012

AC Accustat	INV Invensys (Robertshaw/ Barber Colman/Siebe/ Erie)	KR Kreuter	T Trane
AS American Stablis	JC Johnson Controls	LS Landis & Staefa/ Powers/Siemens	V Victronics
BL Belimo	JO Joventa	PJC Penn (JC)	WR White Rogers (Emerson Climate Tech)
DT Delta		ST Staefa	
HW Honeywell			

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
331-2834	LS	Pneu. Damper Actuator	331-2793	331-2938	LS	Pneu. Damper Actuator	331-2904
331-2845	LS	Pneu. Damper Actuator	331-4312	331-2939	LS	Pneu. Damper Actuator	331-2961
331-2846	LS	Pneu. Damper Actuator	331-4812	331-2941	LS	Pneu. Damper Actuator	331-2971
331-2847	LS	Pneu. Damper Actuator	331-2904	331-2942	LS	Pneu. Damper Actuator	331-2967
331-2848	LS	Pneu. Damper Actuator	331-2961	331-2945	LS	Pneu. Damper Actuator	331-2972
331-2849	LS	Pneu. Damper Actuator	331-2889	331-2947	LS	Pneu. Damper Actuator	331-4510
331-2850	LS	Pneu. Damper Actuator	331-2960	331-2948	LS	Pneu. Damper Actuator	331-3030
331-2851	LS	Pneu. Damper Actuator	331-2964	331-2953	LS	Pneu. Damper Actuator	331-3032
331-2853	LS	Pneu. Damper Actuator	331-2970	331-3003	LS	Pneu. Damper Actuator	331-2973
331-2854	LS	Pneu. Damper Actuator	331-2919	331-3020	LS	Pneu. Damper Actuator	331-4811
331-2855	LS	Pneu. Damper Actuator	331-4512	331-3021	LS	Pneu. Damper Actuator	331-4311
331-2860	LS	Pneu. Damper Actuator	331-4812	331-3022	LS	Pneu. Damper Actuator	331-4511
331-2861	LS	Pneu. Damper Actuator	331-4310	331-3033	LS	Pneu. Damper Actuator	331-4310
331-2863	LS	Pneu. Damper Actuator	331-4810	331-3034	LS	Pneu. Damper Actuator	331-4810
331-2866	LS	Pneu. Damper Actuator	331-4314	331-3035	LS	Pneu. Damper Actuator	331-4812
331-2870	LS	Pneu. Damper Actuator	331-2968	331-3036	LS	Pneu. Damper Actuator	331-4312
331-2872	LS	Pneu. Damper Actuator	331-4312	331-3037	LS	Pneu. Damper Actuator	331-4512
331-2873	LS	Pneu. Damper Actuator	331-4313	331-3038	LS	Pneu. Damper Actuator	331-4510
331-2874	LS	Pneu. Damper Actuator	331-4813	331-3041	LS	Pneu. Damper Actuator	331-4510
331-2875	LS	Pneu. Damper Actuator	331-4513	331-3042	LS	Pneu. Damper Actuator	331-4313
331-2878	LS	Pneu. Damper Actuator	331-4812	331-3043	LS	Pneu. Damper Actuator	331-4813
331-2879	LS	Pneu. Damper Actuator	331-4312	331-3044	LS	Pneu. Damper Actuator	331-4513
331-2880	LS	Pneu. Damper Actuator	331-4512	331-3045	LS	Pneu. Damper Actuator	331-4519
331-2881	LS	Pneu. Damper Actuator	331-4510	331-3046	LS	Pneu. Damper Actuator	331-4812
331-2891	LS	Pneu. Damper Actuator	331-4311	331-3047	LS	Pneu. Damper Actuator	331-4312
331-2892	LS	Pneu. Damper Actuator	331-4811	331-3048	LS	Pneu. Damper Actuator	331-4811
331-2893	LS	Pneu. Damper Actuator	331-4511	331-3049	LS	Pneu. Damper Actuator	331-4311
331-2894	LS	Pneu. Damper Actuator	331-4313	331-3050	LS	Pneu. Damper Actuator	331-4511
331-2895	LS	Pneu. Damper Actuator	331-4813	331-3051	LS	Pneu. Damper Actuator	331-4314
331-2896	LS	Pneu. Damper Actuator	331-4513	331-3052	LS	Pneu. Damper Actuator	331-4814
331-2899	LS	Pneu. Damper Actuator	331-4519	331-3053	LS	Pneu. Damper Actuator	331-4313
331-2903	LS	Pneu. Damper Actuator	331-2960	331-3054	LS	Pneu. Damper Actuator	331-4813
331-2907	LS	Pneu. Damper Actuator	331-2961	331-3055	LS	Pneu. Damper Actuator	331-4513
331-2908	LS	Pneu. Damper Actuator	331-2927	331-3690	LS	Pneu. Damper Actuator	331-3001
331-2915	LS	Pneu. Damper Actuator	331-3000	332-0220	LS	Pneu. Damper Actuator	332-2969
331-2916	LS	Pneu. Damper Actuator	331-3001	332-2744	LS	Pneu. Damper Actuator	331-2969
331-2920	LS	Pneu. Damper Actuator	331-3002	332-2780	LS	Pneu. Damper Actuator	331-2969
331-2921	LS	Pneu. Damper Actuator	331-2962	332-2781	LS	Pneu. Damper Actuator	332-2973
331-2922	LS	Pneu. Damper Actuator	331-2963	332-2785	LS	Pneu. Damper Actuator	332-2973
331-2923	LS	Pneu. Damper Actuator	331-2964	332-2799	LS	Pneu. Damper Actuator	332-3011
331-2924	LS	Pneu. Damper Actuator	331-2965	332-2926	LS	Pneu. Damper Actuator	332-2973
331-2925	LS	Pneu. Damper Actuator	331-2973	332-2933	LS	Pneu. Damper Actuator	332-2969
331-2928	LS	Pneu. Damper Actuator	331-3004	332-3003	LS	Pneu. Damper Actuator	332-2973
331-2932	LS	Pneu. Damper Actuator	331-2968	339-0122	LS	Elec. Valve	273-03200
331-2937	LS	Pneu. Damper Actuator	331-2966	339-0123	LS	Elec. Valve	273-03202

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Sieba/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
339-0124	LS	Elec. Valve	273-03203	591-606C	LS	Pneu. Valve	277-03114
339-0125	LS	Elec. Valve	273-03204	591-606C	LS	Pneu. Valve	278-03060
339-0126	LS	Elec. Valve	273-03162	591-6070	LS	Pneu. Valve	277-03115
339-0127	LS	Elec. Valve	273-03164	591-6070	LS	Pneu. Valve	278-03061
339-0128	LS	Elec. Valve	273-03166	591-607C	LS	Pneu. Valve	277-03115
339-0129	LS	Elec. Valve	273-03167	591-607C	LS	Pneu. Valve	278-03061
339-0130	LS	Elec. Valve	273-03168	591-6080	LS	Pneu. Valve	277-03116
339-0131	LS	Elec. Valve	273-03270	591-608C	LS	Pneu. Valve	277-03116
339-0132	LS	Elec. Valve	273-03272	591-6120	LS	Pneu. Valve	277-03110
339-0133	LS	Elec. Valve	273-03274	591-6120	LS	Pneu. Valve	278-03056
339-0134	LS	Elec. Valve	273-03275	591-612C	LS	Pneu. Valve	277-03110
339-0135	LS	Elec. Valve	273-03177	591-612C	LS	Pneu. Valve	278-03056
591-1620	LS	Pneu. Valve	281-05963	591-6130	LS	Pneu. Valve	277-03112
591-162B	LS	Pneu. Valve	281-05963	591-6130	LS	Pneu. Valve	278-03058
591-1640	LS	Pneu. Valve	281-05964	591-613C	LS	Pneu. Valve	277-03112
591-164B	LS	Pneu. Valve	281-05964	591-613C	LS	Pneu. Valve	278-03058
591-1760	LS	Pneu. Valve	279-05990	591-6140	LS	Pneu. Valve	277-03113
591-176B	LS	Pneu. Valve	279-05990	591-6140	LS	Pneu. Valve	278-03059
591-1780	LS	Pneu. Valve	279-05991	591-614C	LS	Pneu. Valve	277-03113
591-178B	LS	Pneu. Valve	279-05991	591-614C	LS	Pneu. Valve	278-03059
591-1800	LS	Pneu. Valve	281-05992	591-6150	LS	Pneu. Valve	277-03114
591-180B	LS	Pneu. Valve	281-05992	591-6150	LS	Pneu. Valve	278-03060
591-1820	LS	Pneu. Valve	287-05973	591-615C	LS	Pneu. Valve	277-03114
591-182B	LS	Pneu. Valve	287-05973	591-615C	LS	Pneu. Valve	278-03060
591-1840	LS	Pneu. Valve	287-05974	591-6160	LS	Pneu. Valve	277-03115
591-184B	LS	Pneu. Valve	287-05974	591-6160	LS	Pneu. Valve	278-03061
591-4260	LS	Pneu. Valve	279-06160	591-616C	LS	Pneu. Valve	277-03115
591-426A	LS	Pneu. Valve	279-06160	591-616C	LS	Pneu. Valve	278-03061
591-4280	LS	Pneu. Valve	277-06161	591-6170	LS	Pneu. Valve	277-03116
591-428B	LS	Pneu. Valve	277-06161	591-6170	LS	Pneu. Valve	278-03062
591-4300	LS	Pneu. Valve	283-06161	591-617C	LS	Pneu. Valve	277-03116
591-430B	LS	Pneu. Valve	283-06161	591-617C	LS	Pneu. Valve	278-03062
591-6030	LS	Pneu. Valve	277-03110	591-6210	LS	Pneu. Valve	277-03128
591-6030	LS	Pneu. Valve	278-03056	591-6210	LS	Pneu. Valve	278-03074
591-603C	LS	Pneu. Valve	277-03110	591-621C	LS	Pneu. Valve	277-03128
591-603C	LS	Pneu. Valve	278-03056	591-621C	LS	Pneu. Valve	278-03074
591-6040	LS	Pneu. Valve	277-03112	591-6220	LS	Pneu. Valve	277-03130
591-6040	LS	Pneu. Valve	278-03058	591-6220	LS	Pneu. Valve	277-03187
591-604C	LS	Pneu. Valve	277-03112	591-622C	LS	Pneu. Valve	277-03130
591-6050	LS	Pneu. Valve	277-03113	591-622C	LS	Pneu. Valve	277-03187
591-6050	LS	Pneu. Valve	278-03059	591-6230	LS	Pneu. Valve	277-03131
591-605C	LS	Pneu. Valve	277-03113	591-6230	LS	Pneu. Valve	278-03077
591-605C	LS	Pneu. Valve	278-03059	591-623C	LS	Pneu. Valve	277-03131
591-6060	LS	Pneu. Valve	277-03114	591-623C	LS	Pneu. Valve	278-03077
591-6060	LS	Pneu. Valve	278-03060	591-6240	LS	Pneu. Valve	277-03132

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
591-6240	LS	Pneu. Valve	278-03078	591-6560	LS	Pneu. Valve	281-05992
591-624C	LS	Pneu. Valve	277-03132	591-656C	LS	Pneu. Valve	281-05992
591-624C	LS	Pneu. Valve	278-03078	591-6600	LS	Pneu. Valve	277-03200
591-6250	LS	Pneu. Valve	277-03132	591-660E	LS	Pneu. Valve	277-03200
591-6250	LS	Pneu. Valve	278-03079	591-6610	LS	Pneu. Valve	277-03202
591-625C	LS	Pneu. Valve	277-03132	591-661E	LS	Pneu. Valve	277-03202
591-625C	LS	Pneu. Valve	278-03079	591-6620	LS	Pneu. Valve	277-03203
591-6300	LS	Pneu. Valve	277-03128	591-662D	LS	Pneu. Valve	277-03203
591-6300	LS	Pneu. Valve	278-03074	591-6630	LS	Pneu. Valve	277-03204
591-630C	LS	Pneu. Valve	277-03128	591-663D	LS	Pneu. Valve	277-03204
591-630C	LS	Pneu. Valve	278-03074	591-6640	LS	Pneu. Valve	277-03205
591-6310	LS	Pneu. Valve	277-03130	591-664D	LS	Pneu. Valve	277-03205
591-6310	LS	Pneu. Valve	277-03187	591-6650	LS	Pneu. Valve	277-03206
591-631C	LS	Pneu. Valve	277-03130	591-665D	LS	Pneu. Valve	277-03206
591-631C	LS	Pneu. Valve	277-03187	591-6660	LS	Pneu. Valve	277-03200
591-6320	LS	Pneu. Valve	277-03131	591-666E	LS	Pneu. Valve	277-03200
591-6320	LS	Pneu. Valve	278-03077	591-6670	LS	Pneu. Valve	277-03202
591-632C	LS	Pneu. Valve	277-03131	591-667E	LS	Pneu. Valve	277-03202
591-632C	LS	Pneu. Valve	278-03077	591-6680	LS	Pneu. Valve	277-03203
591-6330	LS	Pneu. Valve	277-03132	591-668D	LS	Pneu. Valve	277-03203
591-6330	LS	Pneu. Valve	278-03078	591-6690	LS	Pneu. Valve	277-03204
591-633C	LS	Pneu. Valve	277-03132	591-669D	LS	Pneu. Valve	277-03204
591-633C	LS	Pneu. Valve	278-03078	591-6700	LS	Pneu. Valve	277-03205
591-6340	LS	Pneu. Valve	277-03133	591-670D	LS	Pneu. Valve	277-03205
591-6340	LS	Pneu. Valve	278-03079	591-6710	LS	Pneu. Valve	277-03206
591-634C	LS	Pneu. Valve	277-03133	591-671D	LS	Pneu. Valve	277-03206
591-634C	LS	Pneu. Valve	278-03079	591-6720	LS	Pneu. Valve	277-06160
591-6350	LS	Pneu. Valve	277-03134	591-672B	LS	Pneu. Valve	277-06160
591-6350	LS	Pneu. Valve	278-03080	591-6730	LS	Pneu. Valve	277-06161
591-635C	LS	Pneu. Valve	277-03134	591-673B	LS	Pneu. Valve	283-06160
591-635C	LS	Pneu. Valve	278-03080	591-6740	LS	Pneu. Valve	281-06162
591-6430	LS	Pneu. Valve	277-03184	591-674B	LS	Pneu. Valve	285-06161
591-643C	LS	Pneu. Valve	277-03184	591-6750	LS	Pneu. Valve	277-06160
591-6440	LS	Pneu. Valve	277-03185	591-675B	LS	Pneu. Valve	277-06160
591-644D	LS	Pneu. Valve	277-03185	591-6760	LS	Pneu. Valve	277-06161
591-6450	LS	Pneu. Valve	277-03186	591-676B	LS	Pneu. Valve	277-06161
591-645C	LS	Pneu. Valve	277-03186	591-6770	LS	Pneu. Valve	281-06162
591-6460	LS	Pneu. Valve	277-03187	591-677B	LS	Pneu. Valve	277-03205
591-646C	LS	Pneu. Valve	277-03187	591-7250	LS	Pneu. Valve	287-06162
591-6470	LS	Pneu. Valve	277-03188	591-7260	LS	Pneu. Valve	281-06163
591-647C	LS	Pneu. Valve	277-03188	591-7260	LS	Pneu. Valve	281-06164
591-6540	LS	Pneu. Valve	277-05990	591-7850	LS	Pneu. Valve	277-03166
591-654C	LS	Pneu. Valve	277-05990	591-7851	LS	Pneu. Valve	277-03166
591-6550	LS	Pneu. Valve	277-05991	591-7852	LS	Pneu. Valve	277-03167
591-655C	LS	Pneu. Valve	277-05991	591-7853	LS	Pneu. Valve	277-03167

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
591-7854	LS	Pneu. Valve	277-03168	591-8023	LS	Pneu. Valve	287-05973
591-7855	LS	Pneu. Valve	277-03168	591-8024	LS	Pneu. Valve	281-05964
591-7856	LS	Pneu. Valve	277-03169	591-8025	LS	Pneu. Valve	287-05974
591-7857	LS	Pneu. Valve	277-03169	591-8028	LS	Pneu. Valve	279-06160
591-7858	LS	Pneu. Valve	277-03170	591-8029	LS	Pneu. Valve	279-06161
591-7859	LS	Pneu. Valve	277-03170	591-8030	LS	Pneu. Valve	281-06162
591-7860	LS	Pneu. Valve	277-03184	591-8071	LS	Pneu. Valve	277-03110
591-7861	LS	Pneu. Valve	277-03184	591-8072	LS	Pneu. Valve	277-03112
591-7862	LS	Pneu. Valve	277-03185	591-8073	LS	Pneu. Valve	277-03113
591-7863	LS	Pneu. Valve	277-03185	591-8074	LS	Pneu. Valve	277-03114
591-7864	LS	Pneu. Valve	277-03186	591-8075	LS	Pneu. Valve	277-03115
591-7865	LS	Pneu. Valve	277-03186	591-8076	LS	Pneu. Valve	277-03116
591-7866	LS	Pneu. Valve	277-03187	591-8077	LS	Pneu. Valve	277-03128
591-7867	LS	Pneu. Valve	277-03187	591-8078	LS	Pneu. Valve	277-03130
591-7870	LS	Pneu. Valve	277-03166	591-8079	LS	Pneu. Valve	277-03131
591-7871	LS	Pneu. Valve	277-03167	591-8080	LS	Pneu. Valve	277-03132
591-7872	LS	Pneu. Valve	277-03168	591-8081	LS	Pneu. Valve	277-03133
591-7873	LS	Pneu. Valve	277-03169	591-8082	LS	Pneu. Valve	277-03134
591-7874	LS	Pneu. Valve	277-03170	591-8330	LS	Pneu. Valve	277-05980
591-7875	LS	Pneu. Valve	277-03184	591-8331	LS	Pneu. Valve	277-05990
591-7876	LS	Pneu. Valve	277-03185	591-8332	LS	Pneu. Valve	277-05981
591-7877	LS	Pneu. Valve	277-03186	591-8336	LS	Pneu. Valve	279-05980
591-7878	LS	Pneu. Valve	277-03187	591-8337	LS	Pneu. Valve	279-05990
591-7879	LS	Pneu. Valve	277-03188	591-8338	LS	Pneu. Valve	279-05981
591-7891	LS	Pneu. Valve	281-05963	591-8339	LS	Pneu. Valve	279-05991
591-7892	LS	Pneu. Valve	281-05964	591-8340	LS	Pneu. Valve	281-05982
591-7893	LS	Pneu. Valve	287-05973	591-8341	LS	Pneu. Valve	281-05992
591-7894	LS	Pneu. Valve	287-05974	592-6600	LS	Pneu. Valve	283-03200
591-7971	LS	Pneu. Valve	278-03056	592-6610	LS	Pneu. Valve	283-03202
591-7972	LS	Pneu. Valve	278-03058	592-6620	LS	Pneu. Valve	283-03203
591-7973	LS	Pneu. Valve	278-03059	592-6630	LS	Pneu. Valve	283-03204
591-7974	LS	Pneu. Valve	278-03060	592-6640	LS	Pneu. Valve	283-03205
591-7975	LS	Pneu. Valve	278-03061	592-6720	LS	Pneu. Valve	283-06160
591-7976	LS	Pneu. Valve	278-03062	592-6730	LS	Pneu. Valve	283-06161
591-7977	LS	Pneu. Valve	278-03074	592-7870	LS	Pneu. Valve	283-03166
591-7978	LS	Pneu. Valve	278-03076	592-7871	LS	Pneu. Valve	283-03167
591-7979	LS	Pneu. Valve	278-03077	592-7872	LS	Pneu. Valve	283-03168
591-7980	LS	Pneu. Valve	278-03078	592-7873	LS	Pneu. Valve	283-03169
591-7981	LS	Pneu. Valve	278-03079	592-7874	LS	Pneu. Valve	283-03170
591-7982	LS	Pneu. Valve	278-03080	592-7875	LS	Pneu. Valve	283-03184
591-8017	LS	Pneu. Valve	279-05990	592-7876	LS	Pneu. Valve	283-03185
591-8019	LS	Pneu. Valve	279-05991	592-7877	LS	Pneu. Valve	283-03186
591-8020	LS	Pneu. Valve	281-05982	592-7878	LS	Pneu. Valve	283-03187
591-8021	LS	Pneu. Valve	281-05992	592-7879	LS	Pneu. Valve	283-03188
591-8022	LS	Pneu. Valve	281-05963	592-7971	LS	Pneu. Valve	284-03056

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
592-7972	LS	Pneu. Valve	284-03058	594-8412	LS	Pneu. Valve	287-06163
592-7973	LS	Pneu. Valve	284-03059	594-8413	LS	Pneu. Valve	287-06164
592-7975	LS	Pneu. Valve	284-03061	598-0001	LS	Elec. Valve	295-05980
592-7976	LS	Pneu. Valve	284-03062	598-0002	LS	Elec. Valve	296-05980
592-7977	LS	Pneu. Valve	284-03074	598-0003	LS	Elec. Valve	296-05980
592-7978	LS	Pneu. Valve	284-03076	598-0004	LS	Elec. Valve	295-05981
592-7980	LS	Pneu. Valve	284-03078	598-0005	LS	Elec. Valve	296-05981
592-7981	LS	Pneu. Valve	284-03079	598-0006	LS	Elec. Valve	296-05981
592-7982	LS	Pneu. Valve	284-03080	598-0007	LS	Elec. Valve	297-05982
592-8020	LS	Pneu. Valve	287-05982	598-0008	LS	Elec. Valve	297-05982
592-8028	LS	Pneu. Valve	285-06160	598-0009	LS	Elec. Valve	297-05982
592-8029	LS	Pneu. Valve	285-06161	598-0010	LS	Elec. Valve	271-03166
592-8030	LS	Pneu. Valve	287-06162	598-0011	LS	Elec. Valve	274-03166
592-8071	LS	Pneu. Valve	283-03110	598-0012	LS	Elec. Valve	276-03184
592-8072	LS	Pneu. Valve	283-03112	598-0013	LS	Elec. Valve	271-03167
592-8073	LS	Pneu. Valve	283-03113	598-0014	LS	Elec. Valve	274-03167
592-8074	LS	Pneu. Valve	283-03114	598-0015	LS	Elec. Valve	276-03185
592-8075	LS	Pneu. Valve	283-03115	598-0016	LS	Elec. Valve	271-03168
592-8076	LS	Pneu. Valve	283-03116	598-0017	LS	Elec. Valve	274-03168
592-8077	LS	Pneu. Valve	283-03128	598-0018	LS	Elec. Valve	276-03186
592-8078	LS	Pneu. Valve	283-03130	598-0019	LS	Elec. Valve	271-03169
592-8079	LS	Pneu. Valve	283-03131	598-0020	LS	Elec. Valve	274-03169
592-8080	LS	Pneu. Valve	283-03132	598-0021	LS	Elec. Valve	276-03187
592-8082	LS	Pneu. Valve	283-03134	598-0022	LS	Elec. Valve	271-03170
592-8330	LS	Pneu. Valve	283-05980	598-0023	LS	Elec. Valve	274-03170
592-8331	LS	Pneu. Valve	283-05990	598-0024	LS	Elec. Valve	276-03188
592-8332	LS	Pneu. Valve	283-05981	598-0025	LS	Elec. Valve	271-03002
592-8336	LS	Pneu. Valve	285-05980	598-0026	LS	Elec. Valve	274-03002
592-8337	LS	Pneu. Valve	285-05990	598-0027	LS	Elec. Valve	274-03074
592-8338	LS	Pneu. Valve	285-05981	598-0028	LS	Elec. Valve	271-03004
592-8339	LS	Pneu. Valve	285-05991	598-0029	LS	Elec. Valve	274-03004
592-8340	LS	Pneu. Valve	287-05982	598-0030	LS	Elec. Valve	274-03076
592-8341	LS	Pneu. Valve	287-05992	598-0031	LS	Elec. Valve	271-03005
593-8342	LS	Pneu. Valve	281-05983	598-0032	LS	Elec. Valve	274-03005
593-8344	LS	Pneu. Valve	281-05984	598-0033	LS	Elec. Valve	274-03077
593-8360	LS	Pneu. Valve	281-05963	598-0034	LS	Elec. Valve	271-03006
593-8362	LS	Pneu. Valve	281-05964	598-0035	LS	Elec. Valve	274-03006
593-8412	LS	Pneu. Valve	281-06163	598-0036	LS	Elec. Valve	274-03078
593-8413	LS	Pneu. Valve	281-06164	598-0037	LS	Elec. Valve	271-03007
594-8342	LS	Pneu. Valve	287-05983	598-0038	LS	Elec. Valve	274-03007
594-8343	LS	Pneu. Valve	287-05993	598-0039	LS	Elec. Valve	274-03079
594-8344	LS	Pneu. Valve	287-05984	598-0040	LS	Elec. Valve	271-03008
594-8345	LS	Pneu. Valve	287-05994	598-0041	LS	Elec. Valve	274-03008
594-8361	LS	Pneu. Valve	287-05973	598-0042	LS	Elec. Valve	274-03080
594-8363	LS	Pneu. Valve	287-05974	598-0043	LS	Elec. Valve	271-03146

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
598-0044	LS	Elec. Valve	274-03146	598-2031	LS	Elec. Valve	296-05981
598-0045	LS	Elec. Valve	271-03148	598-2032	LS	Elec. Valve	296-05981
598-0046	LS	Elec. Valve	274-03148	598-2033	LS	Elec. Valve	297-05982
598-0047	LS	Elec. Valve	271-03149	598-2034	LS	Elec. Valve	297-05982
598-0048	LS	Elec. Valve	274-03149	598-2035	LS	Elec. Valve	297-05982
598-0049	LS	Elec. Valve	271-03150	598-2036	LS	Elec. Valve	271-03056
598-0050	LS	Elec. Valve	274-03150	598-2037	LS	Elec. Valve	274-03056
598-0051	LS	Elec. Valve	271-03151	598-2038	LS	Elec. Valve	274-03074
598-0052	LS	Elec. Valve	274-03151	598-2039	LS	Elec. Valve	271-03058
598-0053	LS	Elec. Valve	271-03152	598-2040	LS	Elec. Valve	274-03058
598-0054	LS	Elec. Valve	274-03152	598-2041	LS	Elec. Valve	274-03076
598-0055	LS	Elec. Valve	295-06160	598-2042	LS	Elec. Valve	271-03059
598-0056	LS	Elec. Valve	296-06160	598-2043	LS	Elec. Valve	274-03059
598-0057	LS	Elec. Valve	295-06161	598-2044	LS	Elec. Valve	274-03077
598-0058	LS	Elec. Valve	296-06161	598-2045	LS	Elec. Valve	271-03060
598-0059	LS	Elec. Valve	297-06162	598-2046	LS	Elec. Valve	274-03060
598-0060	LS	Elec. Valve	297-06162	598-2047	LS	Elec. Valve	274-03078
598-2003	LS	Elec. Valve	271-03166	598-2048	LS	Elec. Valve	271-03061
598-2004	LS	Elec. Valve	274-03166	598-2049	LS	Elec. Valve	274-03061
598-2005	LS	Elec. Valve	274-03184	598-2050	LS	Elec. Valve	274-03079
598-2006	LS	Elec. Valve	271-03167	598-2051	LS	Elec. Valve	271-03062
598-2007	LS	Elec. Valve	274-03167	598-2052	LS	Elec. Valve	274-03062
598-2008	LS	Elec. Valve	274-03185	598-2053	LS	Elec. Valve	274-03080
598-2009	LS	Elec. Valve	271-03168	598-2054	LS	Elec. Valve	295-05920
598-2010	LS	Elec. Valve	274-03168	598-2055	LS	Elec. Valve	296-05920
598-2011	LS	Elec. Valve	274-03186	598-2056	LS	Elec. Valve	296-05920
598-2012	LS	Elec. Valve	271-03169	598-2057	LS	Elec. Valve	295-05921
598-2013	LS	Elec. Valve	274-03169	598-2058	LS	Elec. Valve	296-05921
598-2014	LS	Elec. Valve	274-03187	598-2059	LS	Elec. Valve	296-05921
598-2015	LS	Elec. Valve	271-03170	598-2060	LS	Elec. Valve	297-05922
598-2016	LS	Elec. Valve	274-03170	598-2061	LS	Elec. Valve	297-05922
598-2017	LS	Elec. Valve	274-03188	598-2062	LS	Elec. Valve	297-05922
598-2018	LS	Elec. Valve	295-05980	598-2063	LS	Elec. Valve	271-03110
598-2019	LS	Elec. Valve	296-05980	598-2064	LS	Elec. Valve	274-03110
598-2020	LS	Elec. Valve	296-05980	598-2065	LS	Elec. Valve	271-03128
598-2021	LS	Elec. Valve	295-05981	598-2066	LS	Elec. Valve	271-03112
598-2022	LS	Elec. Valve	296-05981	598-2067	LS	Elec. Valve	274-03112
598-2023	LS	Elec. Valve	296-05981	598-2068	LS	Elec. Valve	271-03130
598-2024	LS	Elec. Valve	297-05982	598-2069	LS	Elec. Valve	271-03113
598-2025	LS	Elec. Valve	297-05982	598-2070	LS	Elec. Valve	274-03113
598-2026	LS	Elec. Valve	297-05982	598-2071	LS	Elec. Valve	271-03131
598-2027	LS	Elec. Valve	295-05980	598-2072	LS	Elec. Valve	271-03114
598-2028	LS	Elec. Valve	296-05980	598-2073	LS	Elec. Valve	274-03114
598-2029	LS	Elec. Valve	296-05980	598-2074	LS	Elec. Valve	271-03132
598-2030	LS	Elec. Valve	295-05981	598-2075	LS	Elec. Valve	271-03115

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
598-2076	LS	Elec. Valve	274-03115	598-2175	LS	Elec. Valve	274-03204
598-2077	LS	Elec. Valve	271-03133	598-2176	LS	Elec. Valve	271-03205
598-2078	LS	Elec. Valve	271-03116	598-2177	LS	Elec. Valve	274-03205
598-2079	LS	Elec. Valve	274-03116	598-2178	LS	Elec. Valve	271-03206
598-2080	LS	Elec. Valve	271-03134	598-2179	LS	Elec. Valve	274-03206
598-2081	LS	Elec. Valve	295-05960	598-2180	LS	Elec. Valve	295-06175
598-2082	LS	Elec. Valve	296-05960	598-2181	LS	Elec. Valve	296-06175
598-2083	LS	Elec. Valve	296-05960	598-2182	LS	Elec. Valve	295-06176
598-2084	LS	Elec. Valve	295-05961	598-2183	LS	Elec. Valve	296-06176
598-2085	LS	Elec. Valve	296-05961	598-2184	LS	Elec. Valve	297-06177
598-2086	LS	Elec. Valve	296-05961	598-2185	LS	Elec. Valve	297-06177
598-2087	LS	Elec. Valve	297-05962	598-2186	LS	Elec. Valve	295-06160
598-2088	LS	Elec. Valve	297-05962	598-2187	LS	Elec. Valve	296-06160
598-2089	LS	Elec. Valve	297-05962	598-2188	LS	Elec. Valve	295-06161
598-2090	LS	Elec. Valve	271-03167	598-2189	LS	Elec. Valve	296-06161
598-2091	LS	Elec. Valve	274-03167	598-2190	LS	Elec. Valve	297-06162
598-2092	LS	Elec. Valve	274-03185	598-2191	LS	Elec. Valve	297-06162
598-2093	LS	Elec. Valve	271-03168	598-5001	LS	Elec. Valve	295-05980
598-2094	LS	Elec. Valve	274-03168	598-5002	LS	Elec. Valve	296-05980
598-2095	LS	Elec. Valve	274-03186	598-5003	LS	Elec. Valve	296-05980
598-2096	LS	Elec. Valve	271-03169	598-5004	LS	Elec. Valve	295-05981
598-2097	LS	Elec. Valve	274-03169	598-5005	LS	Elec. Valve	296-05981
598-2098	LS	Elec. Valve	274-03187	598-5006	LS	Elec. Valve	296-05981
598-2099	LS	Elec. Valve	271-03170	598-5007	LS	Elec. Valve	297-05982
598-2100	LS	Elec. Valve	274-03170	598-5008	LS	Elec. Valve	297-05982
598-2101	LS	Elec. Valve	274-03188	598-5009	LS	Elec. Valve	297-05982
598-2102	LS	Elec. Valve	271-03113	598-5010	LS	Elec. Valve	271-03166
598-2103	LS	Elec. Valve	274-03113	598-5011	LS	Elec. Valve	274-03166
598-2104	LS	Elec. Valve	271-03131	598-5012	LS	Elec. Valve	276-03184
598-2105	LS	Elec. Valve	271-03114	598-5013	LS	Elec. Valve	271-03167
598-2106	LS	Elec. Valve	274-03114	598-5014	LS	Elec. Valve	274-03167
598-2107	LS	Elec. Valve	271-03132	598-5015	LS	Elec. Valve	276-03185
598-2108	LS	Elec. Valve	271-03115	598-5016	LS	Elec. Valve	271-03168
598-2109	LS	Elec. Valve	274-03115	598-5017	LS	Elec. Valve	274-03168
598-2110	LS	Elec. Valve	271-03133	598-5018	LS	Elec. Valve	276-03186
598-2111	LS	Elec. Valve	271-03116	598-5019	LS	Elec. Valve	271-03169
598-2112	LS	Elec. Valve	274-03116	598-5020	LS	Elec. Valve	274-03169
598-2113	LS	Elec. Valve	271-03134	598-5021	LS	Elec. Valve	276-03187
598-2168	LS	Elec. Valve	271-03200	598-5022	LS	Elec. Valve	271-03170
598-2169	LS	Elec. Valve	274-03200	598-5023	LS	Elec. Valve	274-03170
598-2170	LS	Elec. Valve	271-03202	598-5024	LS	Elec. Valve	276-03188
598-2171	LS	Elec. Valve	274-03202	598-5025	LS	Elec. Valve	271-03002
598-2172	LS	Elec. Valve	271-03203	598-5026	LS	Elec. Valve	274-03002
598-2173	LS	Elec. Valve	274-03203	598-5027	LS	Elec. Valve	274-03074
598-2174	LS	Elec. Valve	271-03204	598-5028	LS	Elec. Valve	271-03004

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
598-5029	LS	Elec. Valve	274-03004	657-527	LS	Pneu. Valve	268-03164
598-5030	LS	Elec. Valve	274-03076	657-641	LS	Pneu. Valve	268-03272
598-5031	LS	Elec. Valve	271-03005	657-642	LS	Pneu. Valve	268-03274
598-5032	LS	Elec. Valve	274-03005	657-643	LS	Pneu. Valve	268-03275
598-5033	LS	Elec. Valve	274-03077	657-645	LS	Pneu. Valve	268-03272
598-5034	LS	Elec. Valve	271-03006	657-646	LS	Pneu. Valve	268-03274
598-5035	LS	Elec. Valve	274-03006	657-647	LS	Pneu. Valve	268-03275
598-5036	LS	Elec. Valve	274-03078	657-653	LS	Pneu. Valve	658-0008
598-5037	LS	Elec. Valve	271-03007	657-655	LS	Pneu. Valve	658-0012
598-5038	LS	Elec. Valve	274-03007	657-656A	LS	Pneu. Valve	268-03203
598-5039	LS	Elec. Valve	274-03079	657-656A	LS	Pneu. Valve	270-03203
598-5040	LS	Elec. Valve	271-03008	657-657A	LS	Pneu. Valve	268-03200
598-5041	LS	Elec. Valve	274-03008	657-657A	LS	Pneu. Valve	270-03200
598-5042	LS	Elec. Valve	274-03080	657-658A	LS	Pneu. Valve	268-03202
598-5043	LS	Elec. Valve	271-03146	657-658A	LS	Pneu. Valve	270-03202
598-5044	LS	Elec. Valve	274-03146	657-659	LS	Pneu. Valve	658-0008
598-5045	LS	Elec. Valve	271-03148	657-661	LS	Pneu. Valve	658-0012
598-5046	LS	Elec. Valve	274-03148	657-674	LS	Pneu. Valve	268-03275
598-5047	LS	Elec. Valve	271-03149	657-711	LS	Pneu. Valve	268-03274
598-5048	LS	Elec. Valve	274-03149	657-730A	LS	Pneu. Valve	268-03204
598-5049	LS	Elec. Valve	271-03150	657-730A	LS	Pneu. Valve	270-03204
598-5050	LS	Elec. Valve	274-03150	657-758	LS	Pneu. Valve	268-03162
598-5051	LS	Elec. Valve	271-03151	657-7580	LS	Pneu. Valve	268-03162
598-5052	LS	Elec. Valve	274-03151	657-759	LS	Pneu. Valve	268-03164
598-5053	LS	Elec. Valve	271-03152	657-7590	LS	Pneu. Valve	268-03164
598-5054	LS	Elec. Valve	274-03152	657-760	LS	Pneu. Valve	268-03162
598-5055	LS	Elec. Valve	295-06160	657-7600	LS	Pneu. Valve	268-03162
598-5056	LS	Elec. Valve	296-06160	657-761	LS	Pneu. Valve	268-03164
598-5057	LS	Elec. Valve	295-06161	657-7610	LS	Pneu. Valve	268-03164
598-5058	LS	Elec. Valve	296-06161	657-762	LS	Pneu. Valve	268-03272
598-5059	LS	Elec. Valve	297-06162	657-762	LS	Pneu. Valve	268-03272
598-5060	LS	Elec. Valve	297-06162	657-7620	LS	Pneu. Valve	268-03272
656-0001	LS	Pneu. Valve	257-02039	657-7620	LS	Pneu. Valve	268-03272
656-0003	LS	Pneu. Valve	257-02035	657-763	LS	Pneu. Valve	268-03274
656-0005	LS	Pneu. Valve	257-02045	657-763	LS	Pneu. Valve	268-03274
656-0013	LS	Pneu. Valve	256-02008	657-7630	LS	Pneu. Valve	268-03274
656-0014	LS	Pneu. Valve	257-02069B	657-7630	LS	Pneu. Valve	268-03274
656-0019	LS	Pneu. Valve	257-02040	657-764	LS	Pneu. Valve	268-03275
656-0020	LS	Pneu. Valve	257-02039	657-7640	LS	Pneu. Valve	268-03275
656-0028	LS	Pneu. Valve	257-02033	657-7640	LS	Pneu. Valve	268-03275
656-0029	LS	Pneu. Valve	257-02033	657-765	LS	Pneu. Valve	658-0008
657-414	LS	Pneu. Valve	658-0014	657-7650	LS	Pneu. Valve	658-0008
657-524	LS	Pneu. Valve	268-03162	657-767	LS	Pneu. Valve	658-0012
657-525	LS	Pneu. Valve	268-03164	657-7670	LS	Pneu. Valve	658-0012
657-526	LS	Pneu. Valve	268-03162				

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa

KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.	Original Part No.	Mfg.	Description	Part No.
657-768	LS	Pneu. Valve	268-03200	657-8225	LS	Pneu. Valve	268-03202
657-768	LS	Pneu. Valve	270-03200	657-8225	LS	Pneu. Valve	270-03202
657-7680	LS	Pneu. Valve	268-03200	657-8226	LS	Pneu. Valve	268-03203
657-7680	LS	Pneu. Valve	270-03200	657-8226	LS	Pneu. Valve	270-03203
657-769	LS	Pneu. Valve	268-03202	657-8227	LS	Pneu. Valve	658-0051
657-769	LS	Pneu. Valve	270-03202	657-8228	LS	Pneu. Valve	658-0050
657-7690	LS	Pneu. Valve	268-03202	658-0001	LS	Pneu. Valve	257-02054
657-7690	LS	Pneu. Valve	270-03202	658-0002	LS	Pneu. Valve	257-02038
657-770	LS	Pneu. Valve	268-03203	658-0009	LS	Pneu. Valve	268-03166
657-770	LS	Pneu. Valve	270-03203	658-0011	LS	Pneu. Valve	268-03167
657-7700	LS	Pneu. Valve	268-03203	658-0013	LS	Pneu. Valve	268-03168
657-7700	LS	Pneu. Valve	270-03203	658-0018	LS	Pneu. Valve	257-02035
657-771	LS	Pneu. Valve	268-03204	658-0019	LS	Pneu. Valve	257-02039
657-771	LS	Pneu. Valve	270-03204	658-0020	LS	Pneu. Valve	268-03274
657-7710	LS	Pneu. Valve	268-03204	658-0021	LS	Pneu. Valve	268-03275
657-7710	LS	Pneu. Valve	270-03204	658-0022	LS	Pneu. Valve	268-03177
657-772	LS	Pneu. Valve	268-03274	658-0026	LS	Pneu. Valve	268-03200
657-7720	LS	Pneu. Valve	268-03274	658-0027	LS	Pneu. Valve	268-03200
657-774	LS	Pneu. Valve	658-0014	658-0028	LS	Pneu. Valve	268-02070
657-7740	LS	Pneu. Valve	658-0014	658-0029	LS	Pneu. Valve	270-02070
657-7900	LS	Pneu. Valve	270-03182	658-0030	LS	Pneu. Valve	258-02071
657-7910	LS	Pneu. Valve	270-03184	658-0031	LS	Pneu. Valve	270-03203
657-7920	LS	Pneu. Valve	270-03185	658-0032	LS	Pneu. Valve	270-03204
657-8006	LS	Pneu. Valve	268-03270	658-0033	LS	Pneu. Valve	268-03204
657-8006	LS	Pneu. Valve	268-03270	658-0041	LS	Pneu. Valve	257-02044
657-8046	LS	Pneu. Valve	658-0050	658-0042	LS	Pneu. Valve	257-02046
657-8047	LS	Pneu. Valve	658-0007	658-0061	LS	Pneu. Valve	257-02038
657-8055	LS	Pneu. Valve	658-0051	658-0086	LS	Pneu. Valve	270-03180
657-8098	LS	Pneu. Valve	658-0052	658-0100	LS	Pneu. Valve	268-03162
657-8203	LS	Pneu. Valve	268-03162	658-0101	LS	Pneu. Valve	268-03270
657-8204	LS	Pneu. Valve	268-03162	804190E	HW	Pressure Gauge	142-0305
657-8205	LS	Pneu. Valve	268-03162	804191B	HW	Pressure Gauge	142-0277
657-8206	LS	Pneu. Valve	268-03164	804191E	HW	Pressure Gauge	142-0304
657-8213	LS	Pneu. Valve	270-03182	832-0450	LS	Pneu. Room Thermostat	192-202
657-8214	LS	Pneu. Valve	270-03184	832-0460	LS	Pneu. Room Thermostat	192-202
657-8215	LS	Pneu. Valve	270-03185	832-0490	LS	Pneu. Room Thermostat	192-202
657-8216	LS	Pneu. Valve	268-03272	832-0500	LS	Pneu. Room Thermostat	192-202
657-8217	LS	Pneu. Valve	268-03274	832-1010	LS	Pneu. Room Thermostat	192-202
657-8218	LS	Pneu. Valve	268-03275	832-1020	LS	Pneu. Room Thermostat	192-202
657-8219	LS	Pneu. Valve	268-03270	832-1030	LS	Pneu. Room Thermostat	192-202
657-8220	LS	Pneu. Valve	658-0008	832-1070	LS	Pneu. Room Thermostat	192-202
657-8222	LS	Pneu. Valve	658-0012	832-1090	LS	Pneu. Room Thermostat	192-202
657-8223	LS	Pneu. Valve	658-0007	832-1100	LS	Pneu. Room Thermostat	192-202
657-8224	LS	Pneu. Valve	268-03200	832-1110	LS	Pneu. Room Thermostat	192-202
657-8224	LS	Pneu. Valve	270-03200	832-1150	LS	Pneu. Room Thermostat	192-204

AC Accustat
AS American Stablis
BL Belimo
DT Delta
HW Honeywell

INV Invensys (Robertshaw/
 Barber Colman/Siebe/
 Erie)
JC Johnson Controls
JO Joventa


KR Kreuter
LS Landis & Staefa/
 Powers/Siemens
PJC Penn (JC)
ST Staefa

T Trane
V Victronics
WR White Rogers
 (Emerson Climate Tech)

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.

Functional Cross Reference

Original Part No.	Mfg.	Description	Part No.
832-1210	LS	Pneu. Room Thermostat	192-202
832-1230	LS	Pneu. Room Thermostat	192-204
832-1678	LS	Pneu. Room Thermostat	192-202
908-020	LS	Air Filter	908-033
908-0200	LS	Air Filter	908-033
908-034	LS	Air Filter	908-051
908-036	LS	Air Filter	908-051
908-038	LS	Air Filter	908-048
908-039	LS	Air Filter	908-049
908-040	LS	Air Filter	908-051
908-041	LS	Air Filter	908-051
908-044	LS	Air Filter	908-051



- | | | | |
|----------------------------|---|--|--|
| AC Accustat | INV Invensys (Robertshaw/
Barber Colman/Siebe/
Erie) | KR Kreuter | T Trane |
| AS American Stablis | JC Johnson Controls | LS Landis & Staefa/
Powers/Siemens | V Victronics |
| BL Belimo | JO Joventa | PJC Penn (JC) | WR White Rogers
(Emerson Climate Tech) |
| DT Delta | | ST Staefa | |
| HW Honeywell | | | |

Every effort has been made to make this cross-reference as accurate as possible. To verify the recommended replacement part, refer to the product specification sheets. For installation/mounting, service kits or replacement parts, refer to the Accessories and Service Kits section for each product line. Complete indexes by part number and product name are at the front of the catalog.