



Illustrated Parts List

Model Series

15C100

TYPE NUMBERS
0002 through 8939.

TABLE OF CONTENTS

Blower Housing/Shrouds	7
Camshaft	2
Carburetor	5
Controls	6
Crankcase Cover	3
Crankshaft	2
Cylinder	2
Cylinder Head	4
Electric Starter	8
Exhaust System	7
Flywheel	7
Fuel Supply	5
Governor Spring	6
Ignition	8
Kits/Gaskets - Carburetor	5
Kits/Gaskets - Engine	2
Kits/Gaskets - Valves	4
Lubrication	3
Piston Group	2
Rewind Starter	6






Not for reproduction



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

15C100



1319 WARNING LABEL

REQUIRED when replacing parts with warning labels affixed.

1319A WARNING LABEL







REQUIRED when replacing parts with warning labels affixed.

1058 OPERATOR'S MANUAL


1330 REPAIR MANUAL

1036 EMISSIONS LABEL

1019 LABEL KIT






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3946-2 Assemblies include all parts shown in frames. 02/03/2014




21

415





22





287










15C100




- 914A
- 914B
- 914







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3946-5 Assemblies include all parts shown in frames. 02/03/2014










Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3946-7 Assemblies include all parts shown in frames. 02/03/2014

15C100



1059



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3946-8 Assemblies include all parts shown in frames. 02/03/2014

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	794188	Cylinder Assembly	18	699804	Cover-Crankcase	22	799318	Screw
2	796961	Kit-Bushing/Seal (Magneto Side)			Used on Type No(s). 0017, 0020, 0024, 0025, 0100, 0111, 0112, 0113, 0114, 0116, 0117, 0118, 0120, 0121, 0122, 0123, 0131, 0137, 0142, 0150, 0151, 0152, 0153, 0154, 0158, 0159, 0162, 0167, 0170, 0171, 0172, 0173, 0175, 0176, 0179, 0417, 0939, 1212, 1235, 1240, 1365, 1463, 1464, 1465, 1468, 1598, 2463, 2464, 2465, 3006, 3007, 3017, 3020, 3212, 8212, 8240, 8365, 8939.	23	699516	Flywheel
3	299819s	Seal-Oil (Magneto Side)						----- Note ----- 798882 Flywheel
5	791720	Head-Cylinder						Used on Type No(s). 0002, 0003, 0024, 0025, 0026, 0027, 0110, 0150, 0151, 0153, 0155, 0156, 0167, 0178, 0182, 0200, 1598, 2143, 2463, 2464, 2465, 3006, 3007, 3018, 3020, 3022.
7B	791716	Gasket-Cylinder Head				24	796335	Key-Flywheel
11B	695745	Tube-Breather				25	791786	Piston Assembly (Standard)
12	699485	Gasket-Crankcase						----- Note ----- 791791 Piston Assembly (.020" Oversize)
13	699482	Screw (Cylinder Head)	18A	699672	Cover-Crankcase	26	791787	Ring Set (Standard)
15	691686	Plug-Oil Drain			Used on Type No(s). 0023, 0127, 0128, 0129, 0130, 0132, 0140, 0141, 0143, 0145, 0146, 0168, 0169, 0200, 2143, 3023.			----- Note ----- 791792 Ring Set (.020" Oversize)
16	797070	Crankshaft				27	690975	Lock-Piston Pin
		----- Note ----- 791721 Crankshaft Used on Type No(s). 0939, 1212, 1240, 1365, 8240, 8939. 795116 Crankshaft Used on Type No(s). 0612, 0613, 0614, 0661, 0662, 0682, 0683. 797253 Crankshaft Used on Type No(s). 0023, 0100, 0127, 0128, 0129, 0130, 0132, 0169, 3023. 797077 Crankshaft Used on Type No(s). 0007, 0020, 0134, 0135, 0136, 0138, 0139, 0144, 0147, 0155, 0156, 0157, 0160, 0162, 0174, 0175, 0177, 0178, 0180, 0181, 1463, 1464, 1465, 1468, 1531, 1598, 2463, 2464, 2465, 3007. 797075 Crankshaft Used on Type No(s). 0027, 0179. 797079 Crankshaft Used on Type No(s). 0022, 0161, 0165, 0828, 3022. 797072 Crankshaft Used on Type No(s). 0145, 0146, 0168. 799047 Crankshaft Used on Type No(s). 0003, 0026.				28	690229	Pin-Piston
						29B	791783	Rod-Connecting
						32B	791784	Screw (Connecting Rod)
						33	499642	Valve-Exhaust
						34	795443	Valve-Intake
						35	691304	Spring-Valve (Intake)
						36	691304	Spring-Valve (Exhaust)
						37	699661	Guard-Flywheel
						40	692194	Retainer-Valve
						45	690977	Tappet-Valve
						46	693404	Camshaft
						46A	695285	Camshaft
						51	692555	Gasket-Intake
						51A	791718	Gasket-Intake
						55A	696710	Housing-Rewind Starter
						58	693389	Rope-Starter (Cut To Required Length)
						60	591519	Grip-Starter Rope Used on Type No(s). 0002, 0024, 0025, 0027, 0167, 0182,
17	798538	Bearing-Ball	18C	699677	Cover-Crankcase			
					Used on Type No(s). 0018, 3018.			
			20	692550	Seal-Oil (PTO Side)			
			20A	691952	Seal-Oil (PTO Side) (Auxiliary Drive)			
			21	281658s	Cap-Oil Fill			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3946-9 Assemblies include all parts shown in frames. 02/03/2014

15C100

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
65	699228	Screw (Rewind Starter)	117E	590906	Jet-Main (Standard) (Used After Code Date 11080700).	118E	590440	Jet-Main (High Altitude) (Used After Code Date 11080700).
65A	699851	Screw (Rewind Starter)			----- Note -----			----- Note -----
78	699205	Screw (Flywheel Guard)		590906	Jet-Main (Standard) (Used After Code Date 11080700).		590440	Jet-Main (High Altitude) (Used After Code Date 11080700).
82	690369	Screw (Gear Reduction Case)			Used on Type No(s). 0131, 0136, 1365.			Used on Type No(s). 0131, 0136, 1365.
95	691636	Screw (Throttle Valve)		590906	Jet-Main (Standard) (Used After Code Date 11061200).		590440	Jet-Main (High Altitude) (Used After Code Date 11061200).
97C	797628	Shaft-Throttle			Used on Type No(s). 0129, 0140, 0141, 0143, 0145, 0146, 0168, 0169, 2143.			Used on Type No(s). 0129, 0140, 0141, 0143, 0145, 0146, 0168, 0169, 2143.
98C	797156	Kit-Idle Speed		798930	Jet-Main (Standard) (Used Before Code Date 11080800).		798661	Jet-Main (High Altitude) (Used Before Code Date 11080800).
104C	797622	Pin-Float Hinge		798930	Jet-Main (Standard) (Used After Code Date 11080800 and Before Code Date 10071200).		798661	Jet-Main (High Altitude) (Used After Code Date 10080800 and Before Code Date 11071200).
105A	797139	Valve-Choke			Used on Type No(s). 0131, 0136.			Used on Type No(s). 0131, 0136.
108	796993	Valve-Choke		798930	Jet-Main (Standard) (Used Before Code Date 11080800).		798661	Jet-Main (High Altitude) (Used Before Code Date 11080800).
109	791957	Shaft-Choke			Used on Type No(s). 1365.			Used on Type No(s). 1365.
109B	695729	Shaft-Choke		798930	Jet-Main (Standard) (Used Before Code Date 11061300).		798661	Jet-Main (High Altitude) (Used Before Code Date 11061300).
109C	791954	Shaft-Choke			Used on Type No(s). 0129, 0140, 0141, 0143, 0145, 0146, 2143.			Used on Type No(s). 0129, 0140, 0141, 0143, 0145, 0146, 2143.
						121D	797634	Kit-Carburetor Overhaul
						122	791717	Spacer-Carburetor
						125	593358	Carburetor (Used After Code Date 11080700).
						125E	590907	Carburetor (Used Before Code Date 11080800).
						127E	797633	Plug-Welch
						130D	797630	Valve-Throttle
						133B	797136	Float-Carburetor

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3946-10 Assemblies include all parts shown in frames. 02/03/2014

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
137D	798932	Gasket-Float Bowl	187B	798907	Line-Fuel (2.9" Molded) (Used After Code Date 10070900).	209	692571	Spring-Governor (No Color)
155	797442	Plate-Cylinder Head (Metric) (Used After Code Date 09061700).			----- Note ----- 791874 Line-Fuel (5.4" Molded) (Used Before Code Date 10071000).			----- Note ----- 693206 Spring-Governor (Yellow) Used on Type No(s). 0003, 0026, 0151, 0152, 0153, 0154, 0182, 1365, 2465, 3212.
		----- Note ----- 698214 Plate-Cylinder Head (SAE) (Used Before Code Date 09061800).			798907 Line-Fuel (2.9" Molded) Used on Type No(s). 1365.			693710 Spring-Governor (Black) Used on Type No(s). 0155, 0156, 0157, 0160, 0174.
163B	696024	Gasket-Air Cleaner (Flat Panel Air Cleaner)			791874 Line-Fuel (5.4" Molded) (Used Before Code Date 10071300).			693710 Spring-Governor (Black) (Used After Code Date 10071200).
187	791766	Line-Fuel (15" Cut to Required Length)			Used on Type No(s). 0131.			Used on Type No(s). 0136.
187A	798908	Line-Fuel (2.6" Molded) (Used After Code Date 10070900).	188	699479	Screw (Control Bracket)			693206 Spring-Governor (Yellow) (Used After Code Date 10071200).
		----- Note ----- 791867 Line-Fuel (5" Molded) (Used Before Code Date 10071000).	190	699220	Screw (Fuel Tank)			Used on Type No(s). 0131.
		798908 Line-Fuel (2.6" Molded) (Used After Code Date 10071200).	192	797440	Adjuster-Rocker Arm (Metric) (Used After Code Date 09061700).			692571 Spring-Governor (No Color) (Used Before Code Date 10071300).
		Used on Type No(s). 0136.			----- Note ----- 694543 Adjuster-Rocker Arm (SAE) (Used Before Code Date 09061800).			Used on Type No(s). 0131, 0136.
		791867 Line-Fuel (5" Molded) (Used Before Code Date 10071300).						693710 Spring-Governor (Black) (Used After Code Date 10070900).
		Used on Type No(s). 0136.						Used on Type No(s). 0134, 0135, 0138, 0139, 0614, 0661, 0682.

15C100

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
		693206 Spring-Governor (Yellow) (Used After Code Date 10070900). Used on Type No(s). 0100, 0116, 0117, 0118, 0120, 0121, 0122, 0123, 0158, 0159, 0165, 0170, 0171, 0172, 0173, 0176, 0612, 0613, 0662, 0683, 0828, 0939, 1212, 1235, 1240, 1465, 8212, 8240, 8365, 8939.	281A	793133	Panel-Control Used on Type No(s). 0017, 0018, 0020, 0022, 0023, 0124, 0125, 0126, 0127, 0128, 0129, 0130, 0132, 0135, 0136, 0139, 0140, 0141, 0143, 0145, 0146, 0144, 0157, 0161, 0162, 0168, 0169, 0174, 0175, 0179, 0200, 0417, 1468, 1531, 1598, 2143, 3017, 3018, 3020, 3022, 3023.	309A	796238	Motor-Starter Used on Type No(s). 0017, 0018, 0020, 0022, 0023, 0100, 0112, 0114, 0116, 0117, 0120, 0122, 0124, 0126, 0127, 0131, 0135, 0136, 0137, 0139, 0141, 0142, 0143, 0147, 0153, 0157, 0174, 0612, 0613, 0614, 0661, 0662, 0682, 0683, 0828, 0939, 1235, 1240, 1365, 1463, 1464, 1465, 1531, 3017, 3023, 8240, 8365, 8939.
		692571 Spring-Governor (No Color) (Used Before Code Date 10071000). Used on Type No(s). 0100, 0116, 0117, 0118, 0120, 0121, 0122, 0123, 0134, 0135, 0138, 0139, 0612, 0613, 0614, 0661, 0662, 0682, 0683, 0828, 0939, 1212, 1235, 1240, 1465, 8212, 8240, 8365, 8939.	287	699234	Screw (Dipstick Tube)	309B	798884	Motor-Starter Used on Type No(s). 0110, 0150, 0151, 0153, 0156, 0167, 0178, 0200, 1598, 2143, 2463, 2464, 2465, 3018, 3020, 3022. ----- Note ----- 799038 Motor-Starter Used on Type No(s). 0003.
209A	691278	Spring-Governor (Platinum)	300E	798173	Muffler ----- Note ----- 799048 Muffler Used on Type No(s). 0003, 0026. 799525 Muffler Used on Type No(s). 0002, 0007, 0017, 0018, 0020, 0022, 0023, 0024, 0025, 0027, 0110, 0134, 0135, 0136, 0138, 0139, 0142, 0144, 0147, 0155, 0156, 0157, 0160, 0161, 0162, 0165, 0167, 0174, 0175, 0177, 0178, 0180, 0181, 0182, 0828, 1464, 1468, 1531, 1598, 2464, 3006, 3007, 3017, 3018, 3020, 3022, 3023.	309C	593445	Motor-Starter Used on Type No(s). 0002, 0024, 0027. ----- Note ----- 593446 Motor-Starter Used on Type No(s). 0026.
219	693578	Gear-Governor	304	699598	Housing-Blower	309D	699786	Motor-Starter Used on Type No(s). 0111, 0113, 0118, 0121, 0123, 0125, 0128, 0129, 0130, 0132, 0140, 0144, 0145, 0146, 0152, 0154, 0158, 0159, 0161, 0162, 0168, 0169, 0170, 0171, 0172, 0173, 0175, 0176, 0179, 0180, 0417, 1212, 1468, 3212, 8212.
220	691724	Washer (Governor Gear)	305	699481	Screw (Blower Housing)			
222F	793100	Bracket-Control	306A	695710	Shield-Cylinder			
222G	793109	Bracket-Control	307	699483	Screw (Cylinder Shield)			
227	794367	Lever-Governor Control	307A	699234	Screw (Cylinder Shield)			
238	691300	Cap-Valve	307B	790557	Screw (Cylinder Shield)			
268	691025	Control Wire Casing (Cut to Required Length)						
269	691026	Control Wire (Cut to Required Length)						
270	691027	Nut (Control Wire Casing)						
271	691028	Lever-Control						
271A	698038	Lever-Control						
276C	797632	Washer-Sealing						
281	793122	Panel-Control						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3946-12 Assemblies include all parts shown in frames. 02/03/2014

15C100

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION			
608B	797430	Starter-Rewind (Used After Code Date 10071900).	830	797441	Stud-Rocker Arm (Metric) (Used After Code Date 09061700).	914A	797444	Screw (Rocker Cover) (Quantity 1 Top Or Center) (Metric) (Used After Code Date 09061700).			
610	794614	Shield-Carburetor			----- Note -----			----- Note -----			
613D	791972	Screw (Muffler)			694544 Stud-Rocker Arm (SAE) (Used Before Code Date 09061800).			692557 Screw (Rocker Cover) (Top)(SAE) (Used Before Code Date 09061800).			
615	692576	Retainer-Governor Shaft			----- Note -----	914B	697551	Screw (Rocker Cover) (Center)(SAE) (Used Before Code Date 09061800).			
616	692547	Crank-Governor	832D	793193	Guard-Muffler						
619	699481	Screw (Cylinder Head Plate)	832E	797003	Guard-Muffler ----- Note -----						
621	692310	Switch-Stop			799028 Guard-Muffler Used on Type No(s). 0026.						
632	692653	Spring/Link-Mechanical Governor			836E	699854	Screw (Muffler Guard)				
633	693867	Seal-Choke/Throttle Shaft			842	691031	Seal-O Ring (Dipstick Tube) ----- Note -----	930	696709	Guard-Rewind	
635	692076	Boot-Spark Plug						957	792647	Cap-Fuel Tank (Fresh Start) ----- Note -----	
635A	798619	Boot-Spark Plug									
663	699854	Screw (Control Panel) ----- Note -----									
		699206 Screw Used on Type No(s). 0025.									
668	694257	Spacer									
676D	794213	Deflector-Muffler	847	798468	Dipstick/Tube Assembly ----- Note -----	957A	799719	Cap-Fuel Tank (Carbon In Cap)			
677A	699776	Screw (Muffler Deflector)			693617 Dipstick/Tube Assembly Used on Type No(s). 0002, 0003, 0007, 0017, 0018, 0020, 0022, 0023, 0024, 0025, 0026, 0027, 0110, 0134, 0135, 0136, 0138, 0139, 0142, 0144, 0147, 0155, 0156, 0157, 0160, 0161, 0162, 0167, 0174, 0175, 0177, 0178, 0180, 0181, 1464, 1468, 1531, 1598, 2464, 3006, 3007, 3017, 3018, 3020, 3022, 3023.	957B	698109	Cap-Fuel Tank	958	698180	Valve-Fuel Shut Off (Plastic)
684	793369	Screw (Breather Passage Cover)							972	799863	Tank-Fuel (Plastic)
689	691855	Spring-Friction							975D	798931	Bowl-Float
692B	797624	Spring-Detent							976	793382	Primer-Carburetor
697	795012	Screw (Starter Motor)							990	794696	Key-Set
718	690959	Pin-Locating ----- Note -----							990A	798177	Key-Set
		592860 Pin-Locating Used on Type No(s). 0025.							993	694088	Gasket-Cylinder Head Plate
727	698039	Cover-Starter Drive							998	696683	Pipe-Oil (4" Long) ----- Note -----
731A	794589	Hood-Snow									792928 Pipe-Oil (2 1/2" Long)
731B	798456	Hood-Snow									794701 Pipe-Oil (5" Long)
732	699200	Screw (Starter Drive Cover)							1005	692592	Fan-Flywheel
735	795901	Cord-Starter							1011	794544	Tube-Vent
741	695087	Gear-Timing							1019	792211	Kit-Label
742	692564	Retainer-E Ring	851	493880s	Terminal-Spark Plug				1022	691890	Gasket-Rocker Cover
746	790278	Gear-Idler	868	795440	Seal-Valve				1023	499924	Cover-Rocker Arm
773	694258	Retainer	883A	691893	Gasket-Exhaust				1026	790287	Rod-Push
813	690635	Clamp	892	791944	Switch-Key						
			892A	798182	Switch-Key						
			914	699481	Screw (Rocker Cover) (Bottom)						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3946-14 Assemblies include all parts shown in frames. 02/03/2014

15C100

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1029	797443	Arm-Rocker (Metric) (Used After Code Date 09061700).	1095A	791798	Gasket Set-Valve	1251A	796421	Shield-Snow (Used After Code Date 08113000).
		----- Note -----	1119	699772	Screw (Alternator)			----- Note -----
		691230 Arm-Rocker (SAE) (Used Before Code Date 09061800).	1196	798785	Screw (Snow Hood)			790555 Shield- Snow (Used Before Code Date 08120100).
1034	691343	Guide-Push Rod	1196A	699854	Screw (Snow Hood)	1251B	790556	Shield-Snow
1036		Label-Emissions (Available From An Authorized Briggs & Stratton Service Dealer)	1210	498144	Pulley/Spring Assembly (Pulley)	1252	699234	Screw (Snow Shield)
1054	280275	Tie-Cable	1211	498144	Pulley/Spring Assembly (Spring)	1252A	699491	Screw (Snow Shield)
1058	279128TRI	Operator's Manual	1230	699847	Stud (Control Bracket)	1319	794467	Label-Warning
1059	793567	Screw (Starter Motor)				1319A	797669	Label-Warning
1070	699201	Screw (Flywheel Fan)				1330	272147	Repair Manual
						1357	794700	Sleeve-Fuel Line
						1403	699481	Screw (Wire Assembly)
						1427	695757	Cap-Pipe

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3946-15 Assemblies include all parts shown in frames. 02/03/2014

Not for
Reproduction

