

Gig Stand®

- 143E001 (9 lbs) (4 kg).
- Portable stand with 20" x 14" (508 x 356 mm) aluminum desk and 16-gauge steel tube and base.
- Cantilever arm for wide range positioning of desk.
- Hex wrench included for angle adjustment.
- Height adjustment 10" to 42" (254 to 1067 mm) (desk lip to floor).
- Folds into briefcase size 20" x 24-1/2" x 4-5/8" (508 x 622 x 118 mm) with its own carrying handle.
- Black powder-coat paint finish.
- Environmental attributes and LEED compliance for this product can be found at www.wengercorp.com/GREEN or by contacting your Wenger representative.
- Five-year warranty.

Accessories

Electric Music Stand Light

Classic stand light fits all Wenger stands, and most other manufacturers' stands.

1090001 Music Stand Light, 14 oz. (0.4 kg)

LED Music Stand Lights


Compact, attractive, and adjustable, these battery-operated stand lights work with all Wenger stands.

Features all-LED technology, so no bulbs to replace.

237A040 HammerHead LED Music Stand Light, 2.1 oz (0.06 kg)

237A035 Encore LED Music Stand Light, 4.3 oz (0.12 kg)

237A033 Orchestra Music Stand Light, 10.2 oz (0.29 kg)



Accessories continued on next page.

Accessories (continued)

Hands-Free Page Turner

A rugged hands-free device for turning the pages on your digital sheet music. Simple setup and operation make this a great solution for musicians who need a hand.
040A142, 0.55 lbs (0.24 kg)

- Tap the foot switches to turn the pages on your digital sheet music forward or backward.
- No messy cables, connects wirelessly to tablets or computers up to 60' (18 m) away using secure Bluetooth technology.
- Internal rechargeable battery, up to 100 hours between charges.
- Nearly indestructible, made of same material as bullet-proof glass.



Hands-Free Page Turner

Universal Tablet Mount, Single

The perfect holder for most models of tablets. Clipping your tablet in place is easy and secure. No more resting your tablet on a stand, amp, floor, etc.

040A154, 15 oz (0.42 kg)

- Attaches to a standard 5/8" (16 mm) threaded stand or any music stand shaft using our Side Mount Extension.

Side-Mount Extension

Mount your tablet to the shaft of your music stand or mic stand.

040A140, 0.45 lbs (0.20 kg)

- Use your tablet with a traditional music stand or mic stand.
- Heavy duty steel extension bracket fits shafts up to 1" (25 mm) in diameter.
- Accepts our Universal Tablet Mount and other standard 5/8" (16 mm) threaded stand devices.
- 8" (203 mm) long with 6.25" (159 mm) extension from the shaft.



(shown on traditional music stand)

Wenger®

JRCLANCY

GEARBOSS®

© 2017 Wenger Corporation
USA/2017-12/W



WENGER CORPORATION

Phone 800.4WENGER (493-6437) Worldwide +1.507.455.4100 | Fax 507.455.4258 Worldwide +1.507.774.8576
Parts & Service 800.887.7145 | Canada Office 800.268.0148 | Web wengercorp.com | 555 Park Drive, PO Box 448 | Owatonna | MN 55060-0448

JR CLANCY

Phone 800.836.1885 Worldwide +1.315.451.3440 | Fax 877.836.1885 Worldwide +1.315.451.1766 | Web jrclancy.com
7041 Interstate Island Road | Syracuse | NY 13209-9713

GEARBOSS

Phone 800.493.6437 | email gearboss@wengercorp.com | Web gearboss.com | 555 Park Drive, PO Box 448 | Owatonna | MN 55060-0448