

Wireless Gamepad User Manual



X9


V3.0

Product Instruction:

X9 is a new wireless controller with 2 working model (Bluetooth & 2.4G) match all different devices. Which has HID games functions. It compatibles with iOS,Android, Ps3 Windows Systems.

1. Compatible with Android,iOS,PS3,PC windows systems
2. Bluetooth & 2.4G wireless technology can match different devices,working range is over than 10m
3. Support smart phone, tablet PC,tv box all based on android 4.2+ system
4. Working with android smart phone directly no need root , driver or any key mapping setting
5. Support android HID games,compatible with putaogames, kobox tv, bitgames...
6. Support GBA PSP and others simulator games
- 7.Support Apple iOS9.3+,icade games and xiaoji simulator games
8. Dual shock ,compatible with Playstation3 console
- 9.PC 2.4G RF Plug and Play,compatible with HID games
- 10.Four working modes:gamepad model,mouse & muiltplay mode ,icade mode .

Buttons design :



Specification

Item	Specification
Product size	156.6*105.4*64.6mm
Net weight	190G
Wireless distance	0-8M
Support os	Android/iOS/PS3/Windows
Battery	400mA
Work time	20-30h
Charge time	5V<200mA
Connecting current	40mA
Work current	30mA
Sleep current	2uA

How to Pair:

Bluetooth Model (support Android):

1. Turn power of controller off, Press **X + HOME** button for 2 seconds, 4 leds will flash quickly.
2. Set Bluetooth in the phone, turn on Bluetooth and search device
3. Search "mingping-X9" out and click pair, LED1 will light.
4. Press the HOME 1 second to switch mouse/multimedia function, LED2 will light.

2.4G Model(support Android /PS3/PC):

1. Turn power of controller off ,press **A + HOME** button , the led will flash quickly.
2. Plug USB receiver into device, the device connecting success .

USB Wired Connect(support Android):

Turn power of controller off ,press the **START** button then connect the USB cable to turn on the controller, LED1 will light.

Notice:

Bluetooth has memory function when first model is paired success, the device will know the controller model when play again but you can switch model like as following.

Android Device:

Support smart phone, smart TV,TVBOX,tablet all based on android OS.

Support Bluetooth + 2.4G RF + USB Wired working models.

Support google play HID games,compatible with putaogames,
kobox tv, bitgames...

IOS Device:

1.Turn power of controller off, Press **B + HOME** button for 2 seconds,
4 leds will flash quickly.

2.Set Bluetooth in the phone,turn on Bluetooth and search device

3.Phone will search "mingping-X9" out and click pair,LED4 will light.

4.Support iCade games, please change keyboard to English input.

Then you can download icade games from app store and play games.

5.Press the HOME 1 second to switch multimedia function,LED2 will light.

PC Windows Device:

1.Connect controller by 2.4G wireless technology with windows device.

2.Xinput mode (PC360 mode) and Dinput mode (normal mode);

first connection, Dinput default mode, press **SELECT + START** key
combination for 2 seconds to switch to Xinput mode

3.support vibration handle driver needs to be installed.You can
download driver from : <http://pan.baidu.com/s/1qWmPjtE>

PS3 Device:

- 1.Connect controller to PS3 console by 2.4G RF.
- 2.After controller paired ,plug usb receiver into PS3 usb port.
Then controller will be working.
- 3.Enjoy PS3 games with 6 axis and vibration

Charging Controller:

- 1.Controller charged by mini usb cable.the charging current is 5V 500Ma,Charging timing is 3hours about.
- 2.After controller connected,the led on gampad model flash which mean power is low please charge to controller.
- 3.Controller on charging,the LED flash slowly,after charging LED on.
- 4.Controller stay long time,the battery life will be reduced

Notes :

1. When accident cause not boot or unable to shutdown, please use needle to press Reset button on back.
- 2.If already paired,but can't connect,please cancel the pair and boot the device and connect again.

Scan QR Code learn more information



Android app.



PC Driver download



Packing list :



Game Controller
X1



Receiver
X1



Holder
optional



Mini-USB
X1



User Manual
X1