



Quick Contents

- [Common Part Numbers](#)

Appendix: Part Numbers

Accom.[®]

Common Part Numbers

A list of commonly used part numbers follows.

Main Chassis

Main Chassis Power Supply	2800-0069
Power Supply Tray	9500-0235
60mm Fan <i>(This is the one in front of the power supply.)</i>	1700-0047
80mm Fan <i>(Two of these are in the rear of the chassis.)</i>	1700-0002
Power Switch	3200-0100
13 Amp Circuit Breaker	3200-0102
Board Insertion/Extraction Tool	8900-0956
Main DVE Board	9400-0656
Controller/Combiner Board	9400-0691
Warp Address Generator	9400-0702
Communications Board	9400-0690
Color Corrector Option	9400-0648
Color Corrector Bypass	9400-0731
Defocus Option	9400-0699
Target Framestore Option	9400-0700
Motherboard	9400-0689
Serial Digital Input Card	9400-0675
Parallel Digital Input Card	9400-0669
Analog Component Input Card (10 bit)	9400-0722



Start Here



Index



Contents

Analog Component Input Card (8 bit)	9400-0667
Analog Composite Input Card	9400-0696
Analog Component Output Card	9400-0695
Analog Composite Output Card	9400-0697
Channel Output Option	9100-0748
Blank I/O Plate	8900-0976
Coeff 1 SIMM	9400-0661
Coeff 2 SIMM	9400-0662
Frame Buffer SIMM	9400-0658
Line Delay SIMM	9400-0659
DSP RAM SIMM	9400-0660
DSP ROM SIMM	9400-0663
SRAM SIMM	9400-0517
4MB Flash SIMM	9400-0741

Control Panel

CP CPU Board	9400-0693
CP Main Switch Board	9400-0692
CP Keyboard Switch, no LED	3200-0043
CP Keyboard Switch, LED	3200-0083
Internal Floppy Disk Drive	1600-0060
External Floppy Disk Drive	9500-0204
External Floppy Cable	9000-0085

A

Start Here

Index

Contents

Joystick Assembly	9800-0201
Screen Display	1500-0037
Shaft Encoder Assy	9400-0694
Softpot Knob	1902-0156
Softkey Keyboard	9400-0763
Softkey Keyboard Switch, no LED	3200-0048
Local Power Supply	2800-0063
CP Cable, 10'	9000-0205
CP Cable, 33'	9000-0204
CP Cable, 50'	9000-0206
CP Cable, 100'	9000-0207
CP Cable, 150'	9000-0208



Start Here



Index



Contents