
## PORTER+CABLE

## **GENERATOR**

## **BSI525-W-1**

**WARNING:** Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.



- 9. Circuit Breaker
- 10. Vibration Isolator

external earth ground.

11. Receptacle- 120/240V 4-Prong Twistlock

**Grounding Lug-** (not shown) This is the attachment point for a ground wire to an

- 12. Generator Housing
- 13. Oil Drain Plug
- 14. Oil Fill/Dipstick
- 15. Exhaust Muffler
- 16. Air Filter
- "ON/OFF" Switch (Not Shown See Engine Manual)
- 18. **Wheel/Handle Kit-** Included with this generator to make portability easier.
- 19. **Choke**
- 20. **10 HP Briggs & Stratton-** Included with this generator is a copy of the Engine Manufacturer's Operator's Manual. See this manual for more detail on the engine.

## **Maintenance and Accessory Parts**

Part No.	Qty.	Description
GS-0459	1	Fuel Filter
D23219	1	Air Filter
GS-0227	2	Fuel Line Clamps
Z-GS-0225	1	Fuel Line
GS-0033	4	Vibration Isolator
Z-GS-0795	1	Gas Tank
91895680	4	Gas Tank Screws (1/4 - 20 x .75)
SSN-632	4	Gas Tank Washers
GS-0443	1	Gas Cap
GA80	1	Wheel/Handle Kit
RC12YC	1	Champion Spark Plug -
		May be purchased locally

