

[HOME](#)[PRODUCT LIBRARY](#)[RESIDENTIAL](#)[INTERNATIONAL](#)[ORDER](#)[CONTACT US](#)[ABOUT US](#)**QuickSearch**[Search by Manufacturer](#)[Search by Chief Product Type](#)[Cross Reference Lists](#)P. 800.582.6480 F. 877.894.6918 | **INTERNATIONAL** P. 952.894.6280 F. 952.894.6918**PRO Series Cross Reference List**

Choose Manufacturer:

[View Excel Format](#)**Akai:***Display Model**Chief Model*

CT-A42AR7A

PRO-2132

PDP-4290

PRO-2132

PDP-4294

PRO-2132

PDP-5090

PRO-2131

Akira:*Display Model**Chief Model*

EPM-420

PRO-2152

EPM-600

PRO-2151

SV-4201

PRO-2250

SV-4202IQ

PRO-2200

Bang & Olufsen:*Display Model**Chief Model*

Beovision 4

PRO-2051

Barco:*Display Model**Chief Model*

Shark

PRO-2280

Solaris LC40

PRO-2280

BenQ:*Display Model**Chief Model*

PDP46W1

PRO-2231

PDP7843e

PRO-2230

PDP7859

PRO-2232

Boland:*Display Model**Chief Model*

d181c

PRO-2301

d201c

PRO-2301

ByD:sign:*Display Model**Chief Model*

2932

PRO-2323

4032

PRO-2322

4222

PRO-2132

4232

PRO-2132

5032

PRO-2132

Christie:*Display Model**Chief Model*

FP40

PRO-2212

Chungwa:*Display Model**Chief Model*

SN4210P

PRO-2231

Clarity:

<i>Display Model</i>	<i>Chief Model</i>
Bobcat SN-4025-WX	PRO-2270

Cornea:

<i>Display Model</i>	<i>Chief Model</i>
MP4200	PRO-2132
MP4204	PRO-2132
MP4205	PRO-2132

Daewoo:

<i>Display Model</i>	<i>Chief Model</i>
DSP-4210GM	PRO-2220
DSP-42SM	PRO-2220
PD-42S20W	PRO-2170

Digital Device:

<i>Display Model</i>	<i>Chief Model</i>
DPD-4200	PRO-2170
DPD-4210	PRO-2170
DPD-4220	PRO-2170
DPD-4230	PRO-2170
DPD-4240	PRO-2170

DreamVision:

<i>Display Model</i>	<i>Chief Model</i>
Revolution Five	PRO-2042
Revolution One	PRO-2042
Revolution Ten	PRO-2043

Dukane:

<i>Display Model</i>	<i>Chief Model</i>
P37	PRO-2111
P42	PRO-2111
P50	PRO-2081

DWIN:

<i>Display Model</i>	<i>Chief Model</i>
HD-50	PRO-2131

Eiki:

<i>Display Model</i>	<i>Chief Model</i>
PLD-42XU	PRO-2211

Eizo:

<i>Display Model</i>	<i>Chief Model</i>
P5070	PRO-2081
P5071	PRO-2081

Electrograph:

<i>Display Model</i>	<i>Chief Model</i>
DTS4230	PRO-2051
DTS42W	PRO-2200

Epoq:

<i>Display Model</i>	<i>Chief Model</i>
HL-3000	PRO-2182

Faroudja :

<i>Display Model</i>	<i>Chief Model</i>
FPP-42HD10	PRO-2042
FPP-50HD10	PRO-2042
FPP-61HD10	PRO-2043

Fujitsu:

<i>Display Model</i>	<i>Chief Model</i>
P42HCA10AH	PRO-2022
P42HCA10EH	PRO-2022
P42HCA10WH	PRO-2022
P42HCA11AH	PRO-2022
P42HCA11EH	PRO-2022
P42HCA11WH	PRO-2022
P42HCA12AH	PRO-2022
P42HCA12EH	PRO-2022
P42HCA12WH	PRO-2022
P42HHA10US	PRO-2022
P42HHA30US	PRO-2022
P42VCA	PRO-2022
P42VCA20AH	PRO-2022
P42VCA20EH	PRO-2022
P42VCA20UH	PRO-2022
P42VCA20WH	PRO-2022
P42VCA21AH	PRO-2022
P42VCA21EH	PRO-2022
P42VCA21UH	PRO-2022
P42VCA21WH	PRO-2022
P42VCA22AH	PRO-2022
P42VCA22EH	PRO-2022
P42VCA22UH	PRO-2022
P42VCA22WH	PRO-2022
P42VHA20AS	PRO-2022
P42VHA20ES	PRO-2022
P42VHA20US	PRO-2022
P42VHA20WS	PRO-2022
P42VHA30US	PRO-2022
P50XCA10AH	PRO-2023
P50XCA10EH	PRO-2023
P50XCA10UH	PRO-2023
P50XCA10WH	PRO-2023
P50XCA11AH	PRO-2023
P50XCA11EH	PRO-2023
P50XCA11UH	PRO-2023
P50XCA11WH	PRO-2023
P50XCA12AH	PRO-2023
P50XCA12EH	PRO-2023
P50XCA12UH	PRO-2023
P50XCA12WH	PRO-2023
P50XHA10US	PRO-2023
P50XHA30WS	PRO-2025
P55XHA30WS	PRO-2025
P63XHA30WS	PRO-2024
PDS-4203	PRO-2020
PDS-4204	PRO-2020
PDS-4207	PRO-2020
PDS-4208	PRO-2021
PDS-4209	PRO-2021
PDS-4211W-H	PRO-2021
PDS-4212W-H	PRO-2021
PDS-4213-H	PRO-2021
PDS-4214W-H	PRO-2021
PDS-4221	PRO-2021
PDS-4222	PRO-2021
PDS-4229	PRO-2021
PDS-4233	PRO-2021
PDS-4234	PRO-2021
PDS-4241	PRO-2021
PDS-4242	PRO-2021
PDS-5001	PRO-2051
PDS-5002	PRO-2051
PDS-5003	PRO-2051
PDS-5004	PRO-2051
PDS-6101	PRO-2052

Gateway:

<i>Display Model</i>	<i>Chief Model</i>
42	PRO-2200
46	PRO-2231
50	PRO-2201

HD Vision:

<i>Display Model</i>	<i>Chief Model</i>
HDV-42A	PRO-2132
HDV-46P2	PRO-2231

Helios:

<i>Display Model</i>	<i>Chief Model</i>
HLTV4200B	PRO-2132
HPTV4200A	PRO-2132
HPTV4200B	PRO-2132
HPTV4205A	PRO-2132

Hitachi:

<i>Display Model</i>	<i>Chief Model</i>
32HDT20	PRO-2112
32HDT50	PRO-2112
32HDT55	PRO-2112
32HDX60	PRO-2112
32PD3000	PRO-2112
32PD5200	PRO-2112
37PD5000	PRO-2111
37PD5200	PRO-2111
42HDM70	PRO-2111
42HDT20	PRO-2111
42HDT50	PRO-2111
42HDT55	PRO-2111
42HDX60	PRO-2111
42PD3000	PRO-2111
42PD5000	PRO-2112
42PD5100	PRO-2111
42PD5200	PRO-2111
42PD5300	PRO-2111
42PMA400E	PRO-2111
50HDT50	PRO-2081
50HDT55	PRO-2081
50HDX60	PRO-2081
CMP307XU	PRO-2111
CMP401XU	PRO-2111
CMP402HDE	PRO-2111
CMP402HDU	PRO-2111
CMP4102HDU	PRO-2111
CMP4120HDU	PRO-2111
CMP4121HDU	PRO-2111
CMP4201U	PRO-2111
CMP4202HDU	PRO-2111
CMP5000WXE	PRO-2081
CMP5000WXU	PRO-2081

Hyundai:

<i>Display Model</i>	<i>Chief Model</i>
ImageQuest PD421	PRO-2132

IDEX:

<i>Display Model</i>	<i>Chief Model</i>
IX4266-PHD	PRO-2163
PDM-4260	PRO-2160
PDM-4270	PRO-2160
PDP-42	PRO-2160

Iiyama:

<i>Display Model</i>	<i>Chief Model</i>
PLL260W	PRO-2045
PLL320W	PRO-2045
PLL400W	PRO-2045
PLL403W	PRO-2045

InFocus:

<i>Display Model</i>	<i>Chief Model</i>
TD30	PRO-2300

Integra:

<i>Display Model</i>	<i>Chief Model</i>
PLA-50V1	PRO-2042

JVC:

<i>Display Model</i>	<i>Chief Model</i>
GD-V4200PZW	PRO-2100
GD-V4210PCE	PRO-2100
GD-V4210PZW	PRO-2100
GD-V4211PZW	PRO-2100
GD-V500PCE	PRO-2051
GD-V500PZU	PRO-2051
GD-V501U	PRO-2051
GD-V502PCE	PRO-2051
GD-V502U	PRO-2051
GM-P420PCE	PRO-2100
GM-P420UG	PRO-2100
GM-V42UB	PRO-2100
GM-V42UG	PRO-2100
PD42WV74	PRO-2101
PZU	PRO-2051
V501U	PRO-2051
VM-42WX84	PRO-2101

LG Electronics:

<i>Display Model</i>	<i>Chief Model</i>
42PZ60	PRO-2152
50PZ60	PRO-2153
MT-42PZ40	PRO-2152
MT-42PZ41	PRO-2152
MT-42PZ44	PRO-2152
MT-42PZ45	PRO-2152
MT-42PZ46	PRO-2152
MT-42PZ47	PRO-2152
MT-50PZ45V	PRO-2153
MT-50PZ46V	PRO-2153
MT-50PZ47V	PRO-2153
MT-50PZ90	PRO-2153
MT-50PZ91	PRO-2153
MT-50PZ92	PRO-2153
MT-50PZ93	PRO-2153
MU-40PA10B	PRO-2150
MU-42PZ11B	PRO-2152
MU-42PZ41V	PRO-2152
MU-42PZ90V	PRO-2152
MU-50PZ41B	PRO-2153
MU-50TV90V	PRO-2153
MU-60PZ10B	PRO-2151
MU-60PZ11B	PRO-2151
MW-30LZ10	PRO-2154
MW-30LZ13	PRO-2154
MZ-42PZ13	PRO-2152
MZ-42PZ17	PRO-2152
MZ-42PZ44	PRO-2152
MZ-50PZ43	PRO-2153
MZ-60PZ13	PRO-2151
MZ-60PZ14	PRO-2151

MZ-60PZ90V	PRO-2151
RU-42PZ90	PRO-2152
RU-42PZ91	PRO-2152
RU-42PZ92	PRO-2152
RU-42PZ93	PRO-2152

Luce:

<i>Display Model</i>	<i>Chief Model</i>
LCTV30SDA	PRO-2182
PDTV4203A	PRO-2180
PDTV4220A	PRO-2181

Marantz:

<i>Display Model</i>	<i>Chief Model</i>
PD-4220	PRO-2042
PD-4240	PRO-2042
PD-4280	PRO-2042
PD-4290D	PRO-2042
PD-4292D	PRO-2042
PD-4293D	PRO-2042
PD-4298HD	PRO-2111
PD-5010	PRO-2042
PD-5020	PRO-2042
PD-5040	PRO-2042
PD-6120D	PRO-2043
PD-6140	PRO-2043

Maxx:

<i>Display Model</i>	<i>Chief Model</i>
4250	PRO-2132
4250T	PRO-2132
5000	PRO-2131

Mitsubishi:

<i>Display Model</i>	<i>Chief Model</i>
LCD3000	PRO-2044
LT-3020	PRO-2044
LT-3040	PRO-2044
LT-3050	PRO-2044
MLM-300	PRO-2044
MLM-400	PRO-2045
PD-4001	PRO-2030
PD-4225	PRO-2152
PD-5010	PRO-2042
PD-5030	PRO-2042
PD-6130	PRO-2043
XP-4015C	PRO-2030

Monivision:

<i>Display Model</i>	<i>Chief Model</i>
LWX-30MMS	PRO-2190
PD-3231	PRO-2190
PWV-46	PRO-2231

NEC:

<i>Display Model</i>	<i>Chief Model</i>
42MP1S4	PRO-2042
LCD3000	PRO-2044
LCD4000	PRO-2045
PD1	PRO-2042
PD2	PRO-2042
PS-4200	PRO-2042
PS-4205	PRO-2042
PS-4210	PRO-2042
PS-5000W	PRO-2042
PX-42M1A	PRO-2042
PX-42M2A	PRO-2042

PX-42M3A	PRO-2042
PX-42M4A	PRO-2042
PX-42M5A	PRO-2042
PX-42M5A	PRO-2042
PX-42MP1	PRO-2042
PX-42MP2	PRO-2042
PX-42PD1	PRO-2042
PX-42PD2	PRO-2042
PX-42VM1A	PRO-2042
PX-42VM2A	PRO-2042
PX-42VM3A	PRO-2042
PX-42VM4A	PRO-2042
PX-42VP1A	PRO-2042
PX-42VP2A	PRO-2042
PX-42VP3A	PRO-2042
PX-42VP4	PRO-2042
PX-42VP4D	PRO-2042
PX-42XM2A	PRO-2042
PX-42ZP4	PRO-2042
PX-50M5A	PRO-2042
PX-50MP3	PRO-2042
PX-50PD1	PRO-2042
PX-50VP1A	PRO-2042
PX-50VP2A	PRO-2042
PX-50XM1A	PRO-2042
PX-50XM2A	PRO-2042
PX-50XM3A	PRO-2042
PX-61MP1	PRO-2043
PX-61XM1A	PRO-2043
PX-61XM2	PRO-2043
VM2A	PRO-2042
VM3A	PRO-2042
VM4A	PRO-2042
VP1A	PRO-2042
VP2A	PRO-2042
VP3A	PRO-2042
VP4	PRO-2042
VP4D	PRO-2042
XM1A	PRO-2042

NetTV:

<i>Display Model</i>	<i>Chief Model</i>
PDP-42V	PRO-2200

Norcent:

<i>Display Model</i>	<i>Chief Model</i>
PT420	PRO-2330

Optoma:

<i>Display Model</i>	<i>Chief Model</i>
PD-46	PRO-2231

Ovideon:

<i>Display Model</i>	<i>Chief Model</i>
LC3000W	PRO-2044

Panasonic:

<i>Display Model</i>	<i>Chief Model</i>
PH-42PWD3	PRO-2051
PT-37P1	PRO-2051
PT-37PD4P	PRO-2051
PT-42P1	PRO-2051
PT-42PD1-P	PRO-2051
PT-42PD2-P	PRO-2051
PT-42PD3-P	PRO-2051
PT-42PHD4-P	PRO-2051
PT-50PD3-P	PRO-2051

PT-50PHD4-P	PRO-2051
TC-32LH1	PRO-2054
TC-32LX20	PRO-2054
TH-37P1	PRO-2051
TH-37PW5B	PRO-2051
TH-37PWD4E	PRO-2051
TH-37PWD4UZ	PRO-2051
TH-37PWD5BX	PRO-2051
TH-37PWD5UZ	PRO-2051
TH-37PWD6UY	PRO-2051
TH-37PX20UP	PRO-2055
TH-37PX25UP	PRO-2055
TH-42PA20UP	PRO-2053
TH-42PHD4-P	PRO-2051
TH-42PHD5BX	PRO-2051
TH-42PHD5UY	PRO-2051
TH-42PHD6UY	PRO-2051
TH-42PW3E	PRO-2051
TH-42PW3U	PRO-2051
TH-42PW4EX	PRO-2051
TH-42PW5B	PRO-2051
TH-42PWD3U	PRO-2051
TH-42PWD4U	PRO-2051
TH-42PWD4UY	PRO-2051
TH-42PWD5BX	PRO-2051
TH-42PWD5UY	PRO-2051
TH-42PWD6UY	PRO-2051
TH-42PX20UP	PRO-2055
TH-42PX25UP	PRO-2055
TH-50PHD3E	PRO-2051
TH-50PHD3U	PRO-2051
TH-50PHD5BX	PRO-2051
TH-50PHD5UY	PRO-2051
TH-50PHD6UY	PRO-2051
TH-50PHW5B	PRO-2051
TH-50PWD5EX	PRO-2051
TH-50PX20UP	PRO-2055
TH-50PX25UP	PRO-2055
TH-5BX	PRO-2051
TH-5UZ	PRO-2051

Philips:

<i>Display Model</i>	<i>Chief Model</i>
30PF9975/17	PRO-2063
32FD9954	PRO-2063
32PF9964	PRO-2063
37FD9954	PRO-2063
420P10	PRO-2061
42FD9932	PRO-2061
42FD9934	PRO-2063
42FD9935	PRO-2063
42FD9944	PRO-2063
42FD9954	PRO-2063
42FD9955	PRO-2063
42FTR9952	PRO-2061
42PF9936	PRO-2063
42PF9964	PRO-2063
42PF9965	PRO-2063
42PF9966	PRO-2063
50FD9934	PRO-2042
50FD9955	PRO-2042
50W997	PRO-2042

Photonics:

<i>Display Model</i>	<i>Chief Model</i>
32	PRO-2071
42	PRO-2071

Pioneer:

<i>Display Model</i>	<i>Chief Model</i>
PDP-4300	PRO-2083
PDP-4310HD	PRO-2083
PDP-4330HD	PRO-2083
PDP-433CMX	PRO-2083
PDP-433HDE	PRO-2083
PDP-433PU	PRO-2083
PDP-4340HD	PRO-2083
PDP-434DHE	PRO-2083
PDP-502MXE	PRO-2082
PDP-5030HD	PRO-2081
PDP-503CMX	PRO-2081
PDP-503HDE	PRO-2081
PDP-503MXE	PRO-2081
PDP-5040HD	PRO-2081
PDP-505HD	PRO-2081
PDP-610MX	PRO-2043
PDP-V400	PRO-2080
PDP-V401	PRO-2080
PDP-V402	PRO-2080
PDP-V501MC	PRO-2081
PDP-V501X	PRO-2081
PDP-V502MX	PRO-2081
PDP-V502MX	PRO-2081
PRO-1000HD	PRO-2081
PRO-1110HD	PRO-2081
PRO-800HD	PRO-2083
PRO-910HD	PRO-2083

Planar:

<i>Display Model</i>	<i>Chief Model</i>
PDP-42B	PRO-2152

Polaroid:

<i>Display Model</i>	<i>Chief Model</i>
DPD-6010	PRO-2311
PLA-5000	PRO-2310

Polyvision:

<i>Display Model</i>	<i>Chief Model</i>
9350	PRO-2081
9361	PRO-2043

Princeton Graphics:

<i>Display Model</i>	<i>Chief Model</i>
AR4.6PDP	PRO-2231

Rainbow:

<i>Display Model</i>	<i>Chief Model</i>
3750	PRO-2140

RCA:

<i>Display Model</i>	<i>Chief Model</i>
PHD50300	PRO-2042
PHD50500	PRO-2081
PR42300	PRO-2042
PSP42100	PRO-2042

Runco:

<i>Display Model</i>	<i>Chief Model</i>
CW-42	PRO-2042
CW-42i	PRO-2042
CW-43MC	PRO-2083
CW-50MC	PRO-2081
CW-61	PRO-2043

PL-42	PRO-2042
PL-42C	PRO-2042
PL-42CX	PRO-2051
PL-43HDX	PRO-2081
PL-50C	PRO-2081
PL-50CX	PRO-2051
PL-50HDX	PRO-2081
PL-61CX	PRO-2043

Sampo:

<i>Display Model</i>	<i>Chief Model</i>
PME-42S6	PRO-2200
PME-42X6	PRO-2200
PME-50X6	PRO-2201

Samsung:

<i>Display Model</i>	<i>Chief Model</i>
323T	PRO-2139
400T	PRO-2134
403T	PRO-2136
HPL5025	PRO-2131
HPL6315	PRO-2133
HPN4239	PRO-2132
HPN5039	PRO-2131
HPN6339	PRO-2133
LTM295W	PRO-2135
LTM405W	PRO-2134
LTN325W	PRO-2137
LTN406W	PRO-2138
LW-32A23	PRO-2137
LW-40A1	PRO-2138
PDP-4294	PRO-2132
PDP-42HD	PRO-2130
PDP-42VG	PRO-2130
PDP-50HD	PRO-2131
PDP-50VG	PRO-2131
PL-42P3S	PRO-2132
PPM-42S2	PRO-2132
PPM-42S3	PRO-2132
PPM50H2	PRO-2131
PPM50H3	PRO-2132
PPM63H1	PRO-2133
PPM63H3	PRO-2133
PS-42P2S	PRO-2132
SPK-4215M	PRO-2130
SPL-4225K	PRO-2132
SPN-4235	PRO-2132

Sanyo:

<i>Display Model</i>	<i>Chief Model</i>
LMU-TK29L1	PRO-2290
LMU-TK40D2	PRO-2212
PDP-32H1A	PRO-2210
PDP-42H1A	PRO-2211
PDP-42H1W	PRO-2211
PDP-42WE1	PRO-2042
PDP-42WV1	PRO-2023
PDP-42WV1AS	PRO-2023
PDP-42WV1S	PRO-2023

Sceptre:

<i>Display Model</i>	<i>Chief Model</i>
X30	PRO-2044

Sharp:

<i>Display Model</i>	<i>Chief Model</i>
LC-30	PRO-2240

LC-30	PRO-2240
LC-32G4U	PRO-2241
LC-37G4U	PRO-2241
LC-37HV4D	PRO-2241
LC-37HV4E	PRO-2241
LC-37HV4H	PRO-2241
LC-37HV4M	PRO-2241
LC-37HV4U	PRO-2241
LC-PD50U	PRO-2081
LCM3700	PRO-2241
PZ-43HV2U	PRO-2083
PZ-50HV2U	PRO-2081

Sony:

<i>Display Model</i>	<i>Chief Model</i>
KDE-42XBR950	PRO-2096
KDE-50XBR950	PRO-2097
KDE-61XBR950	PRO-2391
KDL-32XBR950	PRO-2392
KDL-42XBR950	PRO-2096
KE-32TS2U	PRO-2093
KE-37XS910	PRO-2390
KE-42MR1	PRO-2096
KE-42TS2U	PRO-2094
KE-42XBR900	PRO-2096
KE-42XS910	PRO-2099
KE-50MR1	PRO-2097
KE-50XBR900	PRO-2097
KE-50XBR950	PRO-2097
KE-50XS910	PRO-2099
KLV-30MR1	PRO-2098
KLV-30XBR900	PRO-2098
KZ-32TS1	PRO-2093
KZ-42TS1	PRO-2094
LDM-3210	PRO-2392
PDM-4200	PRO-2096
PDM-4210	PRO-2096
PDM-5000	PRO-2097
PDM-5010	PRO-2097
PDM-6110	PRO-2391
PFM-32C1	PRO-2095
PFM-42B1	PRO-2095
PFM-42B1U	PRO-2095
PFM-42B2	PRO-2095
PFM-42V1	PRO-2095
PFM-500A1WU	PRO-2090
PFM-500A2WU	PRO-2090
PFM-500A3WU	PRO-2090
PFM-50C1	PRO-2095
PFM-510A1WU	PRO-2090
PFM-510A2WU	PRO-2090

SVA:

<i>Display Model</i>	<i>Chief Model</i>
HD4208TIII-PDP	PRO-2281
HD4208UII-PDP	PRO-2282

Tatung:

<i>Display Model</i>	<i>Chief Model</i>
P42BLTL	PRO-2152
P42BSMT	PRO-2321
P46	PRO-2231
TPD4201S	PRO-2152

Teco:

<i>Display Model</i>	<i>Chief Model</i>
TL3001FM	PRO-2320

TL3011FM	PRO-2320
----------	----------

Thomson:*Display Model**Chief Model*

32PW95	PRO-2213
42WS90E	PRO-2042
42WS93	PRO-2042
42WS93E	PRO-2042
42WS94	PRO-2042
42WS95	PRO-2042
50WS94	PRO-2042
50WS95	PRO-2042

Toshiba:*Display Model**Chief Model*

26HL83	PRO-2301
32HL83	PRO-2303
32WL36	PRO-2303
42HP82	PRO-2042
42HP83	PRO-2302
42WP27	PRO-2051
42WP36	PRO-2302
50HP81	PRO-2051
50HP82	PRO-2042
50PW16	PRO-2051
50XP27	PRO-2051
PD42W1	PRO-2051
PD42WP16	PRO-2051

Trans-Lux:*Display Model**Chief Model*

Plasma 4000	PRO-2080
Plasma 5000	PRO-2081

V INC.:*Display Model**Chief Model*

VIZIO P4	PRO-2231
----------	----------

Vidikron:*Display Model**Chief Model*

VP-42	PRO-2042
VP-42HD	PRO-2042
VP-50	PRO-2042
VP-60	PRO-2043

Viewsonic:*Display Model**Chief Model*

N3000W	PRO-2301
N3020W	PRO-2301
VPW420	PRO-2051
VPW425	PRO-2200
VPW450HD	PRO-2200
VPW500	PRO-2081
VPW505	PRO-2201

Westinghouse:*Display Model**Chief Model*

W33000	PRO-2044
W33001	PRO-2044

Yamaha:*Display Model**Chief Model*

PDM-1	PRO-2051
-------	----------

Zenith:*Display Model**Chief Model*

DPDP40W	PRO-2150
---------	----------

L30W26	PRO-2154
L30W36	PRO-2154
P40V22	PRO-2150
P40V24	PRO-2150
P42W22	PRO-2152
P42W24	PRO-2152
P42W34	PRO-2152
P50W26	PRO-2153
P50W28	PRO-2153
P50W38	PRO-2153
P60W26	PRO-2151
P60W36	PRO-2151
P60W38	PRO-2151
SC3260 PDP	PRO-2151
SC352	PRO-2150