

DBX / DOD

025=34-0159-A
025=PHOENIX 6P
025=34-0160-A
025=26-0268-A

CAP,FADER 2231/IEQ3102
CONNECTOR,6P PHOENIX ZONE PRO
KNOB W/POINTER 166XL/2215
POWER TRANS 166XL/223/410/234

DENON

162=2124775905
162=2125604907

SWITCH,TACT DN-650F
SWITCH,TACT EJECT SW203 DNT620

EASTERN ACOUSTIC WORKS [VIEW ONLINE](#)

394=15410104
394=15410073
394=15410083
394=806061
394=806023
394=15410065
394=0001386
394=152001
394=11460008
394=102017
394=804097
394=0010572
394=0012338
394=805005
394=805016
394=105007
394=105008
394=105061
394=804095
394=804052
394=804041
394=804104
394=11186029
394=804003
394=804056

DIAPHRAGM AS460/490 HF DRIVER
DIAPHRAGM AS690I
DIAPHRAGM CD3501 SM122E DM2521
DIAPHRAGM DM2522 FR129Z/FR159
DIAPHRAGM DM5001 LA325 KF650
DIAPHRAGM HF DRIVER JF80/JF80Y
FLY CLIP W/RING FOR FLY RAIL
FOOT,RUBBER SM/LA/FR SERIES
RECONE KIT LC1523/LC15542K
SCREW JF60 BRACKET
SPEAKER 10" DC1 KF650Z
TWEETER ASSY VR51/VR21
TWEETER JF60Z/JF60/UB80
TWEETER UB12S
TWEETER UB12SE
WASHER,FLAT JF60 BRACKET
WASHER,LOCK JF60 BRACKET
WASHER,NEOPRENE JF60 BRACKET
WOOFER 12" FR129Z/SM129Z
WOOFER 15" SB250P/SB600E/SB150
WOOFER 18" LC1814 SB180R/SB850
WOOFER 18" LC1816 SB180Z/SB850
WOOFER 18" SB1000E LC1815
WOOFER 6.5" JF80/JF80Y/JF60
WOOFER LC0532 UB12SE

ELATION [VIEW ONLINE](#)

077=SY2504F-B20

OMEGA BRACKET DESIGN SPOT 250

ELECTRO-VOICE [VIEW ONLINE](#)

031=591183000
215=450372
031=63105CP
031=0355117
031=71241
031=500574000
031=14-09-032487
031=560426220
031=539173000
031=701432000
031=800688001
031=560206000
031=83850
031=85551
031=89486A
031=591237001
031=591244001
031=591238002
031=560343011
031=591235001
031=81161XX
031=81498XX
031=81514XX
031=89858XX
031=81320XX
031=85558XX
034=85615XX
031=81256XX
031=89222A
031=84234XX
031=84233XX
031=89753A
031=301052101
031=833PD990
031=28308
031=28261
031=71944

ADAPTER,HORN HB640 TO DH7/ND6
BATTERY COVER MT2000A/MT2500
BOLT,MB300 MOUNTING KIT
BRONZ CLIPS 100MM
BUMPER RING (GOLD) GRILL ND767
CASTER W/WHEEL POCKET QRX218
COLLAR INSERT COBRAFLEX III
CONNECTOR,CABLE 4P PHOENIX ZXI
CONNECTOR,PHOENIX 4P C4.2/C8.2
CORNER,CABINET 90 DEG FORCE SR
CROSSOVER EVID 6.2
CROSSOVER EVID C 8.2
CROSSOVER NETWORK SX500/SX500+
CROSSOVER W/SPKON FORCE-I SERS
DIAPH.TWEETER T35/S1503/ST350
DIAPHRAGM 1828 CDP848AT/BK315
DIAPHRAGM 1829
DIAPHRAGM 1829BT/1823M 16 OHM
DIAPHRAGM 1829T/CDP850T
DIAPHRAGM 7110XC/ID30C8/ID32T
DIAPHRAGM DH2A/DH2T T252(+)+CBR
DIAPHRAGM DH3 8330997/8331428
DIAPHRAGM ELIMINATOR/SX SERIES
DIAPHRAGM FM1502/S1202 DH1202
DIAPHRAGM FOR DH1A-16
DIAPHRAGM ID60CT/ID60C8
DIAPHRAGM ID60DT
DIAPHRAGM KIT DH1A/DH2012
DIAPHRAGM SENTRY/FM12/MUSICSTR
DIAPHRAGM,HF DH7 QRX112/QRX115
DIAPHRAGM,HF ND6-16 XI1152
DIAPHRAGM,TWEETER S200
DRIVER ASSY HF ND6 160HM
DRIVER ASSY,HF DH3 SX200/SX300
FOOT,RUBBER SX200A/ELIMINATOR
FOOT,RUBBER T52/T52+
FOOT,TILT BACK SX200/SX300

031=56676020
031=73997FT
031=20558
031=74144
031=570255000
031=PLASTIC NUT
031=28012
031=81386XX
031=84591XX
031=83523XX
031=85117XX
031=520028-011
150=70383
031=71220X
031=603215BAD
031=78297
031=361376
031=56-05-022109
031=560045000
031=591655000
031=KIT000005001
031=38829
031=74098
031=500745000
031=500717000
031=812PD3283
031=812WPD3283
031=301583101
031=301206101
031=301207101
031=560459100
031=560042000
031=82129
031=560056101
031=85604CPD
031=815PD3010
031=73028C

FUSE 3.15A SXA100+
GRILLE S40 WHITE
HANDLE SXA250/ELIMINATOR
INPUT PANEL SX80B W/SPEAKON
LOGO,GRILLE QRX218
NUT,PLASTIC 1/4" JACK ELIMINATR
O-RING,FOOT SX300
RECONE KIT 818PD2492 DL18T
RECONE KIT 818PD2883 18" WOOF
RECONE KIT EVX180
RECONE KIT,EVX155
RESISTOR,.1 OHM 5W 5% SXA250
RUBBER BANDS, 313A
RUBBER HAND GRIP ND757/ND457..
SCREW,TERMINAL BLOCK RE20
SHOCKMOUNT BAND 309A (EACH)
SPEAKER,MID 4" C8
TRANSFORMER 70V 30W 7110XC ID3
TWEETER EVID 6.2/4.2
U-CHANNELS,GRILLE SBA760
WALL MOUNT KIT ZX1-90/ZX11-90
WASHER SX300
WINDSCREEN POLAR CHOICE 18
WINDSCREEN US1718/RE90P (EACH)
WINDSCREEN,FOAM PCXL/PC+
WOOFER 12" SX200/SX300/100S
WOOFER 12" WEATHERPROOF SX300
WOOFER 15" ZX560B/90B DVX3150
WOOFER 18" (BLACK) DL18MT ISUB
WOOFER 18" COBRAII PWH EVX180B
WOOFER 8" ZX190 XI1082/SX80PI
WOOFER EVID 6.2
WOOFER FOR S40/S40W
WOOFER SENTRY 100A/100EL/MS802
WOOFER SXA100/SXA100+/SX100+E
WOOFER T252+/T251+/QRX115-75
XLR CONNECTOR HOUSING RE90L

EMINENCE SPEAKER [VIEW ONLINE](#)

744=APT3
744=PSD2002-8DIA
744=APT50
744=PSD2002-8
744=PSD2002S-8
744=LEGEND-CB15
744=ALPHA-6A
744=ALPHA-10A
744=BETA-10A
744=ALPHA-12A
744=BETA-12A-2
744=DELTA-12A
744=KAPPA-12A
744=ALPHA-15A
744=DELTA-15A
744=KAPPA PRO-15A
744=KAPPA PRO-15LF-2
744=OMEGA PRO-15A
744=KILOMAX PRO-18A
744=OMEGA PRO-18A
744=ALPHA-8A

ADAPTER,SCREW-ON(SEE 509=APT3)
DIAPHRAGM 1" 80HM PSD2002
DRIVER ASSY,HF 45W 80HM
DRIVER,HF 80W 80HM BOLT-ON 1"
DRIVER,HF 80W 80HM SCREW-ON
SPEAKER 15" 300W BASS GUITAR
SPEAKER 6" 100W 8 OHM PA
WOOFER 10" 150W 80HM PA
WOOFER 10" 250W 80HM PA
WOOFER 12" 150W 8 OHM PA
WOOFER 12" 250W 80HM PA
WOOFER 12" 400W 80HM PA
WOOFER 12" 500W 80HM PA
WOOFER 15" 200W 8 OHM PA
WOOFER 15" 400W 80HM PA
WOOFER 15" 500W 80HM PA
WOOFER 15" 600W 80HM PA
WOOFER 15" 800W 80HM PA
WOOFER 18" 1250W 80HM PA
WOOFER 18" 800W 8 OHM PA
WOOFER 8" 125W 80HM PA

ETC [VIEW ONLINE](#)

558=HW5125
558=HW5193
558=7060A3058
558=7081A2202-2A
558=4110A-4036
558=P120
558=F113
558=X196-F
558=7060A3043
558=7061A3007
558=7060B7003
558=Z1458-F
558=7060A4008-01
558=HW8112
558=7060A4008-02
558=HW8201
558=7060A4033

BOLT,T-HANDLE KNOB SOURCE 4
BOLT,ZINC BLACK SOURCE 4
BRACKET,YOKE BLACK SOURCE 4
COVER,2 BUTTON STATION (IVORY)
FADER SF2496
FADER,CHANNEL MICROVISN/ACCLAIM
FUSE 1.25A 250V
FUSE HOLDER SMARTBAR
GEL FRAME 6.25" BLACK SRC 4 JR
GEL FRAME PAR BLACK
GROUND WIRE #16 ASSY SOURCE 4
IC
KNOB SET WITH MALE INSERT S4
KNOB,CHANNEL FADER ACCLAIM
KNOB,F INSERT TO Z
KNOB,ZOOM LENS SOURCE 4/JR
LABEL,LENS TUBE 19 DEGREE S4

558=7060A4034 LABEL, LENS TUBE 26 DEGREE S4
 558=7060A2008 LAMP BURNER ASSY BLACK SRC 4
 558=7060A1033 LAMP RETAINER RETROFIT KIT S4
 558=7060A3085 LAMP RETAINER WIRE SOURCE 4
 558=7061A2001 LAMP SOCKET ASSY (BLACK) PAR
 558=RT114 LAMP SOURCE 4/JR EXTENDED LIFE
 558=W330-01TP22CLCM LEAD WIRE, PAR SOCKET SOURCE 4
 558=7061A4012 LENS ROTATION RING, BLACK S4PAR
 558=7060A4077 LENS, ASPHERIC 19 DEG SOURCE 4
 558=7061A4002 LENS, VERY NARROW SOURCE 4 PAR
 558=7060A4012 PAD LENS SUPPORT SOURCE 4
 558=7099A1201B PANNEL MOUNT STAGE PIN CONN.
 558=Q141 POWER CUBE D20
 558=Q210 POWER CUBE SMARTPAK 2-10A 6PIN
 558=Q211 POWER CUBE SMARTPAK 4-10A 8PIN
 558=4105K1004 POWER SUPPLY 2-PORT TNODE 24V
 558=7060A4037 REAR HANDLE BLACK SOURCE 4
 558=7060A4015 REFLECTOR 19 DEGREE SOURCE 4
 558=7060-A3085 RETAINER WIRE, LAMP
 558=7060A2025 SHUTTER BLADE ASSY SOURCE 4
 558=W6195 SLEEVE, FIBREGLASS 39" BLACK
 558=7060B7019 SOCKET ASSY TP22 SOURCE 4/JR
 558=M706 SOCKET ASSY, TP22 SOURCE 4 PAR
 558=W330-04 SOCKET/LEAD WIRE HPL575 SOURC4
 558=7061A3013 SPRING CLIP RETAINER SOURCE 4
 558=HW750 SPRING CLIP RETAINER SOURCE 4
 558=7060A3012 SPRING, LAMP RETAINER SOURCE 4
 558=HW8144 T-HANDLE KNOB SOURCE 4 YOKE
 558=HW8209 TINNEMAN CLIP, WIRE SOURCE 4
 558=HW5126 WASHER, T-HANDLE KNOB SOURCE 4

EVENT

420=1099
 420=1825
 420=1100

TWEETER 2020 TR8/PS6
 TWEETER ASP8N/STUDIO PRES
 WOOFER 8" 2020BAS/II/PS8/TR8

FBT

724=19455

DIAPHRAGM, HF JOLLY SERIES

FENDER PRO AUDIO [VIEW ONLINE](#)

933=0057531000
 933=0070564000
 933=005-7535-000
 933=0070370000
 933=70553

CORD, POWER PASSPORT P10
 LATCH KIT, SPEAKER PASSPORT 150
 RECHARGEABLE BATTERY P10
 TWEETER PASSPORT PD150/PD250
 WOOFER 6.5 INCH PASSPORT P150

FOSTEX [VIEW ONLINE](#)

035=1445900000 CABLE T20/T40 REMOVABLE
 035=1412000700 CONNECTOR A
 035=1412000300 CONNECTOR C
 035=1445800100 JACK, STEREO W/NUT
 035=8240273000 POT, VOL CONTROL, 6301B, TAIWAN
 035=1412000501 SLIDER HOLDER, REAR T20/T40RP
 035=8253135002 SWITCH, TACT TRANSPORT MR8/VF80
 035=L810F07CA4 WOOFER SPA11

FURMAN [VIEW ONLINE](#)

620=401003-392 CAP, LIGHT TUBE PL8
 620=986001-1429 KEYS, QUARTER SIZE (PAIR) CODE?
 620=390688-3993 LED ASSY, LIGHT PL8II/PL PLUSII
 620=E-543 POT, MONO 10K VOLUME HR6
 620=E-590 POT, STEREO 10K MON/EFF/VOL HR6
 620=E-411 VARISTOR, METAL OXIDE ACD100

GALAXY AUDIO [VIEW ONLINE](#)

954=S5N-8 DRIVER, NEOLITE 5" HOTSPOT/MICR
 954=SAGVC GRILLE, FOAM HOTSPOT W/VOLUME
 954=PHSI INSERT, STAND ADAPTER HOT SPOT
 954=SS5C160-8 SPEAKER, HOT SPOT VENTED MAGNET

GENTNER

546=910-200-001 BATTERY DOOR RX1A DIGITAL ONE
 546=592158003 BATTERY, MAX WIRELESS PHONE
 546=41-6041 EAR PAD (LEFT) DMH220
 546=41-6015 EAR PAD (RIGHT) DMH220

JBL [VIEW ONLINE](#)

050=361858-002 BALL LOCK PIN VRX932LA
 050=179-00002-00 BALL MOUNT, BLACK CONTROL 25/28
 050=424-00092-00 CONNECTOR CONTROL 24CT/26C
 050=73393-011 CORNER PROTECTOR SR4719/4691B
 050=73364-011 CORNER, L/R LOWER MIDDLE MR905
 050=73423-011 CORNER, L/R UPPER REAR MR905
 050=73392-011 CORNER, TOP L/BOTTOM R FRONT
 050=73392-041 CORNER, TOP L/BOTTOM R REAR
 050=73392-021 CORNER, TOP R/BOTTOM L FRONT
 050=73392-031 CORNER, TOP R/BOTTOM L REAR
 050=C1006 CROSSOVER CONTROL 1
 050=C5006 CROSSOVER CONTROL 5
 050=336836-001 CROSSOVER NETWORK ASSY MP215
 050=338142-001 CROSSOVER NETWORK CONTROL 25T
 050=129-20020-01 CROSSOVER NETWORK CONTROL 28WH
 050=350261-001 CROSSOVER NETWORK CONTROL 30
 050=129-20052-01 CROSSOVER NETWORK EON 1500
 050=364248-001 CROSSOVER NETWORK JRX125
 050=D16R2405 DIAPHRAGM 2405/2404H DRIVERS
 050=D8R2407 DIAPHRAGM 2406H-1/2407H AM4215
 050=D8R2408 DIAPHRAGM 2408H MRX512 MRX515
 050=D8R2417 DIAPHRAGM 2417H
 050=D8R2418-1 DIAPHRAGM 2418H EONG2/EON15G2
 050=D16R2425 DIAPHRAGM 2425J/2426J/2427J
 050=D8R2425 DIAPHRAGM 2426H/2425H/2425HS
 050=D16R2445 DIAPHRAGM 2445J 160HM
 050=D16R2450 DIAPHRAGM 2446J/2447J/2450J
 050=D8R2452 DIAPHRAGM 2452H SRX725/VRX915M
 050=D8R2416-1 DIAPHRAGM SR4722/G734/MR802
 050=315436-001X DRIVER 2418H MR900/EON SERIES
 050=2416H-1 DRIVER ASSY MR SERIES/OTHERS..
 050=125-10000-00X DRIVER, HF 2412H TR/EON10/MS28
 050=339013-001X DRIVER, HF 2412H-1 JRX/SF SERIE
 050=888-00025-00 ENCLOSURE PLATE CONTROL 25/28
 050=EB-6X12 EYEBOLT, TOP/BOTTOM CONTROL29AV
 050=924-00002-01 FOOT, SOUND FACTOR SERIES
 050=321902-003 FUSE 2A TIME LAG EON POWER 10
 050=453-13402-00 FUSE 4A TIME LAG EON15P
 050=SK3 FUSE LAMP, CROSSOVERS
 050=473002 FUSE, PICO 2A SLOBLO CONTROL 28
 050=128-00163-61 GRILLE ASSY CONTROL 25 WHITE
 050=128-00400-00 GRILLE EON1500/EON15/EON15P
 050=337841-001 GRILLE W/FOAM, WHITE CONTROL 29
 050=923-00021-00 HANDLE BACK MR/TR SERIES
 050=923-00020-00 HANDLE BAR MR/TR SERIES FRONT
 050=126-00023-00 HORN LENS 60X50 15"X10.5"X6.5"
 050=229-0009-01 INSTALL KIT SP215/9
 050=65076 JACK, INPUT SR4738/SR4722
 050=350049-003X MID-RANGE SPEAKER VERTEC 4887
 050=885-00050-00 MOUNTING TAB CONTROL 24
 050=364994-001 NUT, PLASTIC 1/4" JACK MP SERIE
 050=350316-001 PCB, INPUT SIGNAL EON10G2
 050=339555-001 PCB, MAIN AMP EON15PG2
 050=888-00026-00 PIVOT CONTROL 25/CONTROL 28
 050=659-00007-00 POT, SLIDE 10K STEREO EON MIXER
 050=513-00046-00 POT, VOLUME LSR25P
 050=824-41110-10 SCREW, GRILL MP415
 050=804-01110-16 SCREW, WOOFER
 050=804-41110-16 SCREW, CABINET EON POWER 10
 050=729-90001-16 SCREW, FOOT JRX SERIES
 050=803-41000-07 SCREW, GRILLE EON1500
 050=882-51110-12 SCREWS, INPUT PANEL MP215
 050=129-10000-03 TERMINAL CUP, NETWORK CONTRLSB2
 050=705-90000-16 THUMBSCREW FOR EON SERIES
 050=123-00001-00 TWEETER ASSY CONTROL 25
 050=337663-001 TWEETER ASSY CONTROL 29AV
 050=C1002 TWEETER CONTROL 1
 050=123-10002-00 TWEETER CONTROL 28
 050=350245-001 TWEETER CONTROL 30
 050=C5002 TWEETER CONTROL 5
 050=123-10003-00X TWEETER LSR32/MS26/LSR28P
 050=114-21001-00X WOOFER 10" CONTROL SB2
 050=336961-001X WOOFER 12" M112 8 JRX112M 212
 050=73284-01X WOOFER 4208 508G-3S/6208/MS28
 050=67071-01X WOOFER 4301B/4408/4408A
 050=C1003 WOOFER CONTROL 1
 050=124-58001-00 WOOFER CONTROL 28
 050=337646-001 WOOFER CONTROL 29/C29AV-1

