



premium secure fit
wireless earbuds



USER MANUAL



ICON

THANK YOU FOR PURCHASING

BY POM GEAR
premium secure fit
wireless earbuds

All POM Gear products are developed to give the user Peace Of Mind. In today's hectic world, managing our on-the-go lifestyle is a challenge of its own. POM's mission is to create products that provide simple solutions by combining the latest technology and top quality gear to exceed all expectations. We're sure you will have an enjoyable user experience.

To get the most of your new POM Gear product, please read the user manual carefully before use.

WWW.POMGEAR.COM

©2016 POM GEAR Inc. All Rights reserved. All other trademarks and trade names are those of their respective owners. The illustrated product and specifications may differ slightly from that supplied. Designed by POM Gear USA. Manufactured in China.



#unwireyourself

pom gear inc.
90 dayton ave.
passaic nj. 07055
www.pomgear.com



2



- Fully charge the earphones before using them for the first time.
 - Plug the USB charging cable into the controller of the headphones.
 - The LED light will turn blue when the earphones are fully charged.
- Attention:** Please use the original included charging cable to connect the earphones to your computer or compatible USB charging device.

or compatible USB charging device.

8

Warranty and Limitations:

Limited 3 Year Warranty. To activate product warranty go to our website www.pomgear.com and register this product.

- Guarantee will not be applied to the damages caused by faulty usages.

Products that have been subjected to abuse, misuse, accident, alteration, modification, tampering, negligence, faulty connection, attachment to any unauthorized accessory, lack of responsible care, repair or service in any way that is not mentioned in this manual for the product. Such as any damage caused by dust, wetness, coldness, overheating, placement near hot objects, near fire storage or use of corrosive elements. No warranty in damage caused by natural disasters such as floods, fires, typhoons, earthquakes and related matters. To the extent permitted by law, POM GEAR Inc. Shall not be liable for damages beyond replacing the defective product.

Technical Support:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, you can contact a POM Gear representative and they will assist you with any questions, problems or concerns you may have.

Send an email to warranty@pomgear.com



Basic Use:

Power on: Press & hold multi-function button until blue LED goes on.

Power off: Press & hold the power button until red LED goes on.

Pairing: When unit is powered off, press & hold the multi-function button for about 10-15 sec until blue & red LED lights begin to blink. The unit is now in pairing mode. Make sure your Bluetooth enabled device is discoverable. In Available Devices choose "POM Gear Icon".

Volume control: While listening, press the V+ button to increase volume, or the V- button to decrease volume.

Music track: While listening, press & hold the V+ button for the next song, press & hold the V- button for the previous song.

Pause/Play: While listening, press the multi-function button to pause music. Press the button again to play music.

Answer/End call: Tap the multi-function button.

Reject call: Press the multi-function button for 1-2 second.

Redial last number: Double click the multi-function button to redial.

sequence.

SPECIFICATIONS	V4.2	
	Bluetooth	Bluetooth Profiles
	Operation Range	33 Ft/360m
	Frequency Range	20Hz-20,000Hz
	Lithium-Ion Battery	3.7V/60mAh
	Charging Voltage	DC4.75-5.25V
	Charging Time	About 2 Hours
	Playing Music Time	Up to 6 Hours
	Talk Time	Up to 6 Hours
	Standby Time	Up to 200 Hours
	Dimensions	630*21*23mm
	Weight	13g

Warnings and Notes:

- Do not store unit in a high temperature environment, including intense sunlight or heat. Do not place unit near fire or other excessively hot environments.
- Be cautious of excessive drops, bumps, abrasions or other types of impact. If there is any damage to the battery such as dents, punctures, tears, deformities of corrosion, due to any cause, discontinue use and contact manufacturer or dispose of in an appropriate manner.
- Do not disassemble or attempt to modify or replace any part of this unit.
- Do not expose unit to moisture, snow or submerge it in liquid.
- Do not use unit in the vicinity of flammable fumes or gases (such as propane tanks or large engines).
- Do not attempt to operate unit using any other method than directed.

4

LED Indicator:
Low battery warning: Red LED flashing.
Charging: Red LED on when charging and blue LED on when fully charged.

Bluetooth connected: Blue LED flashing slowly.

Power on/off: When turning the earphones on the LED light will blink blue. When turning off the LED will turn red.

Pairing the Bluetooth Earphones:
Available Devices choose "POM Gear Icon". Avoidable Devices choose "POM Gear Icon".

Bluetooth pairing: Blue and red LED flashing rapidly together.

From here you'll have to navigate through Bluetooth settings on your mobile device and choose "POM Gear ICON" from the list of all available Bluetooth devices within range. This should begin the pairing sequence.

*** DO NOT release the power button for another 10-15 sec and the LED indicator lights should begin to blink red and blue. Your device is now in pairing mode.

say "Your POM Gear Device is ON."

FCC Statement

Changes or modifications not expressly approved by the authority to operate the equipment could void the user's warranty. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to follow measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device is subject to the following two conditions and (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

5

After pairing is successfully completed, you will hear a tone in the earphones indicating that the connection has been established and the voice prompt will state "Your POM Gear Device is Now Paired. Enjoy!"

Now you can use your POM Gear ICON Bluetooth earphones to listen to music and make phone calls.



Making and Receiving Calls:

If the earphones are in use (ie, playing music) and you receive an incoming call, the music will be paused while you take that call. Music will resume automatically when the call is over. When you hear an incoming call, press the multi-functional button once to answer & then press once again to end the call. To redial the last number called, press the button twice quickly.



Connection & Standby:

When the Bluetooth earphones are turned on, they will connect automatically to the last connected compatible device within range and then it will automatically enter standby mode and will be ready for use.

Designed For Peace Of Mind

