


正面

80.00 mm  
128.00 mm




使用前,请下载安装QCY手机APP客户端  
以获得更便捷的耳机操控体验

#### 认识耳机




#### 包装清单



本说明书中的图片均为示意图,可能与实物有偏差,请以实物为准。


#### 耳机配对

开机后耳机会自动进入配对模式,打开手机蓝牙搜索“QCY H3 Lite”并点击连接(若有连接记录,耳机开机自动回连有连接记录的设备。如需重新进入配对模式,请在关机情况下长按多功能键4秒。)




#### 同时连接两台设备

A设备已蓝牙连接耳机,关闭A设备的蓝牙,耳机进入配对模式,红灯交替闪烁,打开手机蓝牙搜索“QCY H3 Lite”并连接,之后再打开A设备的蓝牙并连接耳机。



#### 恢复出厂设置


耳机开机状态下同时按住音量加键10秒直至红灯闪烁5次,耳机进入配对模式,恢复出厂设置完成。




#### 亮灯提示

连接状态: 白灯10秒一闪

充电中: 红灯长亮  
充满电: 白灯长亮



#### 功能操作



- ① 开 机: 长按多功能键2秒
- ② 关 机: 长按多功能键4秒
- ③ 接听/挂断: 单击多功能键
- ④ 拒接电话: 长按多功能键1.5秒
- ⑤ 上 一 曲: 长按音量键- 1秒
- ⑥ 下 一 曲: 长按音量键+ 1秒
- ⑦ 音 量 加: 单击音量键+
- ⑧ 音 量 减: 单击音量键-
- ⑨ 语音助手: 双击多功能键
- ⑩ 播放/暂停: 单击多功能键
- ⑪ 游戏模式: 三击多功能键
- ⑫ 降噪开/降噪关/通透模式: 单击ANC按键循环切换

#### 售后服务

QCY产品售后服务承诺: 严格按照《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务, 服务内容包括:  
在三包有效期内, 您可凭购物凭证依照本规定享受免费的修理、更换、退货的权利。  
1. 自您购买之日起7日内, 本产品出现故障, 经由QCY售后服务中心确认为产品质量问题, 可享受修理、更换、退货的服务。  
2. 自您购买之日起15日内, 本产品出现故障, 经由QCY售后服务中心确认为产品质量问题, 可享受修理或更换的服务。  
3. 自您购买之日起12个月内, 本产品出现故障, 经由QCY售后服务中心确认为产品质量问题, 可享受修理的服务。

售后服务与支持  
保修期: 自产品购买之日起12个月(请妥善保管购买凭证)。  
免费服务: 在产品保修期内, 凡属产品本身质量引起的故障, 请用户凭购买凭证与经销商取得联系以享受售后服务。  
如有任何产品损害或瑕疵非可归责于产品质量本身, 则不在保修范围内, 有下列情形者不属于保修范围:  
1. 因火灾、地震、雷击、异常电压、环境因素而发生之故障或毁损的。  
2. 自行或委托未经原厂授权维修之厂商拆卸、改装或更换原厂零件。  
3. 未按使用手册操作或因人为使用不当而造成损坏者, 如产品浸水、腐蚀、掉落、折压或置在异常温度环境下。

#### 三包凭证

产品信息:	
产品型号	_____
订单编号	_____
用户姓名	_____
联系电话	_____
用户地址	_____
退换货原因	_____
购买信息:	
销售单位	_____

#### FAQ

- 1.Q: 手机提示无法连接怎么解决?  
A: 将手机上的配对记录删除, 删除后重新进行搜索配对连接即可。
- 2.Q: 听歌/通话没声音怎么解决?  
A: 安装手机蓝牙连接设备时, 右边有个设置按钮, 点击进入, 关闭手机音频和媒体音频, 再重新开启, 若还是无声, 请将耳机重新与手机配对连接。
- 3.Q: 为什么听歌/游戏有延迟?  
A: 受使用环境、网络、手机编解码等因素的影响, 会引起手机传送音频数据到耳机时有不同程度的延迟。
- 4.Q: 听到的声音卡顿/断续怎么解决?  
A: 在使用时若周围有大量的 Wi-Fi、5G/4G 信号、大功率电器等产生干扰, 可能会引起卡顿、断续的情况, 换个环境或者重新配对连接就可以解决了。

#### 提示

- 1. 使用产品前请仔细阅读本产品使用说明书并妥善保管;
- 2. 首次使用时, 请先将本产品充满电;
- 3. 如果产品长期(超过2个星期)不用, 请及时充电;
- 4. 必须选择正规厂家生产且经过国家CCC认证的充电器;
- 5. 若手机无法搜索到蓝牙耳机, 请将蓝牙耳机重新进入配对模式或将蓝牙耳机恢复出厂设置, 若手机程序出错, 请把手机蓝牙关闭再开启或重启手机。

#### 电池安全

- 1. 请勿拆解或改装电池, 插入异物、置入高温、或浸入水或其它液体中, 以免引起电池漏液、过热、起火或爆炸。电池只能由制造商更换。
- 2. 请勿放置、挤压或穿刺电池, 避免让电池遭受外部的压力, 从而导致电池内部短路和过热。

- 请勿以任何理由拆解或维修改装耳机, 否则可能会导致火灾, 电子击穿甚至彻底损坏本品;
- 请勿将产品置于温度过低或过高(0°C以下或45°C以上的环境下);
- 请避免靠近(1米或动物)的强磁场(产品指示灯);
- 请勿在雷暴天气下使用该产品, 雷暴可导致本产品工作不正常, 并增加触电的危险;
- 请勿用油及其他挥发性液体擦拭本产品;

#### 产品有害物质名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴联苯醚 (PBDE)
外 壳	○	○	○	○	○	○
电路板组件	×	○	○	○	○	○
电 池	○	○	○	○	○	○
充 电 线	×	○	○	○	○	○
附 件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制  
O: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。  
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

使用年限  
如本手册所述, 在正常使用条件下, 本产品的环保使用期限为10年。  
在此期间, 产品不会泄露任何危险物质, 本产品可以回收, 必须按照当地法规处理。

长时间使用耳机可能会造成听力损害, 请合理安排使用时间。

若有售后服务需求, 请联系客服  
电话: 4008-306-708  
网址: www.qcy.com  
制造商: 东莞市和乐电子有限公司  
地址: 广东省东莞市道滘镇粤晖路325号



80x128mm 80g哑粉过哑油 风琴折 正背印刷


背面

80.00 mm  
128.00 mm




For better using experience, please scan to download QCY app before start-up.

#### Overview




#### Packaging List



Above pictures are for reference only yet practical. product may vary.

#### How to Connect

Power on headset and it will auto turn connectable. On phone, search QCY H3 Lite and tap to connect. (It will auto reconnect to the last device in connectivity record. If any. If you need to make it turn connectable again, power it off and press and hold MFB for 4s.)




#### Multi-Point Connection

Connect headset to Device A then turn off its Bluetooth and the headset will auto turn connectable(LED blinks red and blue). On Device B, search QCY H3 Lite and tap to connect. Once again turn on Bluetooth on Device A and connect it to the headset.




#### Factory Setting

Power on headset, press and hold both volume + and - for 10s or until LED blinks red 5 times to reset it factory. It will then auto turn connectable.




#### LED

Connected: LED blinks white every 10s  
Charging: LED glows solid red  
Top-up: LED glows solid white



#### Functions



- ① Power-on: Hold MFB for 2s
- ② Power-off: Hold MFB for 4s
- ③ Answer/end call: Press MFB
- ④ Ignore call: Hold MFB for 1.5s
- ⑤ Skip track backward: Hold Volume- for 1s
- ⑥ Skip track forward: Hold Volume+ for 1s
- ⑦ Volume up: Press Volume+
- ⑧ Volume down: Press Volume-
- ⑨ Voice assistant: Double press MFB
- ⑩ Playback/pause: Press MFB
- ⑪ Gaming mode: Triple press MFB
- ⑫ Switch mode: Press ANC Button to switch among ANC ON, ANC OFF and Transparency.

#### Warranty

Your QCY product purchase is covered by a one-year limited manufacturer warranty from the date of delivery. Please ensure you retain your purchase receipt. If any defects occur due to quality issues within the warranty period, kindly bring both the warranty card and the purchase receipt to the authorized dealer for complimentary replacement services.

Model Number:	
Date of Purchasing:	
User's Name:	
User's Phone:	
User's Address:	
Shop's Name:	
Shop's Address:	
Comments:	

The manufacturer's warranty is void under the following circumstances but not limited to:  
• Improper or inadequate maintenance or modification.  
• Accident, misuse, abuse, contamination, or other external causes.  
• The use of unspecified adapter and accessories.  
• Malfunctions or damages resulting from natural disasters, earthquakes, lightning, abnormal voltage, or environmental factors.  
• Damages that occur as a result of one's failure to follow the instructions.

#### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
--Reorient or relocate the receiving antenna.  
--Increase the separation between the equipment and receiver.  
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
--Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
FCCID:RDR-BH24H3C

**Notice:** This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

#### Safety Precautions

- 1. Please carefully read and retain this user manual before using the product.
- 2. If the product is not used for an extended period (more than 2 weeks), please recharge it.
- 3. You must choose a charger produced by a legitimate manufacturer and certified by the national safety authority.
- 4. If your phone cannot detect the Bluetooth earbuds, either re-enter pairing mode or perform a factory reset on the Bluetooth earbuds. If there is a phone program error, close and reopen Bluetooth on the phone or restart the phone.
- 5. Do not disassemble or modify the battery, insert foreign objects, expose it to high temperatures, or immerse it in water or other liquids to prevent battery leakage, overheating, ignition, or explosion. Battery replacement should only be done by the manufacturer.
- 6. Do not drop, crush, or puncture the battery. Prevent external pressure that may lead to internal short circuits and overheating.
- 7. Do not dismantle or modify the earbuds for any reason, as it may result in fire, electronic breakdown, or permanent damage to the product.
- 8. Do not expose the product to extremely low or high temperatures (below 0°C or above 45°C).
- 9. Do not place the product indicator light near the eyes of children or animals.
- 10. Do not use the product during thunderstorms, as it may cause abnormal operation and increase the risk of electric shock.
- 11. Do not use oil or other volatile liquids to clean the product.
- 12. please do not use this device for long periods of time and at high volume, as there is a risk of hearing damage.

Manufacturer: Dongguan Hele Electronics Co., Ltd.  
Address: No. 325 Yuehui Rd. Daojiao Town Dongguan City Guangdong Province China

