


MS-188RL-英文
尺寸：210*148MM

User Manual

Package contents

Wireless Optical Mouse
USB receiver
2 AAAalkaline batteries
User manual

Installing the battery (Diagram 1)



Whenever new batteries are installed, make sure that they are fresh 1.5V AAA batteries.

A) Remove the battery cover.

B) Insert two AAA batteries into the battery compartment, make sure to properly orient the positive (+) and negative (-) ends as specified by the marks in the battery compartment. Replace the battery cover and make sure it is locked.

C) Switch on the mouse, the LED in bottom of mouse will blink.

Installing the receiver (Diagram 2)

The codes of receiver and mouse were successfully connected in factory. User can directly use the complete set of products, no worry about the code connecting.

A) Insert receiver into USB port of PC, the computer system will automatically detect it and prepare it for full operation.


B) The mouse may use then.

If the user wrongly operates, please redo the above operating procedures.

"ON/OFF" switch (Diagram 1)

Without using the mouse, user may turn off it by "ON/OFF" switch for saving battery power.

Description of keys and DPI adjusting



DPI: 800DPI

System requirements

Windows 2000/XP/Vista/7

(1) 15.21 statement:

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.