

Optical 2.4GHz Wireless Tilt-Wheel Mouse

MS-148OR
MX-168D

User's Manual

Shenzhen Fuyeda Industry Development Corp., Ltd
NO.1Newmen Road, Tongsheng Village, Dalang Street, Bao' an, Shenzhen, China

Manufacturer : Shenzhen Fuyeda industrial co., LTD

Location : NO.1Newmen Road, Tongsheng Village,
Dalang Street, Bao' an, Shenzhen, China

Tel : +86-755-28141356

Hotline : +86-400-8866-811


Http : //www.newmen.com.cn

Executive Standard : Q/FYD001-2006

User Manual

Package contents:
Wireless optical mouse
USB receiver
2 AAA alkaline batteries
User manual

Installing the battery: (Diagram 1)



(Diagram 2)

Whenever new batteries are installed, make sure that they are fresh 1.5V AAA batteries.

- Remove the batteries cover.
- Insert two AAA batteries into the battery compartment, make sure to propely orient the positive (+) and negative (-) end as specified by the marks in the battery compartment. Replace the battery cover and make sure it is locked.
- Switch on the mouse, the LED in bottom of mouse will blink.

Installing the receiver (Diagram 2)

The codes of receiver and mouse were successfully connected in factory. User can directly use the complete set of products, no worry about the code connecting.


- Insert receiver into USB port of PC, the computer system will automatically detect it and prepare it for full operation.
- The mouse may use then.

If the user wrongly operates, please redo above operating procedures.

"ON/OFF" switch (Diagram1)

Without using the mouse, user may turn off it by "ON/OFF" switch for saving battery power.

Description of keys and DPI adjusting



- Using "DPI-adjusting key", the resolution of mouse can be switched between 800DPI and 1600DPI in turn. That LED light in "DPI-adjusting key" blinks slowly indicates 800 DPI and fast 1600 DPI.
- Backward and Frontward keys for your easily navigation forward and backward on the Internet.

Low-voltage alarming function

When batteries have been used for sometime and discover the LED light in "DPI-adjusting key" blinks automatically, which reminds you that batterie's voltage is becoming low, suggested you replace the batteries with new ones.

System requirements
Windows 2000/XP/Vista/7

Specifications and functions

- Super mini receiver can be stored at bottom for easy carrying
- 2.4GHz, freely operating within 10 meters
- Wireless carrier frequency: 2,40 MHz - 2,480 MHz
- 16 wireless working channels, automatic frequency jumping
- 2-way communication technoligy speeds up data transmission without delay
- With optical technology
- Power ON/OFF function
- Low-voltage alarming function
- Resolution: 800DPI and 1600 adjustable

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the use' s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Class B digital device, pursuant to Part 15 of thdesigned to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the in terference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received , including interference that may cause undesired operation.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.