

T25
Car Bluetooth FM Transmitter



User Manual

Features:


1. Transmit the music from U disk or micro SD card to car stereo via FM signal.
2. Transmit the music/navigation of your Bluetooth enabled smart device to car stereo via FM signal.
3. Unique display screen, display car voltage when plugged in.
4. Answer phone calls during driving.
5. 2 USB ports for charging devices.
6. Play lossless music in FLAC/WAV/APE format from U disk or micro SD card.

Specifications:

Frequency: 2.402 ~ 2.480 GHz
Effective Bluetooth Range: 5 meters
Micro SD card/U disk capacity: Up to 32G

-01-

Product Diagram:



-02-

Adjust FM Frequency:

Press the MFB for about 2 seconds, the display flashes means it entered FM frequency adjust mode.

1. Rotate the MFB to increase or reduce frequency.
2. Press the "Next" or "Previous" button to increase or reduce frequency.

Adjust Volume:

Rotate the MFB to increase or reduce volume.

Bluetooth Operation Instruction:

1. Plug the transmitter into the car cigarette socket.
2. The transmitter will power on after you plugged it in, the display flashes means it is in pairing mode.
3. Turn on the Bluetooth function of your smart device. Search for Bluetooth devices and select "T25".
4. If pairing is successful, the display will stop flash and show the FM frequency.
5. Tune the car FM radio to a blank FM station.
6. Tune the FM transmitter into the same frequency with the car FM radio.
7. Open the music player/navigation of your smart device, now it can transmit the phone calls, music or navigation to car stereo system.

-03-

Remark:

1. It will connect to the last paired device automatically when turned on next time. (Turn on the Bluetooth of your smart device first, and then turn on the product.)
2. For the best audio quality, please turn the volume of your smart device and FM transmitter into the max level.
3. The signal of any FM transmitter sometimes can be interfered by the surrounded radio or the similar frequency signal thus cause noise, this is normal.
4. If the noise is too loud, please try another blank FM station.

Make/Answer a Call:

The transmitter can make or answer a call after successfully connected to your phone via Bluetooth.

1. Redial the last number: Double-click the MFB.
2. Reject a call: Long press the MFB for about 2 seconds.
3. Answer a call: Press the MFB once.
4. Hang up a call: Press the MFB once.

Music Play/Pause:

1. Play/Pause: Press the MFB once.
2. Next song: Press the "Next" button.
3. Previous song: Press the "Previous" button.

-04-

Playing Music from U Disk/micro SD card

1. Tune the car FM radio to a blank FM station.
2. Tune the FM transmitter into the same frequency with the car FM radio.
3. Insert the U disk/micro SD card into the device, it will automatically detect and play the MP3/WMA/FLAC/WAV/APE format music.

Music source:

The product plays music from the last connected device, and will memorize it next time. If Bluetooth, U disk, micro SD all connected, long press the "Next" button for about 4 seconds to switch music source. When switch to Bluetooth music, you have to press play button to start the music.

FCC Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

-05-

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

-06-

Correct Disposal Of This Product



(Waste Electrical & Electronic Equipment)

This making shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

-07-

T25车载蓝牙MP3播放器




说明书

产品特点:

1. 通过FM信号将音乐从U盘或Micro SD卡传输到汽车音响播放。
2. 通过FM信号将蓝牙智能设备的音乐传输到汽车音响播放。
3. 独特的高清数码显示屏, 插入时显示汽车电压。
4. 开车时免提接听电话。
5. 2个USB端口, 可用于同时给各种智能设备充电。
6. 支持读取并播放U盘或Micro SD卡里面FLAC/WAV/APE等格式的无损音乐。

-01-

产品图解:



-02-

FM频率调节:

长按多功能按键约2秒钟, 显示屏闪烁表示进入FM频率调节模式。

1. 旋转多功能按键调节频率。
2. 按“下一曲”或“上一曲”增加或减少频率。

音量调节:

旋转多功能按键调节音量。

车载蓝牙MP3播放器操作说明:

1. 将MP3播放器插入汽车点烟口。
2. 插入后, MP3播放器将自动开机, 显示屏会显示汽车电压值, 然后闪烁表示产品等待配对中。
3. 打开智能设备的蓝牙功能, 搜索蓝牙设备并选择“T25”配对。
4. 如果配对成功, 显示屏将停止闪烁并显示FM频率。
5. 将汽车FM收音机调到空白的FM频道。
6. 将MP3播放器调到和汽车FM收音机相同的频道。
7. 打开智能设备的音乐播放器/导航软件, 就可以将音乐, 导航或电话传输到汽车音响系统播放。

-03-

注意:

1. 产品下次开机时, 将自动连接到最后配对的设备。(保证先打开智能设备的蓝牙, 然后再将产品开机。)
2. 为获得最佳音质, 请将智能设备和MP3播放器的音量调至最高水平。
3. 任何MP3播放器的信号有时会被周围的无线电或类似的频率信号干扰, 从而产生噪声, 这是正常的现象。
4. 如果噪音太大, 请确认MP3播放器的频道和汽车的频道是否一致, 或者尝试另一个空白FM频道。

拨打/接听电话:

通过蓝牙成功连接到手机后, 可以通过MP3播放器拨打或接听电话。

1. 重拨最后一个号码: 双击多功能按键。
2. 拒绝来电: 长按多功能按键约2秒钟。
3. 接听电话: 按多功能按键一次。
4. 挂断电话: 按多功能按键一次。

音乐播放/暂停:

1. 播放/暂停: 按多功能按键一次。
2. 下一曲: 按“下一曲”按钮。
3. 上一曲: 按“上一曲”按钮。

-04-

播放U盘/Micro SD卡里面的音乐:

1. 将汽车FM收音机调到空白的FM频道。
2. 将MP3播放器调到和汽车FM收音机相同的频道。
3. 将U盘/ Micro SD卡插入MP3播放器, 它将自动检测并播放MP3/WMA/FLAC/WAV/APE等格式的音乐。

音源切换:

MP3播放器默认播放最后连接的音源, 记忆到最后一首开头的位置, 下次开机会继续播放。如果蓝牙, 3.5mm音频口, U盘, Micro SD卡全部连接了, 长按“下一曲”按钮约4秒钟即可切换音源。切换到蓝牙音乐时, 需要按播放按钮才能开始播放音乐。

注意事项:

1. 本品仅限车上使用。
2. 请勿拆解、强烈撞击、挤压本产品。
3. 请保持产品的清洁和干燥, 不要用化学物品、肥皂、湿布擦拭本产品。
4. 禁止将本产品丢入火中。
5. 离开汽车时请务必将产品从点烟口拔出。
6. 请将产品存放在干燥、远离潮湿及腐蚀性物品的地方。
7. 请看管好小孩, 以确保他们不将产品当作玩具来玩。
8. 请按国家的环保法规处理废弃产品。

-05-

合格证

检 验 员: _____
生产日期: _____

保 修 卡

一、客户资料

用户姓名: _____
性别: ☐男 ☐女
联系电话: _____
联系地址: _____
邮编: _____
机身编号: _____

二、经销商资料:

机器型号: _____ 颜色: _____
购买日期: _____
发票号码: _____
经销商名称: _____
经销商电话: _____

经销商单位 (盖章) _____ (无盖章本卡无效)
年 月 日

-06-