

singbox®

User Manua T2 Athena



singbox

Catalog

Attention.....	1-2
To make sure you can use it safely, please read it before using	
Support device	3
Support Bluetooth device	
Packing list.....	3
List of articles and giftbox	
Products diagram.....	4
Know of the key functions of product	
Using preparation.....	5
Charging	
Power operation	
Operation method.....	5-7
Matching with your Bluetooth device	
Tracks changed and VOL+/-	
Play/Pause	
Mobile phone hands-free function;	
Other functions.....	7-8
Using as external speaker	
Revert to initial state	
Trouble shooting.....	8
Know of method of trouble shooting	
Others.....	9
Technical parameter	
About stoppage	

Attention

About product operation

- Do not stuck in power when the mobile products.
- Moving the product, please remove the movable device, power off, pull out the plug from the socket.
- When be powered , do not pull out the plug from the socket.

Maintenance of products

- when need maintenance ,please cut off the power.
- stained areas, use a soft cloth.
- polluted areas, with a soft cloth dampened with water, wipe lightly after wringing well.
- use of chemical cloth, it may cause product deterioration.
- use of gasoline and thinner, may result in product deterioration, paint loss.
- Use a strong detergent, may lead to product discoloration, deterioration, loss processes.
- use of pesticides and volatile agents may catch fire.
- long time contacted with rubber items , may lead to product paint falls off.
- stick sticker or tape , easy to cause the product of discoloration and paint falls off.

The temperature of the product

- set in a confined space use and prolonged use,products will be hot , not failure.
- Please do not put some items which easily deformed by heat close to the speaker
- Product fever, immediately cut off the power.

About liquefaction

- set in a place with a large temperature difference, sometimes may be liquefied phenomenon.
- liquefied, not the normal operation, may be the cause of the trouble.
- liquefied, please turn off the power and placed for a while.
- cold areas use, please pay special attention to the generation of liquefied phenomenon.

Damage on the magnetic and electromagnetic

- In order to avoid the magnetic impact, please do not put a machine equipped with a magnet near the product.
- In order to avoid the impact of electromagnetic waves, do not produce electromagnetic waves of mobile phones and the machine near the product.
- As the electromagnetic and battery damage, there may be an image disorder,resulting in noise, important data may be lost.

1

Operation of external storage device

- Please carefully read the external storage device subsidiary operating instructions.
- custody, please avoid static electricity and electromagnetic waves place.
- terminals, please do not let garbage and dust like a foreign body attached to the top.
- Do not bend, peel, impact.
- Do not pour liquid.
- paste stickers and tape, may not be drawn into the connector, the connector leading to damage.

About the data

- media data stored in memory, may be lost as for incorrect operation and failure
- media data stored in memory, may be lost as for magnetic and electromagnetic damage .
- media data stored in memory, may be lost as for temperature, humidity and the effects of sunlight.
- important data, recommend backing up to other memory media.
- data management, please refer to the guests responsibility to carry out.

Disclaimer

- non-packaging in accordance with operating instructions and instructions of user manual ,supplier will not bear all the responsibility.
- fall, impact, pressure, load failures produced by external factors, supplier does not bear all the responsibility.
- due to fire, earthquake, lightning, wind and flood damage resulting from failures and other natural disasters, supplier does not bear all the responsibility.
- Due to the loss of continuous using, degradation of cause of failure,supplier does not bear all the responsibility.
- media data stored in the memory is lost, supplier does not bear all the responsibility.
- Using the product , arising from disputes of commercial interests, supplier does not bear all the responsibility.
- Using the the product ,occurred with the other failure of the mobile devices, supplier does not bear all the responsibility.
- Because of the associated mobile devices of interchangeability arising from that the products can not be used, supplier does not bear all the responsibility.
- Because of the state of the memory media and data arising from that the product can not be used, supplier does not bear all the responsibility on the corresponding external storage devices.

Temporarily not in use

- To save power, turn off the power after use.
- Long time not use, remove the plug from the outlet.
- Follow the instructions above marked the operation of the operating temperature,operating humidity range of newspaper management.

2

Support external device

Support Bluetooth device



The product support Bluetooth device as below:
Bluetooth icon+English, IPHONE, IPAD

Note

- Some part of different brands of Bluetooth devices may cause incompatibility



Packing list

Thanks for purchasing T2 speaker


T3 Bluetooth speaker.....	1pc
Audio cable.....	1pc
Data cable.....	1pc
User manual.....	1pc
Warranty card.....	1pc
Certificate.....	1pc

3

Product sketch map


Front view

1. Next / VOL+
2. Play/Pause
3. PRE/VOL-
4. Phone hands-free button
5. Speaker




Back View

1. External sound source input port
2. Mini USB charging port




Side View

1. Microphone



Right side View

1. Power ON/OFF
2. RESET



4

Using Prepare

Charging

- Please charge for the lithium battery according to below order.
1. Use USB cable connects to the dedicated USB power adapter or USB interface.
 2. When charging, the red indicate under hands free button will be shine
 3. After full charging, the red indicate will be dying out.

- When low battery, indicate light will turn to red, shining immediately, it mean it need be charging.
- When battery finish, it will auto power off, please charging it to work again.

- Charging time is 3-4 hours, it will be change according to different dump energy.
- Please make sure charging it by 12 hours for your first time using.

Power operation

- Open power
Please put "ON" at the side of "POWER" this product, when listening "DIDA", blue light will shine soon, it mean power on.
- Closed power
Please put "OFF" at the side of "POWER" this product, when listening "DIDA", indicate light will die soon, it mean power off.

Operation method

Matching with your Bluetooth device

1. After opening the product, the blue indicator is blinking rapidly, it means it is searching matching Bluetooth devices;
2. Please open Bluetooth device on your phone or IPAD and reach equipment.
3. When reaching "T3" device, click to link, the prompt to enter a password, enter "0000", and confirm.
4. When the blue light indicator turns slowly twinkle, whereby means connection now.
5. After connection, you can play music on your phone or IPAD, enjoy the fun.

5

- Maybe the method of operation with some Bluetooth device are different from it.

Note:

1. After disconnect using Bluetooth or cut down power, please wait for 30 seconds then connect it again. (two Bluetooth devices need stop responding first)
2. Most of the True Brand name Bluetooth device and the product as long as the match well, the two devices with Bluetooth opened can automatically connect; Individual brand mobile phone can't automatically connect, it can match with Bluetooth according to the steps of manual settings.

Kind reminder: This Bluetooth speaker is in 2.4G open channel, it may be disturbed by wireless router, strong electromagnetic wave; If this Bluetooth speaker work effect is not good (such as no access or without signal) please check and remove the sources may caused problem.

Tracks changed and VOL+-

● PRE/Next

1. When using this product to play, short press to change to next song.
2. Short press button to turn back previous song.

● VOL+-

1. When playing music, long press button to increase VOL.
2. Long press button to decrease VOL.

● Play/Pause


1. When playing, press button, can pause.
2. When pause, press button to play.

Kindly Note:

After connect with most true brand Bluetooth device, this product can control Play/Pause, PRE/Next, individual brand name mobile phone can not control like this, only adjust VOL+-.

6

Mobile Phone Hands-Free Function




When you use mobile phone connect with this product to play music, when it have calling in, you can press hands-free button (Green button) to use it directly talking.

- When calling come, music will pause; after lose calling, auto to play music again.
- During a call, press the phone hands-free key again, the current call will end

Other function

Using as external speaker

Audio data line is connected with a computer and a music player, can be used as external speakers.



7

Revert to initial state

When machine appear fault, can't process any operation, please press to initial state.

After using key, this product is stored connection data to be removed, need to link Bluetooth devices again, please refer to the "method of operation steps" chapter.

Trouble shooting

Fast solution method of Machine shooting

Problems	Reasons	Resolution
Can't power on	Battery is off or destroy	change or recharge the battery
Can't connect with Bluetooth device	Password error	Please enter correct password (password is 0000)
	The name of Bluetooth device incorrect	This machine is the default name for "T2"

8

Others

Technology Parameter

T2	
Speaker type	Wireless speaker
Speaker system	Key-press . Single track
Main feature	Bluetooth function; supports hands-free answer an incoming call function; Broadcom mainstream chip receiver distance of 10 m.; consistent with the iPhone, Ipad Bluetooth module, match better performance
Power mode	Built in Li-battery 700 MAH; MINI USB port 5V/500MA
External sound source input	Support
Technical parameter	Power rating: 3W ; Frequency response: 120Hz-20KHz
	Distortion: 0.1%(3.7V/1K/0.5W)
	S/N: 82dB; Input Sensitivity: 500mv
Other feature	Fit with Bluetooth V 2.1+EDR (A2DP) (Bluetooth standard)
Speaker size	Diameter 50×length 155mm
Packing list	Speaker ×1 Manuel book ×1 Warranty card ×1 Line in cable ×1 MINI USB cable×1

9

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.105 Information to the user.

(b) For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.