


# TAIDE ELECTRONICS

## BT162 Bluetooth speaker User manual



Distinguished Customers,

Thank you for purchasing this Bluetooth speaker BT162. Before getting started, please read the user's manual carefully so as to ensure proper operation and optimized performance of this product. With stylish outer appearance, compact structure, high fidelity sound and multi-functionality, it has obtained patents concerning its outer appearance and adopted advanced electric and sound technology in the industry, ultimately making itself the best choice to hook up with your devices such as tablet, cellphone and digital music player etc. perfectly by presenting you exceptional stereo effect either you are at home, on vacation or at work.


### I. Precautions

- Please store and use this product at the ambient temperature;
- Do not expose this product to the rain or damp surroundings;
- Prevent this product from falling that could result in serious damage;
- Do not dismantle, repair or modify this product on your own;
- In order to avoid any risk, do not dispose this product inappropriately or toss it into the fire as there is a built-in lithium battery.

### II. Considerate Hints

- 1) Do not turn up the volume to a fair high level constantly as this could shorten the service life of this product or impair your hearing;
- 2) When encountering any fault during operation, please cut off the power supply and disconnect the USB cable to prevent further damage to the speaker or other components;
- 3) The Bluetooth transmission range or connectivity could be affected by low battery power. In that case, please recharge immediately.

### III. Outer Appearance and Function Buttons



+ :Upward: Press and hold the button to decrease volume, press is to select songs upwards while playing music.

- : Downward: Press and hold the button to increase volume; Press is to select songs downwards.

▶ : Play/Pause/ Pick up the call/hang up the call: Press this button to pause, to resume normal operation or pick up the incoming calls in the Bluetooth playback mode. Long Press ▶ to start after power supply is connected and long press ▶ to shut down in operation.

### IV: Product parameter

Model Number: BT162

Bluetooth spec : Bluetooth 4.0

Transmission distance : ≤10M

Power: DC 5V--500mA-2A

Built-in battery:7.4V/2000mah

Battery: 2000mAh

Output power : 10W\*2

Frequency response : 90Hz-20KHz

Sensitivity : 80db±2db

SNR : ≥76dB

### V.System composition:

1.Speaker\*1

2. User manual \*1
3. Gift Box \*1
4. USB charge cable \*1
5. AUX Cable\*1

## VI: Common function description

**Power-on Status:** Long press the Power Button to turn the speaker on and it beeps simultaneously with the blue indicator Appear.

**Bluetooth Connection:** Once switched on, the speaker starts searching for other Bluetooth devices automatically and at

the same time, the bluetooth indicator goes on and off. When found a Bluetooth device, the speaker prompts whether to pair up or not. If selected Yes, it pairs up with the device and meanwhile, the blue indicator flashes slowly and a beep is also generated by the speaker. If failed to detect any other Bluetooth device within 5minutes, the speaker will shut itself down. Turn it back on again to start search. All the paired devices will engage in automatic connection when the speaker is turned on.

Hints: Please recharge when the battery loses its power considerably or the connection is failed.

**Bluetooth music playback:** When connected, the speaker plays music immediately. Press + and - to select tracks upwards or downwards. Press and hold + and - to adjust the volume. While playing music, press  to pause and  to resume

**Call Pick-up:** After connected with the cellphone successfully, the speaker beeps when a call comes in. Press  to pick it up and to terminate conversation, press  one more time.

**AUX playback:** Use the supplied audio cable to connect the speaker to another music player such as computer by plugging one end to the speaker's AUX port and the other end to the music player's audio port. Plug and play mode shall be supported. Press Mode button to switch into working mode, hold "Upward" or "Downward" button for 3 seconds to adjust volume. Click " " button, the voice shall be silent under the condition of AUX and then click " " to open the voice.

**Intelligent Quick Recharge:** Recharge can be performed in the standby mode or power-off situation. Before recharging, plug the mini-USB end of the supplied USB cable to the speaker's USB port and the other end to the USB port of the computer or the USB recharger.

## VII: Compatibility

Bluetooth V4.0 consists of protocols like A2DP, AVRCP and HFP and so on.

#### IV. Trouble shooting

<b>Faults</b>	<b>Phenomena</b>	<b>Solutions</b>
Unable to pair up with other devices		<ol style="list-style-type: none"><li>1. Check whether the speaker is still in the process of search or switch it off and then on.</li><li>2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Please turn them off.</li></ol>
The sound is rather low or distorted		<ol style="list-style-type: none"><li>1. Check the Bluetooth device's volume and then adjust it to a proper level.</li><li>2. Recharge the battery</li></ol>
The music stops from time to time		<ol style="list-style-type: none"><li>1. Check whether the speaker's effective transmission range is exceeded or there is an obstacle standing between the speaker and other Bluetooth devices.</li></ol>
The Bluetooth indicator remains off		<ol style="list-style-type: none"><li>1. It suggests the battery power drops quite low and retry once being recharged.</li><li>2. Turn it on again.</li></ol>

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.