


Dongguan Taide Industrial Co., Ltd.

WBT225 WIFI & Bluetooth speaker User manual



Distinguished Customers,

Thank you for purchasing this WIFI & Bluetooth speaker WBT225. Before getting started, please read the user's manual carefully so as to ensure proper operation and optimized performance of this product. With stylish outer appearance, compact structure, high fidelity sound and multi-functionality, it has obtained patents concerning its outer appearance and adopted advanced electric and sound technology in the industry, ultimately making itself the best choice to hook up with your devices such as tablet, telephone and digital music player etc. perfectly by presenting you exceptional stereo effect either you are at home, on vacation or at work.

I. Precautions

Please store and use this product at the ambient temperature;

Do not expose this product to the rain or damp surroundings;

Prevent this product from falling that could result in serious damage;


Do not dismantle, repair or modify this product on your own;

In order to avoid any risk, do not dispose this product inappropriately or toss it into the fire as there is a built-in lithium battery.

II. Considerate Hints

- 1) Do not turn up the volume to a fair high level constantly as this could shorten the service life of this product or impair your hearing;
- 2) When encountering any fault during operation, please cut off the power supply and disconnect the USB cable to prevent further damage to the speaker or other components;
- 3) The WIFI & Bluetooth transmission range or connectivity could be affected by low battery power. In that case, please recharge immediately.

III. Outer Appearance and Function Buttons



▶▶ : short press: Play/pause

⏻: Long press the Power Button to turn the speaker on or off

🎤: BT mode :short press for pick up and hand up the phone

🎤: WiFi mode: short press to activate the Amazon voice

M: Bluetooth、WiFi switchover, long press WPS to pair

⊕: Upward: Press and hold the button to decrease volume, press is to select songs upwards while playing music.

⊖ : Downward: Press and hold the button to increase volume; press is to select songs downwards.

IV: Product parameter

Model Number:: WBT225

Battery: Lithium battery 2000mAh

Maximum Output power : 3W

Frequency response: 90Hz-20KHz ±2db

Sensitivity: 80db±2db

SNR: ≥75dB

USB Power: DC 5V--700mA

BT Transmission distance: ≤10M (Due to environmental factors and the connection to the Bluetooth device will be differ)

WiFi Transmission distance: ≤100M (open straight -line distance)

Bluetooth spec :

※ Version : Bluetooth V2.1+EDR

WiFi Spec :

※ support 802.11 b/g/n wireless stander

※ support common online audio source : Spotify , Amazon , iHeartRadio, TIDAL, Pandora

- ※ Support Amazon voice recognition assistant "Alexa", in addition to listen to music, the user can also use the Echo takeout, take a taxi, scheduling, weather query and so on.
- ※ Provide application software base on Android、IOS.PO.

V. System composition:

1. Speaker 1
2. User manual /warranty card 1

VI: Common function description

Power-on Status: Long press the Power Button “” for 3 seconds to turn the speaker on and it beeps after 30S simultaneously with the white indicator  Appear. Long press Power Button “” for 3 seconds to turn the speaker off

WiFi connection and use: on the power supply, 30 s, after the prompt speakers WiFi search automatically into the state, white light flash, connection OK after WiFi instructions of light (white light).Detailed connection reference MUZO player APP quickly using guide

Amazon voice use: Speakers connected to the Internet firstly, then login WiFi model into the APP Amazon account (detailed reference APP quickly using guide), after a successful login either through short press  voice interaction.

Bluetooth Connection: Once switched on, the speaker starts searching for other Bluetooth devices automatically and at the same time, the bluetooth indicator goes on and off. When found a Bluetooth device, the speaker prompts whether to pair up or not. If selected Yes, it pairs up with the device and meanwhile, the blue indicator flashes slowly and a beep is also generated by the speaker. If failed to detect any other Bluetooth device within 5minutes, the speaker will shut itself down. Turn it back on again to start search. All the paired devices will engage in automatic connection when the speaker is turned on.

Hints: Please recharge when the battery loses its power considerably or the connection is failed.

Bluetooth music playback: When connected, the speaker plays music immediately. Press +/–” to select tracks upwards or downwards. Press and hold +/–” to adjust the volume. While playing music, press  to pause and  to resume.

Call Pick-up: After connected with the cell phone successfully, the speaker beeps when a call comes in. Press to “” pick it up and to terminate conversation, press “” one more time.

AUX playback: Use the supplied audio cable to connect the speaker to another music player such as computer by plugging one end to the speaker's AUX port and the other end to the music player's audio port. Plug and play mode shall be supported. Press Mode button to switch into working mode, hold “Upward” or “Downward” button for 3 seconds to adjust volume. Click “” button, the voice shall be silent under the condition of AUX and then click “” to open the voice.

Special note: starting up WiFi priority, when inserted into the AUX support after priority mode, now return to your WiFi should unplug AUX, or restart..

Intelligent Quick Recharge: Recharge can be performed in the standby mode or power-off situation. Before recharging, plug the mini-USB end of the supplied USB cable to the speaker's USB port and the other end to the USB port of the computer or the USB recharger.

VII: Compatibility

Bluetooth V2.1+EDR consists of protocols like A2DP, AVRCP and HFP and so on.

IX: Trouble shooting

Faults Phenomena	Solutions
Unable to pair up with WIFI	<ol style="list-style-type: none"> 1、 check whether the router with normal boot; 2、 Check whether the router is too far ,pls try to connect the full signal state. 3、 After connection OK WIFI will grow brighter
Amazon Alexa voice communication is not normal	<ol style="list-style-type: none"> 1. Confirm whether there is connected to the Internet, Amazon Alexa web connection is normal; 2. Confirm if the internet speed is normal; 3. Due to network problems in mainland China voice sometimes unsteadiness ,Pls use 4 g networks of mobile will be relatively a bit faster.
The sound is rather low or distorted	<ol style="list-style-type: none"> 1. Check the Bluetooth device's volume and then adjust it to a proper level. 1、 Recharge the battery
The music stops from time to time	<ol style="list-style-type: none"> 1. Check whether the speaker's effective transmission range is exceeded or there is an obstacle standing between the speaker and other Bluetooth devices.
The Bluetooth indicator remains off	<p>It suggests the battery power drops quite low and retry once being recharged. Turn it on again.</p>

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statements:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.