User Manual

Thank you for purchasing the Samsung Bluetooth Mono Headset WEP20X, we hope you will be delighted with its operation.

Please read this user's guide to get started, and to make the best use of the headset's many features.

Driving safety


- When you are driving a car, driving is your first responsibility.
- When using your headset while driving, follow local regulations in the country or region are in.

BEFORE USING YOUR HEADSET

Checking phone compatibility

Your headset is compatible with most Bluetooth phones that are compliant with Bluetooth version 2.0 and support the headset and/or hands-free profile(s). Ensure that your phone has Bluetooth capability by visiting your phone manufacturer's web site.

Your headset overview



Checking the accessories


Make sure you have the following items with your headset: Charging case, Travel adapter, Manual, 2 headset hooks

Charging the headset


Your headset uses a rechargeable battery. You must charge the battery fully before using the headset for the first time.



1. Put the headset in the supplied charging case and close the cover.



- 2. Plug the travel adapter into the case's charging socket.
- 3. Plug the travel adapter into the electrical outlet.



- Charge the headset until the red light on the headset turns to blue.
- The headset will be fully charged in approximately 2 hours.
- 4. Remove the travel adapter from the case.
- WARNING : Do not attempt to charge the headset with anything other than the travel adapter provided. Using unauthorized travel adapter may damage the headset.
- IMPORTANT : Removing the travel adapter from the case during charging will turn the headset off and stop the charging progress. The headset cannot be used while charging.

Storage of the headset

- Always store the headset with the power off and make sure it is safely protected.
- Avoid storage at high temperatures (above 40C/104F). such as in a hot vehicle or in direct sunlight. (Storage at high temperatures can damaged performance and reduce battery life).
- Do not expose the headset or any of its supplied parts to rain or other liquids.



BASIC OPERATIONS

Turning the headset on/off

То	Press and hold	You will hear	You will see
Turn the headset on	The Multi-Function	A tone	The indicator light
	button for 4		flashes while the
	seconds until you		power is on (see
	see 4 blue flashes		Meaning of the
	on the indicator		indicator light).
	light, then release.		
Turn the headset	The Multi-function	Series 2 tones	The indicator light
off	button for 4		stops flashing.
	seconds until you		
	see 2 blue flashes		
	on the indicator		
	light, then release.		

Meaning of the indicator light

Light	-				Tone				Status
Flashes i	in	blue	every	8	Quick	series	of	2	The headset is in Active
seconds					tones.(Active mode starts.)		mode.		
									• The headset has an
									active call in progress
									• You can talk up to 4
									hours. *
Flashes i	in	blue	every	3	Quick	series	of	2	The headset is in Standby
seconds					tones.(St	andby	mo	ode	mode.
					starts.)				• The headset is waiting
									for a call.
									• The headset can be in
									Standby mode up to 70
									hours.
Flashes i	in	red i	nstead	of	5 tones every 20 seconds.		The battery of the headset		




blue.	is low.
	Recharge the battery.
	• There is only 1 minute
	of talk time left

* Depending on the phone type and usage, the actual time may vary.

Pairing with your Bluetooth phone

Pairing will create a unique and encrypted wireless link between two Bluetooth enabled devices, such as your Bluetooth phone and Bluetooth headset.

- 1. Ensure that the headset is off (see Turning the headset on/off).
- 2. Press and hold the Multi-Function button until the indicator light turns on in blue(approximately 8 seconds).



- 3. Set your Bluetooth phone to discover the headset by following your phone's guide. Typically, the steps involve going to a 'Setup', 'Connect', or 'Bluetooth' menu on your phone and then selecting the option to discover Bluetooth devices.
- 4. Your phone will find the Samsung WEP20X headset and ask if you want to pair with it. Confirm this by pressing the Yes or OK key.
- 5. Enter a passkey or PIN, 0000(4 zeros), then press the Yes or OK key.
- IMPORTANT : If pairing was successful, the indicator light will flash in blue 10 times rapidly before going to flashing every 3 seconds. If unsuccessful, the light remains on, and you will need to re-attempt pairing.

Wearing the headset

Wear the headset on your ear. In general, you will get better performance when there are no obstructions (including parts of your body) between the headset and the phone. Depending on what ear you are going to wear the headset, simply adjust the hook accordingly.

Dream Technology Co., Ltd.

Making a call

Left

Making a voice activated call

If the voice recognition feature is on, you can make a voice activated call.

1. Press the Multi-Function button once. You will hear the voice-activation tone.

User Manual

2. Say the name of the person you wish to call.

Depending on your phone, this feature is not supported.

A Right

Redialing the last number

If the voice recognition feature is off.

Press and hold the Multi-Function button for $2\ {\rm seconds}, {\rm twice}.$

If the voice recognition feature is on,

- 1. Press the Multi-Function button and listen for the voice-activation tone. When you hear it, press the button again to cancel the feature.
- 2. Press and hold the Multi-Function button to access the recent call list.
- 3. Press and hold the Multi-Function button to make a call to the last number you have dialed or received.

IMPORTANT : Depending on your phone, you should press the Multi-Function button briefly or press and hold it to redial the last number.

Ending a call

Press the Multi-Function button once.

Answering a call

After you hear the ring tone, press the Multi-Function button once.

If you answer the call with your phone, you can transfer the call to the headset by pressing the Multi-Function button.

IMPORTANT : Do not hold the Multi-Function button down too long when making a call with your voice, ending, or answering a call. This should only be a quick tap.



User Manual

Rejecting a call

When you receive a call, press and hold the Multi-Function button for 2 seconds to reject the call. Depending on your phone's setting or type, you may only be able to mute the ringer or this feature is not supported.

Adjusting the volume.

Press []on the side of the headset to increase the volume level and [] to decrease the volume level.

Using enhanced feature.

Enhanced feature are available for phones that support the hands-free Bluetooth profile and enhanced features.

Answering a second call(switching between 2 calls)

When your phone notifies you of another incoming call while you are on a call, press and hold the Multi-Function button for 2 seconds.

You can switch between calls by pressing and holding it for 2 seconds.

Depending on your phone, this feature is not supported.

Placing a call on hold

While you are on a call, press and hold the Multi-Function button for 2 seconds.

To retrieve the call, press and hold the Multi Function button for 2 seconds again.

Depending on your phone, this feature is not supported.

Switching off the microphone

Press and hold the Up volume control button to switch off the headset's microphone. To switch it back on, press and hold the button again.

APPENDIX

Frequently asked questions

How far away from my phone will the	The operating range is typically up to 30
headset work ?	feet (10 meters).
Will the headset work with my cordless	The headset is not designed for use with
phone at home?	cordless phones.
Will the headset work with laptops, PCs,	The headset will work with devices that
and PDAs?	are compliant with Bluetooth version 2.0
	and support the headset and/or hands-free
	profile(s).

Dream Technology Co., Ltd.	ser Manual
Will anything cause interference with my	Appliances such as cordless phones and
conversation when I'm using the headset ?	wireless networking equipment may cause
	interference with your conversation. To
	reduce any interference, keep the headset
	away from other devices that use or
	produce radio waves.
Will the headset interfere with my car's	The headset produces significantly less
electronics, radio, or computer?	power than a typical mobile phone. It also
	emits signals that are in compliance with
	the international Bluetooth standard.
	Therefore, you should not expect any
	interference with standard consumer-
	grade electronics equipment.
Can other Bluetooth phone users hear my	When you pair the headset to your
conversation ?	Bluetooth phone, you are creating a
	private link between only these two
	Bluetooth devices. The wireless Bluetooth
	technology used in the headset is not
	easily monitored by third parties, because
	Bluetooth wireless signals are significantly
	lower in radio frequency power than those
	produced by a typical mobile phone.
How do I take care of the headset?	To clean the headset, use a clean, soft
	cloth that is slightly damp.

Bluetooth

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Samsung is under license. Other trademarks and trade names are those of their respective owners.

Warranty and parts replacement

Samsung warrants that product as free of defects in material, design and workmanship for the period of one year from the original date of purchase.

If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased or qualified service center. The liability of Samsung and its appointed



Dream Technology Co., Ltd.

maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

- The warranty is limited to the original purchaser
- A copy of your receipt or other proof of purchases is required for a proper warranty service.
- The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation modification, or repair by unauthorized third parties
- The responsibility of Samsung products shall be limited to the repair or replacement of the product at its sole discretion.
- Specifically exempt from any warranty are limited-life consumable components such as batteries and other accessories.
- Samsung is not liable to for any incidental or consequential damages arising from the use or misuse of any Samsung product
- This warranty gives you specific rights and you may have other rights which vary from area to area.
- Unless otherwise instructed in the User Guide, the user may not, under any circumstance, attempt to perform service, adjustments or repairs on the unit, whether in or out warranty. It must be returned to the purchase point, factory or authorized service agency for all such work
- Samsung will not assume any responsibility for any loss or damage incurred in shipping. All repair work on Samsung products by unauthorized third parties voids any warranty.

Correct disposal of this product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wasted at the end of its working life .

To Prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recyling.

Dream Technology Co., Ltd.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

FCC NOTICE

Section 15.19 Labelling requirements

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference and
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Section 15.21 Information to user

The changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.

* IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.